

[Manuals.plus](#) /

› [eppfun](#) /

› eppfun cutemeet380 VR Bluetooth 5.2 Gaming Wireless Earbuds User Manual

eppfun cutemeet380

eppfun cutemeet380 VR Bluetooth 5.2 Gaming Wireless Earbuds User Manual

Model: cutemeet380 | Brand: eppfun

1. INTRODUCTION

Thank you for choosing the eppfun cutemeet380 VR Bluetooth 5.2 Gaming Wireless Earbuds. These earbuds are designed to provide a low-latency audio experience for gaming across various platforms, including Meta Quest 2, PS5, PC, and Nintendo Switch. This manual provides detailed instructions on how to set up, operate, and maintain your earbuds to ensure optimal performance.

2. PACKAGE CONTENTS

Please verify that all items are present in your package:

- eppfun cutemeet380 Wireless Earbuds (Left and Right)
- Charging Case
- 2.4GHz USB-C Dongle
- USB Type-C Charging Cable
- Multiple sizes of Ear Tips
- User Manual
- Cleaning Cloth



Image: The eppfun cutemeet380 earbuds, their charging case, and various sizes of ear tips.

3. SETUP AND CHARGING

3.1 Initial Charging

Before first use, fully charge the earbuds and the charging case. Connect the USB Type-C charging cable to the charging case and a power source. The charging case takes approximately 1.5 hours to fully charge. The earbuds will charge automatically when placed inside the case.

The Earbuds can play for 6 hours on a single charge, and the charging case provides 24 hours of usage time.



24^H

Charging Case

6^H

Playback

1.5^H

Charging

Image: Earbuds inside the charging case, illustrating the 24-hour charging case capacity, 6-hour playback time per charge, and 1.5-hour charging time.

3.2 Powering On/Off

- **Power On:** Open the charging case, and the earbuds will automatically power on.
- **Power Off:** Place the earbuds back into the charging case and close the lid. They will automatically power off and begin charging.

3.3 Connecting to Devices

The eppfun cutemeet380 earbuds offer two connection methods: Bluetooth 5.2 and 2.4GHz wireless via the USB-C dongle.

3.3.1 2.4GHz Wireless Connection (Recommended for Gaming)

For low-latency gaming, use the included 2.4GHz USB-C dongle.

1. Insert the 2.4GHz USB-C dongle into a compatible USB-C port on your gaming device (e.g., Meta Quest 2, PS5, PC, Nintendo Switch, Steam Deck).
2. Ensure the earbuds are powered on and in pairing mode (usually indicated by a flashing light).
3. The earbuds will automatically connect to the dongle. A solid light on the earbuds or dongle will indicate a successful connection.

Plug the mini transmitter into the converter's USB-C port and charge it while you play to prevent the battery from running out.




Image: The mini 2.4GHz USB-C transmitter dongle plugged into a VR headset's USB-C port, with a charging cable connected to the dongle to allow simultaneous charging while playing.

2.4GHz Wireless USB-C Dongle

30ms Low Latency for Gaming



Image: An earbud and the 2.4GHz USB-C dongle wirelessly connected to a VR headset, demonstrating the low-latency gaming connection.

3.3.2 Bluetooth 5.2 Connection

For general use with mobile phones or other Bluetooth-enabled devices:

1. Open the charging case to power on the earbuds. They will automatically enter Bluetooth pairing mode if not connected to the 2.4GHz dongle.
2. On your device, go to Bluetooth settings and search for "eppfun cutemeet380".
3. Select the earbuds to connect. A voice prompt or indicator light will confirm successful pairing.

4. OPERATING INSTRUCTIONS

4.1 Touch Controls

The earbuds feature intuitive touch controls on their outer surface. Specific functions may vary slightly by device, but common controls include:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Volume Up:** Triple tap on the right earbud.
- **Volume Down:** Triple tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud during an incoming call.
- **Reject Call:** Press and hold either earbud for 2 seconds during an incoming call.
- **Activate Voice Assistant (Siri/Google Assistant):** Press and hold either earbud for 3 seconds.

4.2 Device Compatibility

The eppfun cutemeet380 earbuds are widely compatible with a range of gaming and mobile devices:

- Meta Quest 2 / Quest 1 / Quest 3
- PICO 4
- PlayStation 4 / PlayStation 5 (PS4/PS5)
- PC (Windows/macOS)
- Nintendo Switch
- Steam Deck
- Mobile Phones (iOS/Android)

Widely Compatible



PICO 4



Quest 1/2/3



PS4/PS5



PC



Steam Deck



Mobile Phone



Switch



Image: A visual representation of the wide compatibility of the eppfun cutemeet380 earbuds and their USB-C dongle, including PICO 4, Quest 1/2/3, PS4/PS5, PC, Steam Deck, Mobile Phone, and Switch.

5. MAINTENANCE

5.1 Cleaning

Regularly clean your earbuds and charging case to ensure optimal performance and hygiene. Use the provided cleaning cloth or a soft, dry, lint-free cloth. Do not use abrasive cleaners or immerse the earbuds or case in water.

5.2 Storage

When not in use, store the earbuds in their charging case to protect them and keep them charged. Store the case in a cool, dry place away from direct sunlight and extreme temperatures.

Pocket Friendly

Experience portability with a compact and lightweight design, including a pocket-sized charging case

COMFORTABLE

• • • •




Image: A hand demonstrating the compact and lightweight design of the charging case, easily fitting into a pocket, highlighting its portability.

5.3 Water Resistance

The earbuds are rated IPX5 water-resistant, meaning they can withstand splashes and sweat. They are not designed for

submersion in water. Avoid exposing them to heavy rain or showering with them.

6. TROUBLESHOOTING

If you encounter issues with your eppfun cutemeet380 earbuds, please refer to the following common solutions:

- **No Sound:** Ensure earbuds are charged, properly connected to your device (Bluetooth or dongle), and the volume is turned up on both the earbuds and your device.
- **Connection Issues:**
 - For Bluetooth: Turn off and on your device's Bluetooth, then try re-pairing.
 - For 2.4GHz dongle: Ensure the dongle is securely inserted and try unplugging and re-inserting it. Ensure no other 2.4GHz devices are causing interference.
 - Ensure earbuds are within range of the connected device.
- **Earbuds Not Charging:** Ensure the charging case is charged. Check that the earbuds are correctly seated in the charging case and that the charging contacts are clean.
- **Microphone Not Working:** Ensure the earbuds are selected as the input device in your device's audio settings. Check for any obstructions on the microphone ports.
- **Low Latency Not Achieved:** Ensure you are using the 2.4GHz USB-C dongle for gaming. Bluetooth connections inherently have higher latency.

If problems persist, please refer to the Support section for further assistance.

7. SPECIFICATIONS

Brand	eppfun
Model Name	cutemeet380
Connectivity Technology	Bluetooth 5.2, 2.4G Wireless (USB-C Dongle)
Latency	30ms (Gaming Mode via 2.4G Dongle)
Earbud Battery Life	Up to 6 hours
Total Playback Time (with Case)	Up to 32 hours
Charging Time (Case)	Approx. 1.5 hours
Charging Port	USB Type-C
Material	Acrylonitrile Butadiene Styrene (ABS), Metal
Control Type	Touch Control, Media Control

Frequency Range	2.4 GHz
Impedance	32 ohms
Sound Isolation	Adaptive Noise Reduction (CVC 8.0)
Microphone	Included (4 microphones)
Water Resistance	IPX5
Compatible Devices	Meta Quest 2/1/3, PICO 4, PS4/PS5, PC, Nintendo Switch, Steam Deck, Mobile Phones
Ear Placement	In-ear
Form Factor	True Wireless
Battery Composition	Lithium-ion
Manufacturer	eppfun

8. WARRANTY AND SUPPORT

8.1 Product Warranty

The eppfun cutemeet380 earbuds come with a **1-year manufacturer's warranty** from the date of purchase. This warranty covers manufacturing defects. Please retain your proof of purchase for warranty claims.



60-Day Return

Dissatisfied with a product?
Unable to resolve the issue through
support?Worry not! All products are
eligible for a full hassle free refund
within 60 days of purchase.

Image: Icon representing a 60-day return policy. All products are eligible for a full hassle-free refund within 60 days of purchase if you are dissatisfied or unable to resolve an issue.

8.2 Customer Support

Your satisfaction is important to us. If you experience any problems or have questions regarding your eppfun cutemeet380 earbuds, please contact us through the official eppfun store page or the customer questions & answers section on the product page. We aim to respond to compatibility questions within one business day.



Need Help?

Your satisfaction matters to us! Please contact us through the official eppfun store page if you're experiencing any problems. we will help you with any product issues.

Image: Icon representing a 'Need Help?' query. Contact us via the official eppfun store page for product issues.



Got a Question?

Not sure if your device is compatible with our product? Feel free to leave a question on the product page in the customer questions & answers section and we will get back to you within the next day.

Image: Icon representing a 'Got a Question?' query. For compatibility or other questions, use the product page's Q&A section.

© 2023 eppfun. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question