

LOVENSE Max 2, Nora

LOVENSE Max 2 Male Masturbator and Nora Rabbit Vibrator

USER MANUAL

Introduction

This manual provides comprehensive instructions for the LOVENSE Max 2 Male Masturbator and the LOVENSE Nora Rabbit Vibrator. These devices are designed for personal and couples' use, featuring app control and sync capabilities for an interactive experience.

Package Contents

- LOVENSE Max 2 Male Masturbator
- LOVENSE Nora Rabbit Vibrator
- Charging Cables
- User Manual (this document)

Setup

1. Charging the Devices

Before first use, fully charge both the LOVENSE Max 2 and LOVENSE Nora. Connect the provided charging cables to each device and a compatible USB power source. The indicator light on each device will show charging status and turn solid when fully charged.

2. Downloading the LOVENSE App

Download the official LOVENSE app from your device's app store (iOS or Android). The app is required for remote control, custom patterns, and sync features.

3. Pairing with the App

1. Ensure Bluetooth is enabled on your smartphone or tablet.
2. Turn on the LOVENSE Max 2 and LOVENSE Nora by pressing and holding their respective power

buttons.

3. Open the LOVENSE app and follow the on-screen instructions to search for and pair your devices.
4. Once paired, the devices will be ready for use via the app.

Lovense Remote App

Remote control, custom patterns, sound control, music syncing... explore more!

New York Berlin

Remote My Patterns Control Link Sound Game

Image: LOVENSE Max 2 and Nora devices alongside a smartphone displaying the LOVENSE Remote App interface, highlighting features like remote control, custom patterns, sound control, and game integration.

Operating Instructions

LOVENSE Max 2 Male Masturbator

The LOVENSE Max 2 features an improved shell, 360-degree contractions, and a redesigned vibrator. It offers various modes and can be controlled directly or via the LOVENSE app.

- **Power On/Off:** Press and hold the power button.
- **Mode Selection:** Use the physical buttons on the device or the app to cycle through vibration patterns and contraction intensities.
- **App Control:** Utilize the LOVENSE app for advanced features including custom patterns, sound control, music syncing, and interactive games.

Max 2 Male Masturbator

Explore a whole new world of pleasure



APP Remote Control



Connects in Less
than 3 seconds



Data Security



10000+ Modes



Sync to Video



Long Lasting
up to 120 Hours



Image: An illustration of the LOVENSE Max 2 highlighting its key features: App Remote Control, Connects in Less than 3 seconds, Data Security, 10000+ Modes, Sync to Video, and Long Lasting up to 120 Hours.

Extended, Powerful Vibrator

Vibes everywhere



Image: A detailed view of the LOVENSE Max 2, illustrating its extended and powerful internal vibrator mechanism, designed to provide sensations throughout the device.

LOVENSE Nora Rabbit Vibrator

The LOVENSE Nora is a Bluetooth rabbit vibrator with a wave-shaped shaft and a rotating head, designed for targeted stimulation. Its flexible vibrating arm is optimized for tactility.

- **Power On/Off:** Press and hold the power button.
- **Mode Selection:** Use the physical buttons or the app to adjust vibration patterns and intensity.
- **App Control:** Access various patterns and remote control options through the LOVENSE app.

Rotating Dildo Rabbit Vibrator

Rabbit massager with deep rotation and intense vibrations

- | | | | |
|---|---------------------------|---|-----------------------------|
|  | Dual Stimulation |  | 10,000+ Modes |
|  | App Remote Control |  | Compact |
|  | Soft Silicone |  | Long-Lasting |
|  | Curved Design |  | IPX6 Water-Resistant |



Image: An illustration of the LOVENSE Nora Rabbit Vibrator, detailing its features: Dual Stimulation, App Remote Control, Soft Silicone material, Curved Design, 10,000+ Modes, Compact size, Long-Lasting battery, and IPX6 Water-Resistant rating.

Experience Blended Orgasms

Clit and g-spot dual stimulation vibrator



Image: A graphic representation of the LOVENSE Nora demonstrating its ability to provide dual stimulation to both the clitoris and G-spot, indicating its design for blended sensations.

Sync Technology for Couples

The LOVENSE Max 2 and Nora can be synced together via the LOVENSE app. This allows for interactive play where the movements and sensations from one device are mirrored or controlled by the other, enabling shared experiences regardless of physical distance.

Unique Sync Technology

Sync with Lovense Max 2/Calor/Mission 2/another
Nora over any distance





Image: A couple engaging in remote interaction using LOVENSE devices, illustrating the unique sync technology that allows devices to respond to each other over any distance.

Unlimited Play Options



Couple play

Solo play



Long-distance play

Foreplay



Image: A collage depicting various usage scenarios for the LOVENSE devices, including couple play, solo play, long-distance play, and foreplay, showcasing their versatility.

Maintenance and Care

Proper care ensures the longevity and hygiene of your LOVENSE devices.

- **Cleaning:** Both devices are recommended for hand washing. Use warm water and a mild, toy-safe soap. Rinse thoroughly and allow to air dry completely before storage.
- **Lubrication:** LOVENSE water-based lubricant is recommended for use with these products. Avoid oil-based lubricants as they can damage silicone materials.
- **Storage:** Store devices in a clean, dry place away from direct sunlight and extreme temperatures. Keep them separate from other toys made of different materials to prevent damage.

Easy to clean

TPE Material and 3D Textured Particles



Image: A hand washing the TPE material and 3D textured particles of the LOVENSE Max 2, demonstrating its easy-to-clean design.

Troubleshooting

- **Device not turning on:** Ensure the device is fully charged. Connect it to the charger and wait for the indicator light.
- **Difficulty pairing with app:** Make sure Bluetooth is enabled on your phone and the device is powered on. Try restarting both the device and the app.
- **Weak vibrations/contractions:** The device may need to be recharged. Check battery level in the app if connected.
- **App connectivity issues:** Ensure your app is updated to the latest version. Check your internet connection for remote play features.

Specifications

- **Brand:** LOVENSE
- **Model:** Max 2 Male Masturbator, Nora Rabbit Vibrator
- **Materials:** Max 2 features TPE material; Nora features Soft Silicone.
- **Water Resistance:** Nora is IPX6 Water-Resistant.
- **Control:** App Remote Control, physical buttons.
- **Connectivity:** Bluetooth.
- **Features:** Max 2: 360-degree contractions, redesigned vibrator, improved sensors. Nora: Wave-shaped shaft, rotating head, flexible vibrating arm, dual stimulation.

Warranty and Support

For warranty information, product support, or any inquiries not covered in this manual, please visit the official LOVENSE website or contact LOVENSE customer service directly. Keep your proof of purchase for warranty claims.