

[Manuals.plus](#) /

› [Brookstone](#) /

› Brookstone 500mL Compact Portable Blender Instruction Manual

Brookstone B0CJJPJKLS

Brookstone 500mL Compact Portable Blender

INSTRUCTION MANUAL

Brand: Brookstone | Model: B0CJJPJKLS

PRODUCT OVERVIEW

The Brookstone 500mL Compact Portable Blender is designed for convenience and efficiency, perfect for creating shakes, smoothies, and for food preparation on the go. Its compact size and powerful motor make it an ideal companion for a healthy lifestyle.

Key Features:

- **500mL Capacity:** Ideal for single servings.
- **BPA-Free Construction:** Ensures safe food contact.
- **Two Blending Modes:** Regular and Pulse for versatile blending.
- **Safety Mechanism:** Blender operates only when components are securely aligned.
- **USB Rechargeable:** Convenient charging for portability.
- **Easy to Clean:** Dishwasher-safe jar and blending lid, with a self-cleaning function.



Image: The Brookstone Portable Blender in black, showcasing its compact design and an additional lid for on-the-go use.

SETUP

1. **Initial Charge:** Before first use, fully charge the blender base using the provided USB cable. The indicator lights will show charging progress.
2. **Assembly:** Ensure the blending jar is securely attached to the motor base. The safety mechanism requires proper alignment for operation.
3. **Lid Attachment:** Place the blending lid firmly onto the jar. For on-the-go convenience, you can use the additional lid provided.

Brookstone®

Dishwasher-Safe Parts

6-Blade Technology



flip top lid



Extra cap for easy on-the-go

Image: Diagram illustrating the key components of the Brookstone Portable Blender, including its dishwasher-safe parts and 6-blade technology.

OPERATING INSTRUCTIONS

1. **Prepare Ingredients:** Slice fruits and vegetables into small pieces for optimal blending. Use only a handful of ice, preferably crushed.
2. **Add Liquids First:** Always add liquids to the blending jar before adding ice or frozen items. This ensures proper blending and prevents the blades from getting stuck.
3. **Load Ingredients:** Place your prepared ingredients into the blending jar.
4. **Secure Lid:** Ensure the lid is tightly closed and the jar is securely attached to the base. The blender will not operate if the magnet at the jar's base is not perfectly aligned with the sensor over the push button.
5. **Start Blending:** Press the power button to begin blending. The blender features both regular and pulse modes. Note that the pulse mode can drain the battery faster, so avoid prolonged use in this mode.
6. **Blending Tips:** If the blender struggles to blend, turn it upside down and gently shake to redistribute ingredients, then restart the blending process.

Your browser does not support the video tag.

Video: An official demonstration of the Brookstone Personal Blender, showing its use for preparing smoothies, including ingredient preparation, blending, and cleaning.

CARE AND MAINTENANCE

- **Jar and Blending Lid:** The jar and blending lid are dishwasher-safe. For quick cleaning, you can also fill the jar with water and a drop of detergent, then run the blender. Use the included cleaning brush for thorough cleaning of hard-to-reach areas.
- **Motor Base:** The motor base is NOT dishwasher-safe. Wipe it clean with a damp cloth. Do not submerge the base in water to maintain its longevity.



Image: A detailed view of the blender's lid, highlighting its design for easy use and cleaning.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Blender does not turn on.	Jar not securely attached or misaligned safety magnet. Low battery.	Ensure the jar is firmly twisted onto the base and the magnet is aligned. Charge the blender fully.
Blender struggles or stops during blending.	Too much ice/frozen ingredients, ingredients too large, or insufficient liquid.	Add more liquid. Cut ingredients into smaller pieces. Turn the blender upside down and shake gently to free the blades, then restart.
Battery drains quickly.	Frequent use of pulse mode or heavy blending tasks.	Minimize prolonged use of pulse mode. Ensure ingredients are properly prepared to reduce blending effort.

SPECIFICATIONS

Feature	Detail
Brand	Brookstone
Color	Black
Special Feature	Portable
Capacity	500 Milliliters (approx. 17 oz)
Product Dimensions	3.5"D x 3.5"W x 11.5"H
Included Components	Lid (and additional lid)
Style	Countertop Blenders
Recommended Uses	Blending (smoothies, shakes, sauces)
Power Source	AC (USB Rechargeable)
Number of Speeds	1 (with pulse function)
Voltage	7.4 Volts
Material Type Free	BPA Free
Item Weight	1.41 pounds

WARRANTY AND SUPPORT

This Brookstone Portable Blender comes with a **Limited Warranty**. For specific details regarding warranty coverage, terms, and conditions, please refer to the warranty card included with your product or visit the official Brookstone website.

Should you encounter any issues or require assistance with your product, please contact Brookstone customer support. You can typically find contact information on the product packaging, the official Brookstone website, or through the retailer

where you purchased the item.

When contacting support, please have your product model number (B0CJJPKLS) and proof of purchase readily available to expedite the process.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question