

Dripex 71x47 Playpen

Dripex Baby Playpen User Manual

Model: 71"x47" Playpen

1. INTRODUCTION

This manual provides essential information for the safe and proper use, assembly, and maintenance of your Dripex Baby Playpen. Please read this manual thoroughly before assembly and retain it for future reference.

The Dripex Baby Playpen is designed to provide a safe and spacious environment for babies and toddlers to play and explore. Its robust construction and thoughtful design ensure both child safety and parental convenience.

2. SAFETY INFORMATION

WARNING: Failure to follow these warnings and instructions could result in serious injury or death.

- Always ensure all parts are correctly assembled and securely fastened before placing a child in the playpen.
- Do not leave children unattended in the playpen. Always supervise your child.
- Do not modify the playpen or use accessories not approved by Dripex.
- Keep the playpen away from open flames, heaters, or other heat sources.
- Ensure the playpen is placed on a flat, stable surface.
- Do not allow children to climb out of the playpen.
- Regularly inspect the playpen for any signs of wear, damage, or loose parts. Discontinue use if any damage is found.
- This playpen is NOT FOLDABLE for storage. Attempting to fold it may cause damage.
- The zippered door is designed to be opened only from the outside to prevent children from exiting unsupervised.

3. PACKAGE CONTENTS

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

- Fabric Playpen Enclosure (Oxford Cloth with Mesh)
- Steel Tubes (Long and Short)
- Reinforced Connectors
- Anti-slip Suction Cups (pre-attached to connectors or separate)
- Pull-up Rings (5 pieces)
- Instruction Manual

4. SETUP AND ASSEMBLY

Assembly of the Dripex Baby Playpen is designed to be straightforward and tool-free, typically taking less than 10 minutes. Follow these steps carefully:

1. **Unpack Components:** Lay out all steel tubes, connectors, and the fabric enclosure on a clean, flat surface. Identify the long and short steel tubes.
2. **Assemble Base Frame:** Connect the long and short steel tubes using the appropriate connectors to form the rectangular base frame. Ensure all connections are secure. The anti-slip suction cups should be at the bottom.
3. **Insert Vertical Supports:** Insert the vertical steel tubes into the designated sleeves on the fabric enclosure.
4. **Assemble Top Frame:** Connect the remaining long and short steel tubes to the top of the vertical supports using the remaining connectors, forming the top rectangular frame. Ensure all connections are firm.
5. **Secure Fabric:** Ensure the fabric enclosure is fully stretched and securely fitted around the assembled frame. The anti-collision corners should align with the frame corners.
6. **Attach Pull-up Rings:** Clip the 5 colorful pull-up rings to the top rail of the playpen as desired.
7. **Final Check:** Before use, gently push on all sides and corners to ensure the playpen is stable and all connections are secure.



Image: The fully assembled Dripex Baby Playpen, demonstrating its spacious interior suitable for multiple children and play items like colorful balls.



Image: Detailed view of the playpen's safety features, including reinforced connectors for stability, anti-collision padded corners, anti-slip suction cups on the base for secure placement, and the durable 300D Oxford fabric.

5. OPERATING INSTRUCTIONS

The Dripex Baby Playpen is designed for ease of use and provides a secure environment for your child.

- **Placing Your Child:** Gently place your child inside the playpen. Ensure they have enough space to move freely and play with toys.
- **Zippered Door:** The playpen features an external zippered door for easy access. This zipper can only be opened from the outside, ensuring your child remains safely inside.
- **Visibility:** The breathable mesh sides provide 360-degree visibility, allowing you to easily monitor your child from any angle.
- **Pull-up Rings:** The included pull-up rings can assist your child in developing arm strength and learning to stand.
- **Pet Separation:** The playpen provides a safe space to keep your baby separate from pets, ensuring a peaceful environment for the baby.

Mommy's Helper

360° See-Through Mesh



Image: An adult engaging with a child inside the playpen, illustrating the clear visibility provided by the 360-degree see-through mesh, which allows for constant supervision.

Free from Pets

Interact any time



Image: The playpen providing a secure barrier between a child and a pet, ensuring the baby's safety and undisturbed play time.



Image: A composite image demonstrating key operational features: the external zipper gate for controlled access, a child safely leaning against the sturdy fence, and a child utilizing the pull-up ring to aid in standing.

6. MAINTENANCE AND CLEANING

Regular maintenance and cleaning will extend the life of your Dripex Baby Playpen and ensure a hygienic environment for your child.

- Fabric Cleaning:** The playpen is made of washable Oxford fabric. For spills or stains, wipe clean with a damp cloth and mild soap. Allow to air dry completely before use.
- Frame Cleaning:** Wipe down steel tubes and connectors with a damp cloth as needed.
- Inspection:** Periodically check all connections, fabric, and mesh for any signs of wear, tears, or damage. Ensure all suction cups are intact and providing adequate grip.
- Storage:** Store the playpen in a dry, cool place away from direct sunlight when not in use for extended periods. Note that this model is not designed to be folded for storage.

Mutifunctional Activity Center



Image: The playpen in use as a multifunctional activity center, with an inset demonstrating the ease of cleaning the washable fabric with a damp cloth.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Playpen feels unstable or wobbly.	Connections are not fully secured; not on a flat surface.	Ensure all steel tubes are firmly inserted into connectors. Move to a flat, level surface. Check if suction cups are properly engaged.
Zipper is stuck or difficult to open/close.	Fabric caught in zipper; zipper mechanism dirty.	Carefully free any fabric caught in the zipper. Clean the zipper teeth with a small brush if necessary. Do not force the zipper.
Fabric appears loose or sagging.	Frame not fully extended or assembled correctly.	Re-check all frame connections to ensure they are fully extended and locked into place.

8. SPECIFICATIONS

- **Model:** Dripex 71"x47" Baby Playpen
- **Outer Dimensions (L x W x H):** 71 x 47 x 27 inches (approximately 180 x 120 x 68.5 cm)
- **Floor Area:** 23.17 Square Feet
- **Material:** 300D Oxford Fabric, Steel Tubes
- **Color:** Ash Grey
- **Item Weight:** 12.8 Pounds (approximately 5.8 kg)
- **Age Range (Recommended):** Toddler (suitable for babies 6-12 months and older, depending on development)
- **UPC:** 840325655796



Image: The Dripex Baby Playpen with clear labels indicating its outer dimensions: 71 inches in length, 47 inches in width, and 26 inches in height, providing a visual reference for its size.

9. WARRANTY AND SUPPORT

Dripex is committed to providing high-quality products. For any questions, concerns, or warranty inquiries regarding your Dripex Baby Playpen, please contact our customer support team.

Please have your product model and UPC (840325655796) available when contacting support to expedite assistance.

For the most up-to-date warranty information and contact details, please visit the official Dripex website or refer to your purchase documentation.

© 2023 Dripex. All rights reserved.