

[Manuals.plus](#) /

› [Sixfivsevn](#) /

› User Manual for Sixfivsevn 68 Inch Electric Fireplace

Sixfivsevn XH068A

User Manual

Sixfivsevn 68 Inch Electric Fireplace

Model: XH068A

1. INTRODUCTION

Thank you for choosing the Sixfivsevn 68 Inch Electric Fireplace. This multi-functional unit is designed to enhance your living space with realistic flame effects and efficient heating. It features a high-quality tempered glass panel, 12 flame and LED flame bed color modes, and flexible control options. This manual provides essential information for safe installation, operation, and maintenance of your new electric fireplace.

2. SAFETY INFORMATION

Please read all instructions carefully before installation and operation to ensure safe use and prevent injury or damage. Keep this manual for future reference.

- Ensure the power supply matches the voltage requirements of the fireplace.
- Do not operate the fireplace with a damaged cord or plug.
- Keep combustible materials at least 3 feet (0.9 meters) away from the front of the fireplace.
- Do not block air vents. Proper ventilation is crucial for safe operation.
- This fireplace is equipped with an overheating safety protection system that automatically turns off the unit if the internal temperature becomes too high.
- Always unplug the fireplace before cleaning or performing any maintenance.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- Electric Fireplace Unit
- Remote Control

- Mounting Hardware (screws, anchors, bracket)
- User Manual
- Crystal Glass Stone Media

4. INSTALLATION

The Sixfivsevn 68 Inch Electric Fireplace offers multiple installation options: recessed into a wall, wall-mounted, or inserted into a TV cabinet.




Figure 4.1: Product Dimensions and Multiple Installation Methods

Flexible Installation Modes



Figure 4.2: Flexible Installation Modes

4.1 Wall-Mounted Installation

1. Choose a suitable location on a wall, ensuring it is away from curtains, furniture, and other combustible materials.
2. Mark the desired height and level for the mounting bracket.
3. Drill pilot holes and secure the mounting bracket to the wall using appropriate screws and anchors.
4. Carefully lift the fireplace unit and hook it onto the mounting bracket. Ensure it is securely seated.
5. Plug the fireplace into a grounded electrical outlet.

4.2 Recessed Installation

1. Prepare an opening in the wall according to the fireplace's dimensions (68"D x 5.63"W x 17.71"H). Ensure there is adequate clearance for ventilation.
2. Run electrical wiring to the opening, ensuring it meets local electrical codes.
3. Slide the fireplace unit into the prepared opening.
4. Secure the fireplace to the wall studs using the provided screws.
5. Connect the fireplace to the electrical supply.

5. OPERATING INSTRUCTIONS

Your electric fireplace can be controlled using the button panel on the unit or the included remote control.

Button Panel Control



Figure 5.1: Button Panel Control



Figure 5.2: Remote Control Functions

5.1 Power On/Off

Press the **Power** button on the unit or remote control to turn the fireplace on or off.

5.2 Heat Settings

The fireplace offers two heat settings: 750W and 1500W. Use the **Heat** button on the panel or remote to cycle between these settings. You can also adjust the room temperature from 62°F to 82°F using the temperature controls on the remote.



Low noise Operation
Keep quiet 35-40db



Timer 0.5-9H



Figure 5.3: Heating Operation and Quiet Mode

5.3 Flame and Flame Bed Colors

Customize the ambiance with 12 flame colors and 12 LED flame bed colors, offering 144 combinations.

- Press the **Flame** button to change the flame color.
- Press the **Flame Bed** button to change the LED flame bed color.



SPARKLING-CRYSTAL

Sparkling crystal cannot be hidden in your eyes

12 FLAME-COLORS
12 Led Bed Colors

Double-twelve color presents you with its 144 combinations

Figure 5.4: Flame and Flame Bed Color Options

5.4 Timer Function

Set the timer for automatic shut-off from 0.5 to 9 hours using the **Timer** button on the panel or remote.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your electric fireplace.

- Always unplug the unit before cleaning.
- Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Ensure air vents are clear of dust and debris to maintain proper airflow.
- Check the power cord for any damage periodically.

7. TROUBLESHOOTING

If you encounter issues with your fireplace, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fireplace does not turn on.	No power, remote control battery low, unit switch off.	Check power outlet, replace remote battery, ensure unit is plugged in and power switch is on.
No heat output.	Heat function not activated, thermostat limiter triggered.	Activate heat function via remote/panel. If overheated, unplug and allow to cool for 15-20 minutes before restarting.
Flame effect not working.	Flame effect turned off.	Ensure flame effect is activated via remote/panel.
Remote control not responding.	Battery low or depleted, obstruction between remote and unit.	Replace remote battery. Ensure clear line of sight to the fireplace sensor.

8. SPECIFICATIONS

Feature	Detail
Brand	Sixfivsevn
Model Name	XH068A
Product Dimensions	68"D x 5.63"W x 17.71"H
Power Source	Corded Electric
Material	Tempered Glass
Installation Type	Wall Mount, Recessed
Heat Output	5100 British Thermal Units
Heating Coverage	Up to 400 square feet
Wattage	750W / 1500W (Adjustable)
Temperature Range	62°F to 82°F
Flame Colors	12 Options
LED Flame Bed Colors	12 Options
Timer	0.5 - 9 hours
Noise Level	Low (approx. 35-40dB)
Item Weight	47.3 Pounds

Feature	Detail
UPC	699838483989

9. WARRANTY AND SUPPORT

The Sixfivsevn Electric Fireplace comes with a **24 Months Warranty** from the date of purchase, covering manufacturing defects. Additionally, a **30-day easy returns** policy is available for your convenience.

For technical support, warranty claims, or any questions regarding your product, please contact Sixfivsevn customer service through the retailer's platform or visit the official Sixfivsevn store online.

We are committed to providing satisfactory service and high-quality products.

© 2024 Sixfivsevn. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question