

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

EarFun EarFun Free 2S

EarFun Free 2S Wireless Earbuds User Manual

Model: EarFun Free 2S

Brand: EarFun

INTRODUCTION

Welcome to the user manual for your EarFun Free 2S Wireless Earbuds. These earbuds are designed to provide a high-quality audio experience with features such as powerful bass, clear call quality, customizable sound via the EarFun App, and IPX7 waterproofing. This manual will guide you through the setup, operation, maintenance, and troubleshooting of your new earbuds.



Image: A pair of EarFun Free 2S wireless earbuds, showcasing their sleek black design with the EarFun logo and a blue indicator light.

WHAT'S IN THE BOX

Please check the package contents to ensure all items are present:

- EarFun Free 2S Wireless Earbuds
- USB-C Cable
- Eartips (various sizes)
- User Manual

PRODUCT OVERVIEW

Earbuds and Charging Case

The EarFun Free 2S earbuds feature a compact design for comfortable wear. The charging case provides extended battery life and convenient storage.

The Ideal Budget Earbuds

"The EarFun Free 2S earbuds have the full complement of touch-based controls, and **the quality of the background-noise-reducing microphones rivals that of earbuds 100 dollars or more.**"

 **Wirecutter**



Image: The EarFun Free 2S earbuds alongside their open charging case, illustrating their compact size and how they fit into the case.

Controls and Indicators

The earbuds utilize touch controls for various functions. A blue indicator light on each earbud provides status information.

- **Touch Control:** Manage playback, calls, and voice assistant.
- **LED Indicator:** Shows pairing status, battery level, and charging status.

SETUP

Initial Pairing

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically enter pairing mode, indicated by a flashing blue light.
3. On your device (smartphone, tablet, laptop), enable Bluetooth.
4. Search for "EarFun Free 2S" in the list of available Bluetooth devices and select it to connect.
5. Once connected, the earbud indicator light will turn solid blue or off, depending on the model.



Image: A smartphone screen displaying the Bluetooth settings, with "EarFun Free 2S" highlighted as a connected device, demonstrating the pairing process.

EarFun App Installation and Customization

For enhanced features and personalized settings, download the official EarFun App from your device's app store.

- **Personalized EQ:** Adjust sound profiles to your preference.
- **Customizable Controls:** Remap touch functions on the earbuds.
- **Firmware Update:** Keep your earbuds updated with the latest features and improvements.
- **Game Mode:** Reduce audio latency for a better gaming experience.

EarFun App for Personalization



Image: Screenshots of the EarFun App interface, showing options for personalized EQ, customizable controls, firmware updates, and game mode settings.

OPERATING THE EARBUDS

Wearing the Earbuds

Select the eartips that provide the best seal and comfort. Insert the earbuds into your ear canal and gently rotate to lock them in place.

Feather Light, Comfortable Fit



Image: A person wearing an EarFun earbud, demonstrating a secure and comfortable fit, with an inset showing how to properly insert and twist the earbud to lock it in place.

Basic Functions (Touch Control)

Function	Action
Play/Pause	Single tap on either earbud
Next Track	Double tap on right earbud
Previous Track	Double tap on left earbud
Volume Up	Triple tap on right earbud
Volume Down	Triple tap on left earbud
Activate Voice Assistant	Long press (2 seconds) on either earbud

Making and Receiving Calls

The EarFun Free 2S earbuds are equipped with 4 microphones for clear hands-free calling, minimizing background noise.

Function	Action
Answer/End Call	Single tap on either earbud
Reject Call	Long press (2 seconds) on either earbud



4 Mics ENC for Clear Call

The 4-mic ENC effectively filters environmental noise ensures crystal call



Image: A person using the EarFun Free 2S earbuds for a phone call, with visual representations of voice clarity and noise reduction, highlighting the 4-mic ENC technology.

CHARGING

The earbuds offer up to 7 hours of playtime on a single charge, with a total of 30 hours using the charging case. A quick 10-minute charge provides 2 hours of listening.

Charging the Earbuds and Case

- **USB-C Charging:** Connect the provided USB-C cable to the charging case and a power source.
- **Wireless Charging:** Place the charging case on a compatible wireless charging pad.

Long Battery Life, All Day Playtime



30H
With Charging Case



7H
Single Charge



Fast Charge

Image: The EarFun Free 2S charging case with earbuds inside, placed on a wireless charging pad, illustrating both wireless and USB-C charging options and battery life.

MAINTENANCE

To ensure the longevity and optimal performance of your EarFun Free 2S earbuds, follow these maintenance guidelines:

- **Cleaning:** Regularly clean the earbuds and charging contacts with a soft, dry, lint-free cloth. Remove eartips and clean them with mild soap and water, then dry thoroughly before reattaching.
- **Storage:** Store the earbuds in their charging case when not in use to protect them from dust and damage.
- **Water Resistance:** The earbuds are IPX7 waterproof, meaning they can withstand submersion in up to 1 meter of water for 30 minutes. This protects them from rain and sweat. However, avoid prolonged exposure to water and do

not use them for swimming. Ensure they are dry before placing them back in the charging case.

- **Temperature:** Avoid exposing the earbuds to extreme temperatures (hot or cold) as this can affect battery life and performance.



Image: A close-up of an EarFun Free 2S earbud with water droplets on its surface, emphasizing its IPX7 waterproof rating and resistance to splashes and sweat.

TROUBLESHOOTING

If you encounter any issues with your EarFun Free 2S earbuds, refer to the following common solutions:

- **Earbuds not pairing/connecting:**
 - Ensure Bluetooth is enabled on your device and the earbuds are in pairing mode.
 - Place earbuds back in the case, close it, wait a few seconds, then open it again.
 - Forget "EarFun Free 2S" from your device's Bluetooth list and try pairing again.
 - Ensure earbuds and case have sufficient charge.

- **No sound from one earbud:**

- Place both earbuds back in the charging case, close the lid, and then take them out again.
- Check if both earbuds are charged.
- Perform a factory reset (refer to the full user manual PDF for specific steps if needed).

- **Charging issues:**

- Ensure the USB-C cable is securely connected to both the case and the power source.
- Try a different USB-C cable or power adapter.
- If using wireless charging, ensure the case is properly aligned on the charging pad.
- Clean the charging contacts on both the earbuds and the case.

- **Poor call quality:**

- Ensure the microphones are not obstructed.
- Try moving to a quieter environment.
- Ensure the earbuds are securely fitted in your ears.

SPECIFICATIONS

Feature	Detail
Model Name	EarFun Free 2S
Connectivity Technology	Wireless (Bluetooth 5.2)
Audio Driver Size	7 Millimeters (Dynamic Driver)
Frequency Response	20Hz-20kHz
Sensitivity	100 dB
Impedance	32 Ohm
Battery Life (Single Charge)	7 Hours
Total Playtime (with Case)	30 Hours
Charging Time (Quick Charge)	10 minutes for 2 hours playtime
Water Resistance Level	IPX7 Waterproof
Microphones	4 (for Clear Call)
Control Type	Touch Control
Item Weight	0.14 Ounces (per earbud)

WARRANTY AND SUPPORT

EarFun provides a warranty for its products. For specific warranty terms and conditions, please refer to the official EarFun website or the documentation included with your purchase.


For further assistance, technical support, or warranty claims, please contact EarFun customer service. You can also refer to the comprehensive [User Manual \(PDF\)](#) for detailed instructions and information.

Manufacturer: EarFun

Seller: EarFun US

© 2024 EarFun. All rights reserved.


Documents - EarFun – EarFun Free 2S



[\[pdf\]](#) User Manual Diagram

EarFun TW101S V4 20221122 EarFun Free 2S original media s bol NRB7G9RyGXGL ||| EarFun Free 2S English 01 Deutsch 09 Espaol 17 25 EarFun Audio App Download the EarFun Audio app for an enhanced experience. Equalizer tuning, custom controls Firmware update, earbuds battery status Less data tracking, personalized device name Built-in feedback, and more 2 How to Fi...

lang:en score:50 filesize: 10.41 M page_count: 37 document date: 2023-11-23



[\[pdf\]](#) Frequently Asked Questions

FAQ Amazon EarFun Free 2S Wireless Earbuds Upgraded Version Qualcomm® CVC™ 8 0 ENC Bluetooth 5 2 Sweatshield™ IPX7 Waterproof Headphone aptX™ Deep Bass APP Game Mode Electronics 61qGLJvG7mL m media amazon images I ||| FAQ Table of Contents BLUETOOTH..... R SERVICE TEAM..... 4 BLUETOOTH How do I reset EarFun Free 2S 1. Unpair EarFun Free 2S from your Bluetooth- enabled device and delete the old conn...


lang:en score:40 filesize: 122.99 K page_count: 5 document date: 2022-10-31



[\[pdf\]](#) User Manual

~ai 91d3d7e1 b138 476d 8d18 add0925901ae User Manual EarFun Free 2S Wireless Earbuds Upgraded Version Bluetooth with Deep Bass 4 Mics for Clear Call Customizable EQ App IPX7 Waterproof in Ear Headphones 30H Playtime Charging Electronics B1H7KFk4PoL m media amazon images I |||

... lang:en score:18 filesize: 3.62 M page_count: 44 document date: 2023-11-16



[pdf] User Manual

~ai 8251b02c bd9b 4336 afd3 671398792f7a User Manual Amazon EarFun Free 2S Wireless Earbuds Upgraded Version Qualcomm® CVC™ 8 0 ENC Bluetooth 5 2 Sweatshield™ IPX7 Waterproof Headphone aptX™ Deep Bass APP Game Mode Electronics B1RY mWSG8L m media amazon images I

|||

...

lang:en score:17 filesize: 3.44 M page_count: 37 document date: 2023-09-21



[pdf]

Untitled iOS Gadget Gate PHILE WEB vgp2023 magazine vgp phileweb iFi audio
NEO NEO Stream 1 2 2022 12 06 — JBL TUNE

FLEX JBL TUNE 510BT Reference |||

LZ2000 4KEL PANASONIC LZ2000 OPEN SPEC BS 4K110CS 4K23BS110CS 3 EL
3,8402,160 HDMI4 170W77 ... 20T Bluetooth 56.5 AVIOT TE-D01gs JBL WAVE
100TWS GLIDIC TW-3000 Bluetooth 5 EARFUN EarFun Free 2S AG PITA JVC HA-
A5T HUAWEI HUAWEI Freebuds SE SOUL S-LIVE 30 SOUL S-MIC...

lang:sw score:15 filesize: 5.49 M page_count: 48 document date: 0000-00-00