

FOSSIBOT F101P

# FOSSiBOT F101P Rugged Smartphone User Manual

Model: F101P | Brand: FOSSIBOT

## 1. PRODUCT OVERVIEW

The FOSSiBOT F101P is a rugged smartphone designed for durability and performance in challenging environments. It features a robust build, a large battery, and enhanced audio capabilities.



Figure 1: FOSSiBOT F101P Rugged Smartphone. This image displays the front and back of the FOSSiBOT F101P, highlighting its rugged design and the large speaker on the rear.

## 2. PACKAGE CONTENTS

Verify that all items are present in the package:

- FOSSiBOT F101P Smartphone
- Charging Cable
- Power Adapter
- SIM Ejector Tool
- User Manual (this document)

## 3. DEVICE LAYOUT

Familiarize yourself with the physical components of your FOSSiBOT F101P.

# 5.45" FHD+ Large & Tough Display

**5.45 FHD+**  
Display

**720\*1400**  
Resolution

**18:9**  
Aspect Ratio

**400 nits**  
Brightness



Figure 2: Side view of the FOSSiBOT F101P, illustrating the placement of buttons and ports.

- **Power Button:** Located on the right side. Press and hold to power on/off or restart.
- **Volume Buttons:** Located on the right side, above the power button. Use to adjust media volume and call volume.
- **Customizable Button:** Located on the left side. Can be configured for quick access to specific functions or apps.
- **SIM/TF Card Slot:** Located on the left side. Insert SIM cards and microSD card here.
- **USB-C Port:** Located at the bottom. Used for charging and data transfer.
- **3.5mm Audio Jack:** Located at the top. For connecting headphones.
- **Rear Camera Module:** Includes main camera, macro camera, and LED flash.
- **Front Camera:** Located at the top of the display.
- **Loudspeaker:** Prominently featured on the rear for high-volume audio output.

## 4. SETUP

### 4.1. Inserting SIM and MicroSD Cards

1. Locate the SIM/TF card slot on the left side of the device.



2. Use the provided SIM ejector tool to open the tray.
3. Carefully place your Nano-SIM card(s) and/or microSD card into the designated slots on the tray. Ensure correct orientation.
4. Gently push the tray back into the slot until it is flush with the phone's body.

#### 4.2. Charging the Battery

Before first use, fully charge the device. The FOSSiBOT F101P features a 10600mAh battery with 18W fast charging support.

1. Connect the USB-C cable to the phone's charging port at the bottom.
2. Connect the other end of the cable to the power adapter.
3. Plug the power adapter into a wall outlet.
4. The charging indicator on the screen will show the charging status.



Figure 3: The FOSSiBOT F101P connected to its 18W fast charger, illustrating the charging process.

#### 4.3. Powering On/Off

- To power on: Press and hold the Power button until the FOSSiBOT logo appears.
- To power off: Press and hold the Power button, then select "Power off" from the options.
- To restart: Press and hold the Power button, then select "Restart" from the options.

## 5. OPERATING INSTRUCTIONS

---

### 5.1. Basic Navigation (Android 13)

The FOSSiBOT F101P runs on Android 13, offering an intuitive user interface.

- **Home Screen:** Swipe left or right to access different home screens.
- **App Drawer:** Swipe up from the bottom of the screen to view all installed applications.
- **Notifications Panel:** Swipe down from the top of the screen to access notifications and quick settings.
- **Gestures:** Android 13 supports gesture navigation. You can configure these in *Settings > System > Gestures*.



Figure 4: Screenshots of the Android 13 operating system interface, demonstrating its features like improved security and personalization.

### 5.2. Making Calls and Sending Messages

- **Calls:** Tap the Phone icon, enter the number, and tap the call button.
- **Messages:** Tap the Messages icon, tap "Start chat," enter the recipient's number or select from contacts, and type your message.

### 5.3. Camera Functions

The FOSSiBOT F101P is equipped with a 24MP main camera, 8MP front camera, and a 5MP macro camera.

1. Open the Camera app.
2. Select your desired mode (e.g., Photo, Video, Macro, Portrait, Beauty).
3. Tap the shutter button to capture an image or start/stop video recording.
4. Use the zoom function by pinching the screen or using the volume buttons.

## Intelligent AI image processing



Figure 5: The FOSSiBOT F101P camera interface, showing options for macro photography and other modes.

### 5.4. Loudspeaker Operation

The device features a 123dB loudspeaker for clear and powerful audio output.

- Adjust volume using the physical volume buttons on the side.
- Ensure the speaker is not obstructed for optimal sound quality.



# 123dB Maximum Volume

Waterproof 123dB speaker for impressive sound anywhere.



Figure 6: Diagram illustrating the FOSSiBOT F101P's 123dB loudspeaker, emphasizing its sound output capabilities.

## 5.5. OTG Reverse Charging

The FOSSiBOT F101P can act as a power bank to charge other devices.

1. Connect the charging cable to the FOSSiBOT F101P's USB-C port.
2. Connect the other end of the cable to the device you wish to charge.
3. Ensure the FOSSiBOT F101P has sufficient battery charge.




Figure 7: The FOSSiBOT F101P demonstrating its OTG reverse charging capability by charging another smartphone.

## 6. RUGGED FEATURES AND MAINTENANCE

The FOSSiBOT F101P is designed to withstand harsh conditions. It is IP68/IP69K rated for water and dust resistance, and MIL-STD-810G compliant for drop resistance.

### 6.1. Water and Dust Resistance

- The device can be submerged in water up to 1.5 meters for 30 minutes.
- It is protected against dust ingress.
- Ensure all port covers are securely closed before exposing the device to water or dust.
- After exposure to water, dry the device thoroughly before charging or opening any ports.





Figure 8: The FOSSiBOT F101P shown partially submerged in water, demonstrating its IP68 waterproof rating.

## 6.2. Drop Resistance

- The F101P can withstand drops from up to 1.5 meters.
- While rugged, avoid intentional drops or impacts to prolong the device's lifespan.



Figure 9: The FOSSiBOT F101P shown in a drop scenario, highlighting its drop-resistant design.

### 6.3. Cleaning and Care

- Clean the device with a soft, damp cloth. Avoid harsh chemicals.
- Regularly check and clean the charging port and headphone jack to prevent debris buildup.
- Ensure the speaker grille is free from obstructions for optimal sound.

## 7. TROUBLESHOOTING

### 7.1. Device Not Powering On

- Ensure the battery is charged. Connect to a charger for at least 15 minutes.
- Press and hold the Power button for 10-15 seconds to force a restart.

### 7.2. Poor Call Quality or No Signal

- Check if the SIM card is correctly inserted.
- Ensure you are in an area with network coverage.
- Restart the device.
- Go to *Settings > Network & internet > Mobile network* and check network settings.



### 7.3. Speaker Volume Issues

- Ensure the volume is turned up using the volume buttons.
- Check if the speaker grille is clean and free from obstructions.
- Test audio with different applications.

### 7.4. Charging Problems

- Verify the charging cable and adapter are working correctly. Try a different cable/adapter if available.
- Ensure the USB-C port is clean and free of debris.
- Check if the cable is fully inserted into both the phone and the adapter.

## 8. SPECIFICATIONS

Key technical specifications for the FOSSiBOT F101P:

Feature	Specification
Model Name	F101P
Operating System	Android 13.0
CPU Model	MediaTek Helio P22 Octa-core (2.0 GHz)
RAM	4GB (expandable to 7GB virtual memory)
Internal Storage (ROM)	64GB (expandable up to 512GB via microSD)
Screen Size	5.45 Inches FHD+
Resolution	720 x 1440
Battery Capacity	10600 mAh
Charging	18W Fast Charging, OTG Reverse Charging
Rear Camera	24MP Main + 5MP Macro + 0.3MP Bokeh
Front Camera	8MP
Ruggedness	IP68/IP69K Waterproof & Dustproof, MIL-STD-810G Drop-resistant (1.5m)
Loudspeaker	123dB Volume Fidelity Waterproof Speaker
Dimensions	3 x 0.8 x 6.13 inches
Weight	12.3 ounces (350 grams)



Figure 10: Visual representation of the FOSSiBOT F101P's internal components, including the MediaTek Helio P22 processor and memory configuration.

## 9. WARRANTY AND SUPPORT

FOSSiBOT provides comprehensive customer support for the F101P smartphone.

- **Warranty:** A 2-year long-term warranty is offered.
- **Returns:** A 30-day free return guarantee is available.
- **Customer Service:** Year-round customer support and 24-hour online customer service are provided.
- For warranty claims or technical assistance, please contact FOSSiBOT customer service directly.

## 10. OFFICIAL PRODUCT VIDEOS

Watch these official videos for more information on the FOSSiBOT F101P's features and durability.

### FOSSiBOT F101 10600mAh Rugged Smartphone Overview

Your browser does not support the video tag.

Video 1: This video provides a general overview of the FOSSiBOT F101 rugged smartphone, showcasing its design and key features, including its durability and large battery capacity.













### FOSSiBOT F101 10600mAh Rugged Unlocked Phone Features



Your browser does not support the video tag.

Video 2: This video highlights specific features of the FOSSiBOT F101, such as its ruggedness, unlocked status, and the 10600mAh battery, demonstrating its suitability for various demanding uses.

## Related Documents - F101P



    	<p><a href="#">FOSSiBOT F110L Rugged Smartphone User Manual</a></p> <p>Comprehensive user manual for the FOSSiBOT F110L rugged smartphone, detailing device features, specifications, safety guidelines, care instructions, warranty, and FCC compliance information.</p>
    	<p><a href="#">FOSSiBOT F101 Pro User Manual: Features, Specifications, and Care Guide</a></p> <p>Comprehensive user manual for the FOSSiBOT F101 Pro rugged smartphone, detailing its features, specifications, device overview, accessories, battery information, care instructions, warranty, and FCC compliance.</p>
    	<p><a href="#">FOSSiBOT F106 Pro User Manual - Rugged Smartphone Specifications and Guide</a></p> <p>Comprehensive user manual for the FOSSiBOT F106 Pro rugged smartphone. Includes specifications, features, safety guidelines, care instructions, and warranty information.</p>
    	<p><a href="#">Fossibot F114 User Manual</a></p> <p>User manual for the Fossibot F114 smartphone, covering its features, specifications, safety precautions, and warranty information.</p>

<div></div> <div><div><div>S3 Pro</div><div>User Manual</div></div></div> <div><a href="http://www.fossilbot.com">www.fossilbot.com</a></div>	<div><a href="#">FOSSiBOT S3 Pro User Manual and Specifications</a></div> <div>User manual and technical specifications for the FOSSiBOT S3 Pro smartphone, covering features, safety precautions, and warranty information.</div>
<div></div> <div><div><div>S2</div><div>User Manual</div></div></div> <div><a href="http://www.fossilbot.com">www.fossilbot.com</a></div>	<div><a href="#">Fossilbot S2 User Manual: Features, Specifications, and Care</a></div> <div>Comprehensive user manual for the Fossilbot S2 smartphone, detailing its features, specifications, battery information, care instructions, and warranty. Learn about the device's display, processor, cameras, connectivity, and more.</div>