Hatteker HT-609

Hatteker 8-in-1 Multi-Functional Grooming Kit User Manual

Model: HT-609 | Brand: Hatteker

Introduction

This user manual provides detailed instructions for the safe and effective operation and maintenance of your Hatteker 8-in-1 Multi-Functional Grooming Kit. This versatile cordless grooming kit is designed for comprehensive personal care, including beard trimming, hair clipping, nose and ear hair removal, and body grooming.



Figure 1: Hatteker 8-in-1 Multi-Functional Grooming Kit

What's Included

Your Hatteker Grooming Kit includes the following components:

- T-blade trimmer (main unit)
- Hair clipper head
- Precision trimmer head
- Razor shaver head
- Beard trimmer head
- Nose ear trimmer head
- Body groomer head
- 4 T-blade guide combs (1mm, 3mm, 5mm, 7mm)
- 5 Hair clipper guide combs (3mm, 6mm, 9mm, 12mm, 15mm)
- Adjustable beard trimmer guide comb (1-10mm)
- Adjustable body trimmer comb (3-6-9mm)
- Charging cable (USB)
- Cleaning brush

- Storage base
- Comb
- Lubricating oil



Figure 2: Overview of the 8-in-1 grooming kit components



Figure 3: Hatteker grooming kit with all accessories laid out

Safety Information

For your safety, please read and understand all instructions before using this product.

- Do not submerge the main unit in water. While attachments are washable, the main unit should not be fully immersed.
- Keep away from face and eyes during operation, especially when using the nose/ear trimmer.
- Ensure the device is fully charged before first use.
- Do not use if blades are damaged or bent.
- Keep out of reach of children.

Setup and Charging

Initial Charge

Before first use, fully charge the trimmer for approximately 1.5 hours. A full charge provides up to 180 minutes of operating time.



Figure 4: USB Fast Charging for the trimmer

Video 1: Official product video demonstrating charging and battery display.

Attaching/Detaching Heads

To attach a grooming head, align the head with the main unit and gently push until it clicks into place. To detach, firmly pull the head away from the main unit.



Figure 5: Detachable attachments for versatile grooming

Operating Instructions

General Operation

Press the power button to turn the trimmer on or off. The LED display will show the battery percentage.

Beard Trimming

Use the T-blade trimmer for precise lines and detailing. Attach the appropriate guide comb (1mm, 3mm, 5mm, 7mm) for desired beard length. For a closer trim (0.3mm), use the T-blade without a guide comb.



Figure 6: Zero Gapped Oil Head Design for precise trimming

Hair Clipping

Select the hair clipper head and attach one of the five guide combs (3mm, 6mm, 9mm, 12mm, 15mm) for various hair lengths.



Figure 7: Multiple guide combs for hair cutting



Figure 8: Overview of 9 premium guide combs for various lengths

Nose & Ear Trimming

Attach the nose ear trimmer head. Gently insert the trimmer into the nostril or ear canal and move in a circular motion to trim unwanted hair.

Body Grooming

Use the body groomer head with the adjustable comb (3-6-9mm) for body hair trimming. The razor

shaver head can be used for a smooth finish on various body areas.



Figure 9: Quick-adjust dial and adjustable body trimmer comb




Figure 10: Visual guide to various grooming head applications

Maintenance and Cleaning

Cleaning the Blades

The trimmer heads and guide combs are fully washable (IPX7 waterproof). After each use, detach the head and use the included cleaning brush to remove any hair debris. Rinse the detached head under running water.



Figure 11: Waterproof design allows for easy cleaning under running water

Video 2: Official product video demonstrating rinsing the trimmer head under water for cleaning.

Oiling the Blades

For optimal performance and longevity, regularly apply a few drops of the included lubricating oil to the blades after cleaning. Turn the trimmer on for a few seconds to distribute the oil.

Storage

After cleaning and oiling, ensure all attachments are dry. Store the trimmer and its accessories in the provided storage base to dry naturally and keep them organized.

Product Specifications

Feature	Detail

Model Number	HT-609
Power Source	Rechargeable Lithium-Ion Battery
Charging Time	1.5 Hours
Operating Time	Up to 180 minutes (3 hours)
Waterproof Rating	IPX7 (washable heads)
Blade Material	Self-sharpening steel
Dimensions	8.39 x 5.91 x 2.36 inches
Weight	1.32 Pounds
Manufacturer	Hatteker
Country of Origin	China

Troubleshooting

Trimmer Not Turning On

Ensure the trimmer is fully charged. Check the LED display for battery level.

Poor Trimming Performance

Clean the blades and remove any trapped hair. Apply lubricating oil to the blades. Ensure the correct attachment and guide comb are securely fitted.

Device Overheating

If the device feels excessively warm, turn it off and allow it to cool down before resuming use. Ensure proper ventilation during charging.

Warranty and Support

For warranty information and customer support, please refer to the product packaging or contact Hatteker customer service directly. Keep your purchase receipt for warranty claims.