

SGIN T10P

SGIN T10P 10-Inch Android 12 Tablet User Manual

Model: T10P

1. INTRODUCTION

This manual provides essential information for the proper use and maintenance of your SGIN T10P 10-inch Android 12 Tablet. Please read it thoroughly before operating your device to ensure optimal performance and longevity. The SGIN T10P is designed for a versatile user experience, featuring an Android 12 operating system, an MTK Octa-Core processor, 8GB RAM, 128GB internal storage, and a 10.1-inch HD IPS display.



Image 1.1: Front and back view of the SGIN T10P Tablet, highlighting its 10.1-inch screen, Android 12 OS, 8GB RAM, and 128GB storage.

2. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x SGIN T10P Tablet
- 1 x User Manual (this document)
- 1 x USB Type-C Cable
- 1 x Power Charger

3. DEVICE OVERVIEW

Familiarize yourself with the physical components of your SGIN T10P tablet.



Image 3.1: Diagram illustrating the location of buttons, ports, and cameras on the SGIN T10P Tablet.

3.1. Buttons and Ports

- **Power Button:** Used to power on/off the tablet or wake/sleep the screen.
- **Volume Buttons:** Adjust the audio volume.
- **Headphone Jack (3.5mm):** Connect external audio devices.
- **USB Type-C Port:** For charging the tablet and connecting to a computer for data transfer.
- **Micro TF Card Slot:** Insert a Micro SD card for expandable storage (up to 256GB).
- **Microphone:** For audio input during calls or recordings.
- **Stereo Speakers:** Provide audio output.

3.2. Cameras

- **Front Camera (5MP):** Located on the front bezel, suitable for video calls and selfies.
- **Rear Camera (8MP with Flash Light):** Located on the back, for capturing photos and videos.

4. SETUP

4.1. Charging the Tablet

1. Connect the USB Type-C cable to the tablet's Type-C port.
2. Connect the other end of the USB Type-C cable to the included power charger.
3. Plug the power charger into a wall outlet.
4. Allow the tablet to charge fully before first use. The battery indicator on the screen will show charging status.

The tablet is equipped with a 6000mAh battery, providing approximately 5-7 hours of usage depending on the scenario.

6000MAH Long-life Battery



8 Hours
Video



12 Hours
Music



10 Hours
Browsing



480 Hours
Standby



Image 4.1: Visual representation of the 6000mAh battery capacity and estimated usage times for video, music, browsing, and standby.

4.2. Powering On/Off

- **To Power On:** Press and hold the Power button until the SGIN logo appears on the screen.
- **To Power Off:** Press and hold the Power button until a power-off menu appears. Select "Power off" and confirm.
- **To Sleep/Wake:** Briefly press the Power button to put the tablet to sleep or wake it up.

4.3. Initial Setup

Upon first power-on, follow the on-screen prompts to configure your tablet:

1. Select your preferred language.
2. Connect to a Wi-Fi network.
3. Review and accept the terms and conditions.
4. Sign in with your Google account or create a new one. This is necessary to download apps from the Google Play Store.
5. Set up screen lock (PIN, pattern, or password) for security.

4.4. Connecting to Wi-Fi

Your SGIN T10P supports dual-band Wi-Fi (2.4G/5G) for stable internet connectivity.

1. Go to **Settings > Network & internet > Wi-Fi**.
2. Toggle Wi-Fi **On**.
3. Select your desired Wi-Fi network from the list.
4. Enter the network password if prompted and tap **Connect**.

5. OPERATING YOUR TABLET

5.1. Basic Navigation

The SGIN T10P uses a touchscreen interface. Common gestures include:

- **Tap:** Select an item or open an application.
- **Tap & Hold:** Access contextual menus or move icons.
- **Swipe:** Scroll through lists or switch between screens.
- **Pinch:** Zoom in or out on images and web pages.

5.2. Applications

Your tablet comes with pre-installed Android 12 OS and Google Mobile Services, allowing access to a wide range of applications.

Pre installed Android 12 operating system



Android 12
Protect Your Privacy



Privacy
Security& Device Controls



Image 5.1: The SGIN T10P Tablet showcasing the Android 12 operating system and various popular applications.

- **Installing Apps:** Open the Google Play Store app, search for your desired application, and tap **Install**.
- **Uninstalling Apps:** Tap and hold an app icon on the home screen or app drawer, then drag it to the **Uninstall** option, or go to **Settings > Apps > select the app > Uninstall**.

5.3. Storage Management

The tablet includes 128GB of internal storage. You can expand this by up to 256GB using a Micro TF (SD) card.

Store ALL Your Favorite

8GB RAM with 128GB ROM + 256GB Expand Memory



Image 5.2: Illustration of the tablet's 8GB RAM and 128GB ROM, with support for 256GB expandable memory, suitable for storing videos, music, and photos.

- **Inserting a TF Card:** Carefully insert the Micro TF card into the designated slot until it clicks into place.
- **Managing Storage:** Go to **Settings > Storage** to view usage and manage files.

5.4. Camera Usage

Capture moments with the tablet's 5MP front camera and 8MP rear camera.

Capture Every Moment in Your Life

5MP Front camera + 8MP Rear camera



Image 5.3: Depiction of the 5MP front camera and 8MP rear camera, illustrating their use for capturing photos and videos.

- Open the **Camera** app.
- Tap the shutter button to take a photo.
- Switch between front and rear cameras using the camera toggle icon.
- Select video mode to record videos.

5.5. Bluetooth Connectivity

Connect wireless accessories like headphones or speakers using Bluetooth 5.0.

1. Go to **Settings > Connected devices > Bluetooth**.
2. Toggle Bluetooth **On**.
3. Ensure your Bluetooth device is in pairing mode.
4. Select your device from the list of available devices and follow any on-screen pairing instructions.

6. MAINTENANCE

6.1. Battery Care

- Avoid fully discharging the battery frequently.
- Do not expose the tablet to extreme temperatures.
- Use only the provided charger and USB Type-C cable.

6.2. Cleaning

- Use a soft, lint-free cloth to clean the screen and body.
- For stubborn marks, slightly dampen the cloth with water or a screen cleaner.
- Avoid using harsh chemicals or abrasive materials.

7. TROUBLESHOOTING

If you encounter issues with your SGIN T10P tablet, refer to the following common solutions:

Problem	Solution
Tablet does not power on	Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on again. If unresponsive, press and hold the power button for 10-15 seconds to force a restart.
Wi-Fi connection issues	Check if Wi-Fi is enabled in Settings. Restart your Wi-Fi router. Forget the network and reconnect. Ensure you are within range of the Wi-Fi signal.
Apps are slow or crashing	Close unused applications. Clear app cache in Settings > Apps. Restart the tablet. Ensure sufficient storage space is available.
Screen is unresponsive	Restart the tablet by holding the power button. Ensure the screen is clean and free of debris.
Tablet not charging	Verify the USB Type-C cable and charger are securely connected and undamaged. Try a different power outlet.

8. SPECIFICATIONS

Detailed technical specifications for the SGIN T10P Tablet:

Feature	Detail
Model Name	T10P
Operating System	Android 12
Screen Size	10.1 Inches
Screen Resolution	1280x800 Pixels (HD IPS)
Processor	MTK Octa-Core, 2 GHz
RAM	8 GB DDR4 SDRAM

Feature	Detail
Internal Storage	128 GB
Expandable Storage	Micro TF slot, up to 256 GB
Front Camera	5 MP
Rear Camera	8 MP (with flash light)
Wireless Type	802.11abg (Dual-band Wi-Fi 2.4G/5G)
Bluetooth	Bluetooth 5.0
Battery	6000mAh Lithium Ion
Average Battery Life	6-7 Hours (usage dependent)
Ports	USB Type-C, 3.5mm Headphone Jack, Micro TF Slot
Item Weight	2.23 pounds (approximately 1.01 kg)
Product Dimensions	10.1 x 6 x 0.4 inches (approximately 25.65 x 15.24 x 1.02 cm)
Color	Black

9. WARRANTY AND SUPPORT

SGIN provides a 1-year maintenance period from the date of purchase for this product.

If you encounter any issues or have questions regarding your SGIN T10P tablet, please contact SGIN customer support. Refer to the contact information provided with your purchase documentation or visit the official SGIN website for assistance.

