

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Volkano](#) /
- › [Volkano VK-20194-BK Focus Series Wireless Mouse User Manual](#)

## Volkano VK-20194-BK

# Volkano VK-20194-BK Focus Series Wireless Mouse User Manual

Model: VK-20194-BK

## INTRODUCTION

---

This manual provides instructions for the proper setup, operation, and maintenance of your Volkano VK-20194-BK Focus Series Wireless Mouse. Please read this guide thoroughly before using the device to ensure optimal performance and longevity.

The Volkano Focus Series Wireless Mouse offers reliable 2.4GHz wireless connectivity, a precision optical sensor for smooth cursor control, and an ergonomic design for comfortable use.

## PACKAGE CONTENTS

---

- Volkano VK-20194-BK Focus Series Wireless Mouse
- USB Receiver
- User Manual

## SETUP

---

### 1. Battery Installation

The Volkano VK-20194-BK mouse requires one AA battery (not included) for operation. Locate the battery compartment on the underside of the mouse. Open the cover, insert the AA battery according to the polarity indicators (+/-), and close the cover securely.



Image: Underside view of the mouse, indicating the battery compartment location.

## 2. Connecting the USB Receiver

Locate the USB receiver, typically stored within the battery compartment or a dedicated slot on the mouse. Remove the receiver and plug it into an available USB port on your computer (PC, Laptop, Mac, Chromebook, etc.).



Image: Front view of the mouse, illustrating its design and the small size of a typical USB receiver.

### 3. Powering On

Once the battery is installed and the USB receiver is connected, turn on the mouse using the power switch, usually located on the underside of the device. The mouse is plug-and-play, meaning it should connect automatically without requiring driver installation.

## OPERATING INSTRUCTIONS

---

### Basic Functions

- **Left Click:** Primary button for selecting items, opening files, and interacting with software.
- **Right Click:** Secondary button for accessing context menus and additional options.
- **Scroll Wheel:** Used for scrolling through documents and web pages. It can also function as a middle click button.



Image: Side view of the mouse, highlighting its ergonomic shape for comfortable grip.

### Ergonomics

The Volcano Focus Series mouse is designed with an ergonomic shape to reduce strain during extended use, providing a comfortable grip for both left and right-handed users.

## MAINTENANCE

---

### Cleaning

To clean your mouse, gently wipe the surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish. Ensure no liquid enters the internal components.

### Battery Replacement

When the mouse performance degrades or it stops responding, it is likely time to replace the battery. Follow the battery installation steps outlined in the Setup section.

### Storage

When not in use for extended periods, turn off the mouse to conserve battery life. Store the USB receiver in

its designated slot on the mouse to prevent loss.

## TROUBLESHOOTING

---

- **Mouse Not Responding:**

- Check if the mouse is powered on.
- Ensure the battery is correctly installed and has sufficient charge. Replace if necessary.
- Verify the USB receiver is securely plugged into a working USB port on your computer. Try a different USB port.
- Restart your computer.

- **Erratic Cursor Movement:**

- Clean the optical sensor on the underside of the mouse with a soft, dry cloth.
- Ensure you are using the mouse on a suitable surface. Avoid highly reflective or transparent surfaces.
- Check for interference from other wireless devices.

- **Connection Issues:**

- Move the mouse closer to the USB receiver.
- Unplug and re-plug the USB receiver.
- If possible, try the mouse with another computer to determine if the issue is with the mouse or the computer.

## SPECIFICATIONS

---

Feature	Detail
Brand	Volkano
Model Name	Focus Series
Model Number	VK-20194-BK
Colour	Black
Connectivity Technology	2.4GHz Wireless (USB Receiver)
Special Feature	Wireless
Movement Detection	Optical Sensor
Number of Buttons	3
Recommended Use	Office
Compatible Devices	Personal Computer, PC, Laptop, Tablet, Mac, iPad, Chromebook, Notebook
Operating System	Windows, Linux

## WARRANTY AND SUPPORT

---

Volkano products are designed and manufactured to the highest quality standards. For information regarding warranty, returns, or technical support, please refer to the warranty card included with your product or visit the official Volkano website. You may also contact your retailer for assistance. For further assistance, you can visit the [Volkano Store on Amazon](#).