CELLECOR CB-44 TWS

CELLECOR BROPODS CB44 TWS Earbuds User Manual

Model: CB-44 TWS

Introduction

This manual provides comprehensive instructions for the CELLECOR BROPODS CB44 True Wireless Stereo (TWS) in-ear earbuds. It covers essential information regarding setup, operation, maintenance, and troubleshooting to ensure you get the best experience from your device. Please read this manual carefully before using the product.

What's in the Box



Image: CELLECOR BROPODS CB44 TWS Earbuds and Charging Case. This image displays the white earbuds and their compact charging case.

- 1 Pair of TWS Earbuds
- 1 Wireless Charging Case
- 1 Type-C Charging Cable
- 1 Warranty Card

Product Features

- **Extended Playtime:** Up to 35 hours of total playtime with the charging case.
- **Quick Charge:** 10 minutes of charging provides 120 minutes of playtime via Type-C.
- **Auto-Connect:** Seamless automatic connection to previously paired devices.
- **Water-Resistant:** IPX4 rating for sweat and splash resistance.
- **Bluetooth V5.1:** Stable and efficient wireless connectivity.
- **Dynamic Audio:** 10mm dynamic drivers for rich sound and deep bass.

- **Intuitive Controls:** Integrated touch controls for music, calls, and voice assistant.

Setup

1. Charging the Earbuds and Case




Image: Earbuds in charging case with LED indicator. The image highlights the LED indicator on the charging case, showing its status.

1. Before first use, ensure both the earbuds and the charging case are fully charged.
2. Connect the provided Type-C charging cable to the charging port on the case and to a compatible USB power source.
3. The LED indicator on the charging case will illuminate to show charging status.
4. A full charge for the earbuds takes approximately 60 minutes. The case charges separately.
5. For quick power, a 10-minute charge can provide up to 120 minutes of playtime.

2. Pairing with Your Device



Image: Smartphone screen showing Bluetooth pairing for BroPods CB44. This image illustrates the process of connecting the earbuds via Bluetooth on a mobile device.

1. Open the lid of the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your smartphone, tablet, or other Bluetooth-enabled device, go to the Bluetooth settings.
3. Ensure Bluetooth is enabled.
4. Search for available devices and select **"BroPods CB44"** from the list.
5. Once connected, the earbuds will automatically connect to this device whenever they are removed from the case and Bluetooth is active on your device.

Operating Instructions

Power On/Off

- **Power On:** Open the charging case, and the earbuds will power on automatically.
- **Power Off:** Place the earbuds back into the charging case and close the lid. They will power off automatically.

Touch Controls



Image: Earbud with touch control icons. This image displays the touch-sensitive area on an earbud and icons representing various functions like play, pause, and volume adjustment.

Function	Action
Play/Pause Music	Single tap on either earbud
Next Track	Double tap the **Right** earbud
Previous Track	Double tap the **Left** earbud
Volume Up	Long press the **Right** earbud
Volume Down	Long press the **Left** earbud
Answer/End Call	Single tap on either earbud
Reject Call	Long press on either earbud

Function	Action
Activate Voice Assistant	Triple tap on either earbud

Maintenance

Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, solvents, or harsh chemicals.
- Ensure the charging contacts on both the earbuds and the case are clean and free of debris to maintain proper charging.

Storage

- Always store the earbuds in their charging case when not in use to protect them and keep them charged.
- Store the device in a cool, dry place, away from direct sunlight, extreme temperatures, and humidity.

Water Resistance (IPX4)

- The earbuds are rated IPX4, providing protection against splashing water from any direction.
- They are suitable for workouts and light rain but are**not** designed for swimming, showering, or submersion in water.
- Ensure the earbuds are dry before placing them back into the charging case to prevent damage.

Troubleshooting

If you encounter any issues with your CELLECOR BROPODS CB44, please refer to the following common solutions:

Problem	Possible Solution
Earbuds not pairing	• Ensure earbuds are charged. • Verify Bluetooth is enabled on your device. • Place earbuds back in the case, close the lid, then reopen to re-enter pairing mode. • Forget "BroPods CB44" from your device's Bluetooth list and attempt pairing again.
No sound from earbuds	• Check the volume level on both your device and the earbuds. • Ensure the earbuds are properly connected to your device. • Try restarting your device and re-pairing the earbuds.
Charging issues	• Verify the Type-C charging cable is securely connected to both the case and the power source. • Try using a different Type-C cable and a compatible power adapter. • Clean the charging contacts on the earbuds and inside the charging case.

Problem	Possible Solution
One earbud not working	• Place both earbuds back into the charging case, close the lid, and then take them out again. • Ensure both earbuds are charged. • Try resetting the earbuds (refer to manufacturer's website for specific reset instructions if needed).

Specifications



Image: Exploded view of a 10mm dynamic driver. This image shows the internal components of a 10mm dynamic driver, highlighting its construction.



Image: Earbuds with '35 Hrs Playtime' graphic. This image emphasizes the extended battery life of the earbuds.

Feature	Detail
Brand	CELLECOR
Model Number	CB-44 TWS
Ear Placement	In Ear
Form Factor	True Wireless
Noise Control	Sound Isolation (Environmental Noise Cancellation - ENC)
Bluetooth Version	V5.1
Driver Unit	10mm Dynamic Drivers
Water Resistance Level	IPX4

Feature	Detail
Total Playback Time	Up to 35 hours (with charging case)
Earbud Charging Time	60 Minutes
Connection Distance	10-15 Meters
Frequency Response	20Hz-2KHz
Standby Time	120 Hours
Control Method	Touch
Item Weight	100 Grams
Material	Plastic
Compatible Devices	Cellphones, Laptops, Smart Speakers

Warranty Information

The CELLECOR BROPODS CB44 TWS earbuds are covered by a**6 Months Manufacturer Warranty** from the date of purchase.
This warranty covers manufacturing defects. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.
For warranty claims or to understand the full terms and conditions, please refer to the warranty card included in your product packaging or visit the official CELLECOR website.

Support

For any further assistance, technical support, or inquiries regarding your CELLECOR BROPODS CB44 TWS earbuds, please contact CELLECOR customer service through the following channels:

- **Manufacturer:** Creatons Corporation Private Limited, Plot No.-36, Block-H, Sector-63, Noida, 201301 Uttar Pradesh, India.
- **Importer:** Cellecor Gadgets Limited.
- Please refer to the official CELLECOR website for the most up-to-date contact information and support resources.

© 2024 CELLECOR. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question