

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Ecolab](#) /
- › [Ecolab SmartPower Sanitizer 6101355 User Manual](#)

Ecolab 6101355

Ecolab SmartPower Sanitizer 6101355 User Manual

Model: 6101355

INTRODUCTION

The Ecolab SmartPower Sanitizer is designed for effective sanitization of hard, non-porous food contact surfaces. This product helps prevent the transmission of germs from surfaces such as countertops, stovetops, sinks, dishware, glassware, and silverware. This manual provides instructions for safe and effective use.



Image: Ecolab SmartPower Sanitizer product container, a white and blue container with the product label.

SAFETY INFORMATION

WARNING: Read all instructions and safety data sheets before use. Keep out of reach of children. Avoid contact with eyes, skin, and clothing. In case of contact, rinse immediately with plenty of water and seek medical advice. Do not ingest. Use in a well-ventilated area. Wear appropriate personal protective equipment (PPE) such as gloves and eye protection.

- Always follow dilution instructions precisely.
- Do not mix with other cleaning products or chemicals.
- Store in original container in a cool, dry place away from direct sunlight and incompatible materials.
- Dispose of product and container in accordance with local regulations.

SETUP AND PREPARATION

The Ecolab SmartPower Sanitizer is a solid chemistry product designed for use with an appropriate dispensing system (dispenser not included). Ensure your dispensing system is clean and in good working order before inserting the product.

1. **Inspect Dispenser:** Verify that the sanitizer dispenser is clean and free from obstructions.
2. **Insert Product:** Carefully place the solid SmartPower Sanitizer into the designated compartment of the dispenser according to the dispenser's instructions.
3. **Connect Water:** Ensure the dispenser is properly connected to a potable water supply.
4. **Prime System:** Follow dispenser instructions to prime the system and ensure proper dilution.

OPERATING INSTRUCTIONS

This sanitizer is intended for use on hard, non-porous food contact surfaces. Always pre-clean surfaces before sanitizing.

General Sanitization Procedure:

1. **Pre-clean:** Thoroughly clean surfaces with an appropriate detergent to remove gross food particles and soil. Rinse with potable water.
2. **Apply Sanitizer:** Activate the dispenser to create the sanitizing solution. Apply the solution to the pre-cleaned surface using a cloth, sponge, or spray device, ensuring the entire surface is thoroughly wetted.
3. **Contact Time:** Allow the sanitizer to remain on the surface for the recommended contact time, typically 60 seconds, or as specified by local health regulations and product label.
4. **Air Dry:** Allow surfaces to air dry. No rinsing is required after sanitization unless specified by local regulations or for specific applications.

Specific Applications:

- **Dishware, Glassware, Silverware:** After washing and rinsing, immerse items in the sanitizing solution for the recommended contact time. Allow to air dry.
- **Countertops, Stovetops, Sinks:** Apply solution as described above, ensuring full coverage.

MAINTENANCE

- **Dispenser Cleaning:** Regularly clean and descale the dispensing unit according to the manufacturer's instructions to ensure proper function and dilution.
- **Product Storage:** Store unused product in its original packaging in a cool, dry, well-ventilated area, away from incompatible materials and direct sunlight.
- **Expiration:** Check the product for any expiration dates. Dispose of expired product safely according to local regulations.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Sanitizer not dispensing	Product empty; Dispenser clogged; Water supply off	Replace product; Clean dispenser; Check water connection
Poor sanitization results	Insufficient pre-cleaning; Incorrect dilution; Insufficient contact time	Ensure thorough pre-cleaning; Verify dispenser settings; Increase contact time
Product dissolving too quickly/slowly	Water temperature issues; Dispenser flow rate incorrect	Check water temperature; Adjust dispenser settings as per manufacturer guidelines

SPECIFICATIONS

Brand: Ecolab

Model: 6101355

Item Form: Solid

Scent: Unscented

Package Weight: Approximately 2 lbs. (per unit, 2 units per case)

Package Dimensions: 12 x 7 x 7 inches (for the case)

Specific Uses: Sanitizer for hard, non-porous food contact surfaces

SUPPORT AND WARRANTY

For technical assistance, product inquiries, or information regarding warranty, please contact Ecolab customer support directly. Refer to the product packaging or the official Ecolab website for contact details.

Legal Disclaimer: Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition. *(Note: This disclaimer is provided as part of the product information, though its relevance to a surface sanitizer may vary.)*