

[Manuals.plus](#) /

› [POLICE](#) /

› User Manual for POLICE Stun Gun 8810 & BURN Pepper Spray Combo

POLICE Police Stun Gun 8810 Burn Pepper Spray

User Manual

POLICE STUN GUN 8810 & BURN PEPPER SPRAY COMBO

Introduction

This manual provides essential instructions for the safe and effective use of your POLICE Stun Gun 8810 and BURN Pepper Spray combo. This self-defense kit is designed to offer personal protection. Please read all instructions carefully before use and retain this manual for future reference.





Image: The POLICE Stun Gun 8810 and BURN Pepper Spray, shown together as a complete self-defense kit.

Safety Information

Warning: These devices are intended for self-defense purposes only. Misuse may result in serious injury or legal consequences. Always check local laws and regulations regarding the possession and use of stun guns and pepper spray in your area.

- Keep out of reach of children and unauthorized individuals.
- Do not use on individuals with pacemakers, heart conditions, or pregnant women.
- Do not use in flammable environments.
- Avoid direct contact with eyes or sensitive areas when testing the stun gun.
- Pepper spray should only be used in self-defense situations. Avoid spraying against the wind.
- Store both devices in a cool, dry place away from direct sunlight and extreme temperatures.

Stun Gun: Setup and Operation

Charging the Stun Gun

The POLICE Stun Gun 8810 features an internal USB rechargeable battery. Before first use, fully charge the device for approximately 8-10 hours. Subsequent charges may take less time depending on battery depletion.

1. Locate the charging port on the stun gun.
2. Connect the provided USB charging cable to the stun gun and a standard USB power outlet (e.g., wall adapter, computer USB port).
3. A red indicator light will illuminate during charging. The light may turn off or change color when fully charged (refer to specific model behavior if different).
4. Disconnect the charger once charging is complete.



Image: The POLICE Stun Gun 8810 connected to a wall outlet via its USB charging cable, showing the charging process.

Operating the Flashlight

The stun gun is equipped with a tactical LED flashlight with multiple modes.

1. Locate the power button or switch for the flashlight, typically on the side of the device.
2. Press the button repeatedly to cycle through the light modes: High, Low, and Strobe.
3. The flashlight may also feature an adjustable focus zoom by twisting the head of the flashlight.



Image: The POLICE Stun Gun 8810, highlighting its flashlight end and the side switch for operation.

Activating the Stun Function

The stun gun has a safety switch to prevent accidental discharge.

1. Ensure the safety switch is in the "ON" or "ARMED" position. This switch is usually a sliding button located near the flashlight switch.
2. Once armed, press the dedicated stun activation button (often a separate button or a further push of the main switch).
3. The stun gun will emit a loud crackling sound and visible arc between the electrodes.
4. To use, firmly press the electrodes against an attacker's body. A brief contact (1-2 seconds) is usually sufficient to cause disorientation and muscle spasms.
5. Immediately return the safety switch to the "OFF" or "SAFE" position after use.



Image: A hand holding the POLICE Stun Gun 8810, demonstrating its ergonomic design and grip for effective use.

Pepper Spray: Setup and Operation

Understanding the Safety Lock

The BURN Pepper Spray features a safety twist lock to prevent accidental discharge. This mechanism ensures the spray is only deployed when intentionally activated.

SPECIFICATIONS



Image: Detailed view of the BURN Pepper Spray, illustrating its safety twist lock, keychain clip, and compact 1/2 oz mini can size.

How to Use the Pepper Spray

In a self-defense situation, quick and decisive action is crucial.

1. **Unlock:** Twist the red activator tab to the side (counter-clockwise) until it aligns with the small cut on the back cap, indicating it is unlocked and ready to spray.
2. **Aim:** Point the pepper spray release hole directly towards the assailant's eyes, nose, and mouth.
3. **Spray:** Press down firmly on the red tab, using short bursts. The spray has a long range, allowing you to maintain a safe distance.
4. **Escape:** After deploying, immediately create distance and seek safety.



HOW TO USE:

1. Unlock the red activator by sliding the flat red tab to the right so the red tab aligns with the small cut on the back cap.
2. Point the pepper spray release hole toward the assailant, targetin eyes, nose and mouth.
3. Press down firmly on the red tab, using the short bursts.

Image: Visual instructions on how to unlock and press the activator to deploy the BURN Pepper Spray.

Maintenance

Stun Gun Maintenance

- **Battery Care:** To prolong battery life, avoid fully discharging the stun gun. Recharge it regularly, even if not used frequently (e.g., once every 1-2 months).
- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use abrasive cleaners or immerse in water.
- **Storage:** Store in a cool, dry place away from extreme temperatures and direct sunlight.

Pepper Spray Maintenance

- **Expiration Date:** Check the expiration date printed on the canister. Pepper spray can lose effectiveness over time. Replace it before the expiration date.
- **Storage:** Store in a cool, dry place. Avoid extreme heat or cold, which can affect pressure and effectiveness.
- **Testing:** Do not test fire the pepper spray unless absolutely necessary, as each spray depletes the contents.

Troubleshooting

Stun Gun Issues

Problem	Possible Cause	Solution
Stun gun not activating/no spark	Low battery; Safety switch in "OFF" position; Stun activation button not fully pressed.	Recharge the battery; Ensure safety switch is "ON"; Press the stun activation button firmly.
Flashlight not working	Low battery; Flashlight button not pressed correctly.	Recharge the battery; Press the flashlight button to cycle modes.

Pepper Spray Issues

Problem	Possible Cause	Solution
Pepper spray not deploying	Safety lock engaged; Canister is empty or expired.	Twist the safety lock to the unlocked position; Check expiration date and replace if necessary.

Specifications

POLICE Stun Gun 8810

Feature	Detail
Model Name	Police Stun Gun 8810
Material	Aircraft-grade Aluminum
Power Source	Internal USB Rechargeable Battery
Flashlight	Tactical LED with High, Low, Strobe modes; Adjustable Focus Zoom
Safety Feature	On/Off Safety Switch
Dimensions	Approximately 7.5 inches (length)
Included Accessories	Holster with belt loop, USB charging cable

BURN Pepper Spray

Feature	Detail
Formula	Maximum stopping power, one of the hottest formulas available
Effect Duration	Up to 45 minutes incapacitation
Spray Type	Long-range spray
Container Size	1/2 oz Mini Can
Safety Feature	Safety Twist Lock
Portability	Keychain attachment, belt clip
Dimensions	Approximately 3 inches (height)

Warranty and Support

For warranty information or technical support, please contact the manufacturer directly. Refer to the product packaging or the official POLICE brand website for contact details.

You can also visit the [POLICE Store on Amazon](#) for additional product information and support resources.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

