

VBGK 2 Burner Electric Cooktop

VBGK Electric Cooktop User Manual

Model: 2 Burner Electric Cooktop

Brand: VBGK

1. IMPORTANT SAFETY INSTRUCTIONS

Read all instructions carefully before using the appliance to prevent injury or damage. Keep this manual for future reference.

- **Electrical Safety:** Ensure the cooktop is connected to a 110-120V power supply as specified. Do not use extension cords or adapters.
- **Burn Hazard:** The cooktop surface and cooking zones become hot during use and remain hot for a period after use. Do not touch hot surfaces. Use oven mitts or pot holders.
- **Child Safety:** This appliance is not intended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Keep children away from the cooktop during operation and cooling. Utilize the Child Safety Lock feature.
- **Overheat Protection:** The cooktop is equipped with an overheat protection system. If the temperature becomes excessively high, the unit will automatically shut off.
- **Proper Ventilation:** Ensure adequate ventilation around the cooktop, especially if built-in. Do not block air vents.
- **Cookware:** Use only appropriate cookware. Ensure pots and pans are stable on the cooking zones.
- **Cleaning:** Always disconnect the power supply before cleaning. Allow the cooktop to cool completely before cleaning.

2. PRODUCT OVERVIEW

The VBGK Electric Cooktop is a versatile 2400W appliance designed for efficient cooking. It features two independent heating zones, each with 1200W power, allowing for simultaneous cooking of multiple dishes. The sleek black ceramic glass surface is scratch-resistant and easy to clean.




Image: Top view of the VBGK 2-burner electric cooktop, showing the two radiant heating elements.

Key Features:

- **Dual Heating Zones:** Two independent 1200W burners for simultaneous cooking.
- **Flexible Installation:** Can be used as a countertop appliance or built-in.
- **Touch Knob Control:** Intuitive LED touch knob controls for precise temperature and power adjustments.
- **Multiple Power Levels:** 10 power levels for diverse cooking needs (simmer, deep fry, boil, sear, steam, slow cook, grill).
- **Adjustable Timer:** Integrated timer adjustable from 1 to 120 minutes.
- **Safety Features:** Includes Child Safety Lock, Overheat Protection, Residual Heat Indication, and Auto Shut-off.
- **Universal Cookware Compatibility:** Works with iron, aluminum, ceramic, stainless steel, copper, heat-resistant glass, and other common cookware types.

3. SETUP AND INSTALLATION

The VBGK Electric Cooktop offers flexibility for either countertop placement or built-in installation.

3.1 Countertop Use:

For countertop use, simply place the cooktop on a stable, flat, heat-resistant surface. Ensure there is adequate clearance around the unit for ventilation. The cooktop features non-slip bases for stability.

3.2 Built-in Installation:

If installing as a built-in unit, ensure the cutout dimensions in your countertop match the product specifications. Provide sufficient space below and around the cooktop for proper airflow and heat dissipation. Consult a qualified electrician for electrical connections if you are unsure.



Image: Illustration showing the cooktop placed on a table and a diagram indicating its built-in design with a radiator fan.

3.3 Electrical Connection:

The cooktop operates on 110-120 Volts. Ensure your electrical outlet and circuit can support the 2400W power

requirement. It is recommended to have a dedicated circuit for the appliance.

4. OPERATING INSTRUCTIONS

Familiarize yourself with the controls for optimal use of your VBGK Electric Cooktop.

4.1 Powering On/Off:

- To turn on, press the power button or rotate the knob for the desired burner.
- To turn off, rotate the knob to the minimum setting or press the power button again.

4.2 Adjusting Power/Temperature:

Each burner has an independent LED touch knob control. Rotate the knob to select from 10 power levels, corresponding to a wide temperature range (212-1112°F).

Suitable For All Kinds Of Cookwares



Image: Close-up of the cooktop's touch controls, highlighting the knob and sensor touch functionality for quick and easy use.

4.3 Timer Function:

The integrated timer can be set from 1 minute to 120 minutes. Use the timer function for precise cooking durations. The cooktop will automatically shut off once the set time expires.

4.4 Child Safety Lock:

Activate the Child Safety Lock to prevent accidental operation, especially important in households with children. Refer to the specific instructions in the full manual for activating and deactivating this feature.



Image: Depiction of the child safety lock icon and timer icon on the cooktop, with a family in the background, emphasizing safety.

4.5 Cookware Compatibility:

The VBGK Electric Cooktop is compatible with a wide range of cookware materials, including:

- Iron
- Aluminum
- Ceramics
- Stainless Steel
- Copper

- Heat-resistant Glass
- Barbecue grates
- Casseroles

Ensure the base of the cookware is flat and covers the heating zone adequately for efficient heat transfer.

- 
Knob & Sensor Touch
- 
Child Lock Function
- 
Overheat Protection
- 
9 Power Levels
(2400W High Power)
- 
Easy to Clean
- 
110-220V
- 
0-120 Min Time

Portable Dual Electric Cooktop

Meets All Your Cooking Needs



Image: Visual guide showing various types of cookware (iron, stainless steel, casserole, aluminum, glass, copper, barbecue, ceramics) compatible with the cooktop.

5. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your VBGK Electric Cooktop.

5.1 Daily Cleaning:

- Always ensure the cooktop is cool to the touch before cleaning.
- Wipe the ceramic glass surface with a soft cloth dampened with warm, soapy water.
- For stubborn stains, use a non-abrasive ceramic cooktop cleaner.
- Dry the surface thoroughly with a clean, dry cloth to prevent water spots.



Image: Icon representing the easy cleaning feature of the cooktop.

5.2 General Care:

- Avoid dropping heavy or sharp objects on the ceramic glass surface.
- Do not use abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the surface.
- Ensure spills are cleaned promptly to prevent them from baking onto the surface.

6. TROUBLESHOOTING

If you encounter issues with your VBGK Electric Cooktop, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Cooktop does not turn on.	No power supply; Child Safety Lock activated.	Check power cord connection and circuit breaker. Deactivate Child Safety Lock.
Burner not heating or heating slowly.	Incorrect power level selected; Cookware not suitable or improperly placed.	Increase power level. Ensure cookware is flat-bottomed and centered on the heating zone.
Cooktop shuts off unexpectedly.	Overheat protection activated; Timer expired.	Allow cooktop to cool down. Check if timer has reached zero.
Controls are unresponsive.	Child Safety Lock activated; Surface is wet or dirty.	Deactivate Child Safety Lock. Clean and dry the control panel.

If the problem persists after attempting these solutions, please contact VBGK customer support.

7. SPECIFICATIONS

Feature	Detail
Brand	VBGK
Model	2 Burner Electric Cooktop
Color	Black
Material	Metal, Ceramic Glass
Product Dimensions (D x W x H)	23.62"D x 14.17"W x 3.34"H
Item Weight	12.58 pounds (5.72 Kilograms)
Wattage	2400 watts (1200W per burner)
Voltage	110-120 Volts
Controls Type	LED Touch Knob Control
Burner Type	Radiant
Heating Elements	2
Power Levels	10
Temperature Range	212-1112°F
Timer	1 to 120 minutes
Special Features	Automatic Shut-Off, Electric, Power-On Indicator, Safety Lock, Temperature Control, Overheat Protection, Residual Heat Indication
Installation Type	Freestanding or Drop-In
Noise Level	40 dB
Certification	Energy Star

8. WARRANTY AND SUPPORT

8.1 Product Warranty:

The VBGK Electric Cooktop comes with a **one-year warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. Please retain your proof of purchase for warranty claims.

8.2 Customer Support:

For any questions, technical assistance, or warranty claims, please contact VBGK customer support. Refer to the contact information provided with your product packaging or visit the official VBGK website for the most up-

to-date support details.

You can also visit the VBGK Store on Amazon for more information:[VBGK Amazon Store](#)