

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [iDIGMALL](#) /

› [iDIGMALL G9 Bluetooth Headset User Manual](#)

## iDIGMALL G9

# iDIGMALL G9 Bluetooth Headset User Manual

Model: G9

## INTRODUCTION

---

This manual provides detailed instructions for the proper use and maintenance of your iDIGMALL G9 Bluetooth Headset. The G9 headset features an open-ear design for comfort and situational awareness, a detachable DSP noise-canceling boom microphone for clear communication, Bluetooth 5.3 for stable connectivity, multi-point pairing, and a long-lasting 12-hour battery. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

## PACKAGE CONTENTS

---

- 1 × G9 Wireless Headset
- 1 × Removable Boom Microphone
- 4 × Removable Soft Rubber Cover
- 1 × USB Type-C Charging Cable
- 1 × User Manual

# Package Includes

- 1×G9 Wireless Headset
- 1×Removable Boom Microphone
- 4×Removable Soft Rubber Cover
- 1×USB Type-C Charging Cable
- 1×User Manual



Figure 1: Contents included in the iDIGMALL G9 Bluetooth Headset package.

## PRODUCT OVERVIEW

The iDIGMALL G9 headset is designed for comfort and functionality. It features an open-ear design that rests outside the ear canal, allowing for environmental awareness. The flexible neckband connects the two earpieces, and a detachable boom microphone can be attached for enhanced call clarity.



Figure 2: The iDIGMALL G9 Bluetooth Headset with its detachable microphone.



Figure 3: Detailed diagram of the headset controls and components.

Your browser does not support the video tag.

Video 1: An overview of the iDIGMALL Bluetooth 5.3 Headset with Detachable Microphone, showcasing its features and design.

## SETUP

---

### 1. Charging the Headset

Before first use, fully charge the headset. Connect the provided USB Type-C charging cable to the headset's charging port and a compatible USB power source. The LED indicator will show charging status. A full charge takes approximately 1.5 hours, providing up to 12 hours of continuous playtime and 200 hours of standby time.

# Latest Bluetooth 5.3 Dual Connection

More stable and faster connection  
Stronger signal transmission



iOS



Android



Windows



33ft | 10m  
Wireless Range



Figure 4: Charging the headset and battery life details.

## 2. Bluetooth Pairing

The G9 headset utilizes Bluetooth 5.3 for stable and fast connections.

1. **Initial Pairing:** Power on the headset. The LED indicator will flash, indicating it's in pairing mode. On your device (phone, PC, laptop, tablet), enable Bluetooth and search for "G9". Select it to connect.
2. **Multi-Point Pairing:** The headset supports connecting to two devices simultaneously. After pairing with the first device, disable Bluetooth on that device. Put the headset back into pairing mode and connect to the second device. Once connected to the second device, re-enable Bluetooth on the first device. The headset should now be connected to both devices, allowing for seamless switching.

## Wearing Anywhere Anytime

All day comfort on ear

Design for all-day wear & for learning/sports/office work/driving



Figure 5: Bluetooth 5.3 and multi-point connection capabilities.

### 3. Attaching/Detaching the Microphone

The boom microphone is magnetically detachable, allowing you to switch between a professional headset and sport headphones. Simply align the microphone's magnetic connector with the port on the headset to attach it. To detach, gently pull the microphone away from the headset. The microphone can be rotated 360° for optimal positioning.

# Detachable Boom Microphone

Go from Work to Play



Figure 6: Detachable boom microphone for versatile use.

## OPERATING INSTRUCTIONS

### Controls Overview

The headset features a Multi-Function Button (MFB) and dedicated volume buttons. Refer to Figure 3 for button locations.

- **MFB (Button 1):** Power On/Off, Play/Pause Music, Activate Voice Assistant, Switch Game/Music Mode, Answer/Hang Up/Reject/Redial Calls.
- **Volume + (Button 2):** Volume Up, Next Song, Turn Off Mute.
- **Volume - (Button 3):** Volume Down, Previous Song, Turn On Mute.

### Power On/Off

- **Power On:** Press and hold the MFB until the LED indicator lights up.
- **Power Off:** Press and hold the MFB until the LED indicator turns off.

### Music Playback

- **Play/Pause:** Press the MFB once.

- **Next Song:** Press the Volume + button twice.
- **Previous Song:** Press the Volume - button twice.
- **Volume Up:** Press the Volume + button once.
- **Volume Down:** Press the Volume - button once.

## Call Management

The DSP noise-canceling boom microphone ensures clear call quality by filtering ambient noise.

- **Answer/Hang Up Call:** Press the MFB once.
- **Reject Call:** Press and hold the MFB for 2 seconds.
- **Redial Last Number:** Press the MFB twice.
- **Mute/Unmute Microphone:** Press the Volume - button once to mute, and the Volume + button once to unmute.



Figure 7: DSP Noise Canceling Microphone for clear communication.

## Voice Assistant Activation

Press and hold the MFB for 2 seconds to activate your device's voice assistant (e.g., Siri, Google Assistant).

## Switch Music/Game Modes

Press the MFB three times to switch between music mode and game mode. Game mode is designed to reduce audio latency.

## MAINTENANCE

---

To ensure the longevity and optimal performance of your iDIGMALL G9 headset, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the headset. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the headset in a cool, dry place away from direct sunlight and extreme temperatures.
- **Water Resistance:** The headset has an IPX5 waterproof rating, making it resistant to sweat and light splashes. Do not submerge the headset in water or expose it to heavy rain. Ensure the charging port cover is securely closed to maintain water resistance.
- **Flexibility:** The headset is designed to be flexible and can be bent 360° without deformation. However, avoid excessive force or sharp bends to prevent damage.



Figure 8: Open-ear design, lightweight, and IPX5 waterproof features.

## TROUBLESHOOTING

---

If you encounter issues with your iDIGMALL G9 headset, refer to the following common problems and solutions:

Problem	Possible Solution
Headset does not power on.	Ensure the headset is fully charged. Connect it to a power source using the USB Type-C cable.
Cannot pair with device.	Ensure the headset is in pairing mode (LED flashing). Turn off Bluetooth on other nearby devices. Restart your device and try pairing again.
No sound or low volume.	Check the volume levels on both the headset and your connected device. Ensure the headset is properly connected.
Microphone not working.	Ensure the detachable boom microphone is securely attached. Check if the microphone is muted (refer to Operating Instructions).
Intermittent connection.	Ensure the headset is within the 33-foot (10-meter) Bluetooth range of your device. Avoid obstacles that may interfere with the signal.

## SPECIFICATIONS

Feature	Detail
Model Name	G9
Connectivity Technology	Bluetooth 5.3, Wireless
Noise Control	Active Noise Cancellation (DSP Mic)
Ear Placement	Open Ear
Battery Life	12 Hours (Playtime)
Charging Time	1.5 Hours
Standby Time	200 Hours
Battery Capacity	150 mAh
Bluetooth Range	33 Feet (10 Meters)
Audio Driver Size	15.4 Millimeters
Impedance	32 Ohm
Water Resistance Level	IPX5 (Waterproof)
Item Weight	10 Grams (0.353 ounces)
Material	Plastic, Silicone
Compatible Devices	Cellphones, Desktops, Laptops, Tablets

## WARRANTY AND SUPPORT

iDIGMALL products are designed with quality and customer satisfaction in mind. For any questions, technical support, or warranty claims, please contact iDIGMALL customer service through the retailer where you purchased the product or visit the official iDIGMALL website for contact information. Please retain your proof of purchase for warranty purposes.

