

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Sonoro](#) /

› [Sonoro Maestro HiFi Receiver User Manual](#)

## Sonoro Maestro

# Sonoro Maestro HiFi Receiver User Manual

Model: Maestro | Brand: Sonoro

## 1. INTRODUCTION

The Sonoro Maestro is an all-in-one HiFi receiver designed to deliver high-quality audio experiences from various sources. It integrates a CD player, Internet radio, FM/DAB+ radio, and supports Bluetooth, Spotify, Amazon Music, and Deezer.

Featuring Hypex Class-D amplifiers and room correction capabilities, the Maestro is engineered to optimize sound output for your listening environment and speaker systems.



Figure 1.1: Front view of the Sonoro Maestro HiFi Receiver, showcasing its minimalist design and central display.

## 2. SAFETY INFORMATION

Please read all safety instructions before operating the device. Retain this manual for future reference.

- **Power Source:** Connect the unit only to an AC power outlet of the specified voltage.
- **Ventilation:** Ensure adequate ventilation. Do not block ventilation openings. Avoid placing the unit on soft surfaces that may obstruct airflow.
- **Water and Moisture:** Do not expose the unit to rain, moisture, dripping, or splashing. Do not place objects filled with liquids, such as vases, on the apparatus.
- **Heat:** Keep the unit away from heat sources such as radiators, heat registers, stoves, or other apparatus (including

amplifiers) that produce heat.

- **Cleaning:** Unplug the unit from the wall outlet before cleaning. Use a dry cloth only.
- **Servicing:** Do not attempt to service this product yourself. Refer all servicing to qualified service personnel.

## 3. PACKAGE CONTENTS

Carefully unpack the box and ensure all items are present:

- Sonoro Maestro HiFi Receiver
- Remote Control (with batteries)
- Power Cable
- FM/DAB+ Antenna
- Wi-Fi Antenna
- Quick Start Guide

## 4. SETUP

### 4.1 Placement

Place the Maestro on a stable, flat surface with sufficient space around it for proper ventilation. Avoid direct sunlight or proximity to heat sources.

### 4.2 Connecting Speakers

Connect your passive speakers to the speaker terminals on the rear panel. Ensure correct polarity (red to red, black to black) for optimal sound. The Maestro supports speakers with an impedance of 4 to 8 ohms.

### 4.3 Antenna Connections

- **Wi-Fi Antenna:** Screw the provided Wi-Fi antenna into the 'Wi-Fi Antenna' connector on the rear panel.
- **FM/DAB+ Antenna:** Connect the FM/DAB+ antenna to the 'DAB/FM ANTENNA' input. Extend the antenna for better reception.

### 4.4 Connecting External Devices

The Maestro offers a variety of input options:

- **Optical Input (TV):** Use an optical cable to connect devices like a TV or game console to the 'OPTICAL IN' port.
- **AUX Inputs:** Connect analog audio sources using RCA cables to 'AUX1' or 'AUX2' inputs.
- **Phono Input (MM):** For turntables with a Moving Magnet (MM) cartridge, connect to the 'PHONO IN (MM)' ports. Ensure the turntable's ground wire is connected to the 'GND' terminal.
- **USB:** Connect a USB storage device for media playback to the 'USB' port.
- **Network (LAN):** For a stable internet connection, connect an Ethernet cable to the 'LAN' port.



Figure 4.1: Rear panel of the Sonoro Maestro, detailing speaker terminals, antenna connections, and various input/output ports.

## 4.5 Power Connection

Connect the power cable to the 'AC MAINS' inlet on the rear panel and then to a wall outlet. Ensure the main power switch on the rear is in the 'ON' position.

## 4.6 Initial Power-On and Room Correction

Press the power button on the front panel or remote control to turn on the unit. Follow the on-screen instructions for initial setup, including network configuration. Utilize the MAESTRO room correction application for individualized sound optimization based on your room acoustics.

# 5. OPERATING INSTRUCTIONS

## 5.1 Power On/Off

Press the **STANDBY** button on the front panel or remote control to switch the unit between standby and operational mode. The main power switch on the rear should remain 'ON' for standby functionality.

## 5.2 Source Selection

Use the dedicated source buttons on the front panel (CD, FM, DAB, AUX, DIGITAL, PHONO) or the remote control to select your desired audio source. For Internet Radio and streaming services, navigate through the menu using the control knob and display.

# Wir geben Sound eine ikonische Gestalt.



**Figure 5.1:** Detailed view of the front panel controls, including source selection buttons, display, and navigation knob.

## 5.3 CD Playback

Insert a CD into the disc slot. The unit will automatically switch to CD mode and begin playback. Use the playback control buttons (Play/Pause, Skip, Stop) on the front panel or remote.

## 5.4 Radio Tuning (FM/DAB+)

Select FM or DAB+ mode. Use the navigation controls to scan for stations or tune manually. Save your favorite stations as presets for quick access.

## 5.5 Bluetooth Pairing

Select Bluetooth as the source. On your mobile device, search for available Bluetooth devices and select 'Sonoro Maestro'. Once paired, you can stream audio wirelessly.

## 5.6 Internet Radio and Streaming Services

Ensure the Maestro is connected to your network (Wi-Fi or LAN). Navigate through the menu to access Internet Radio stations or integrated streaming services like Spotify, Amazon Music, and Deezer. Follow the on-screen prompts to log in to your accounts.

## 5.7 Volume Control

Adjust the volume using the large rotary knob on the front panel or the volume buttons on the remote control.

## 5.8 Remote Control and App Control

The included remote control provides full functionality. For enhanced control, download the 'Undok' app on your smartphone or tablet to manage sources, playlists, and settings.

## 6. KEY FEATURES

- Powerful Amplification:** Hypex Class-D amplifier delivering 2 x 170 W into 4 ohms or 2 x 100 W into 8 ohms.
- All-in-One Audio:** Integrated CD player, FM, DAB+, Internet radio, Bluetooth, Spotify, Amazon Music, and Deezer.
- Advanced Connectivity:** Optical digital input (for TV), AUX inputs, Wi-Fi, headphone jack, RCA, line/pre-out/phono input (MM), and Bluetooth aptX.
- Room Correction:** Individual sound optimization via the MAESTRO room correction application.
- German Engineering & Design:** Hand-polished cabinet with premium lacquer finish, full metal front, rear, and buttons.
- System Compatibility:** Designed to integrate harmoniously with Sonoro PLATINUM turntables and Orchestra speakers.

## 7. MAINTENANCE

### 7.1 Cleaning

Wipe the unit with a soft, dry, lint-free cloth. Do not use liquid cleaners, aerosols, or abrasive materials, as these may damage the finish.

### 7.2 Software Updates

Periodically check for available software updates through the unit's menu or the companion app. Updates can improve performance, add features, and enhance stability.

## 8. TROUBLESHOOTING

If you encounter issues with your Sonoro Maestro, refer to the following common problems and solutions:

Problem	Possible Cause / Solution
No power	Ensure the power cable is securely connected and the main power switch on the rear is 'ON'. Check the wall outlet.
No sound	Check speaker connections and polarity. Verify the correct input source is selected. Adjust volume. Ensure 'Loudness' function is enabled if desired for richer sound.
Poor radio reception	Adjust the position of the FM/DAB+ antenna. Check for local interference. For Internet Radio, ensure a stable network connection.
Bluetooth pairing issues	Ensure the Maestro is in Bluetooth pairing mode. Disable and re-enable Bluetooth on your mobile device. Move devices closer.

Problem	Possible Cause / Solution
Wi-Fi connectivity unstable	Ensure the Wi-Fi antenna is securely attached. Move the unit closer to your router or consider a wired LAN connection for stability.
Unit becomes excessively warm	Ensure adequate ventilation around the unit. Do not place it in an enclosed space without airflow. If overheating persists, contact support.
App (Undok) issues / slow performance	Ensure the app and unit firmware are up to date. Restart the app and the Maestro. Note that the app may have limitations with very large music libraries.

For further assistance, please refer to the official Sonoro support resources.

## 9. SPECIFICATIONS

Feature	Detail
Brand	Sonoro
Color	Matte Silver White
Connectivity Technology	Bluetooth, USB
Special Feature	Bluetooth aptX Technology
Included Components	Remote Control
Supported Audio Formats	CD-Audio, MP3, AAC
Connection Interfaces	USB, AUX, Optical Digital Input, RCA, Line/Pre-out/Phono Input, Bluetooth
Media Format Type	Audio CD
Compatible Devices	TV, Personal Computer, Tablet, Smartphone, Amplifier
Headphone Jack	True
Battery Composition	Lithium Manganese Dioxide
Rechargeable Battery	No
Manufacturer	sonoro audio GmbH
ASIN	B0CJRBP28J
Date First Available	September 25, 2023
Spare Parts Availability	Information unavailable
Software Updates Guaranteed Until	Information unavailable

## 10. WARRANTY AND SUPPORT

The Sonoro Maestro HiFi Receiver comes with a manufacturer's warranty. Please refer to the warranty card included with your product or visit the official Sonoro website for detailed warranty terms and conditions.

For technical support, service inquiries, or further assistance, please contact Sonoro customer service through their official website or the contact information provided in your product documentation.

© 2023 Sonoro. All rights reserved.

## Related Documents - Maestro

 <p>Operating instructions</p>	<p><a href="#"><u>MEISTERSTÜCK (Gen. 2) All-In-One Audio Music System Operating Instructions</u></a></p> <p>Detailed operating instructions for the sonoro MEISTERSTÜCK (Gen. 2) All-In-One Audio Music System. Covers setup, operation of various sources (DAB, FM, Internet Radio, Bluetooth, CD, Streaming), sound settings, network connectivity, troubleshooting, and technical specifications.</p>
 <p>Dirac Live App Quick Start Guide</p>	<p><a href="#"><u>Dirac Live App Schnellstartanleitung für sonoro MAESTRO Quantum</u></a></p> <p>Optimieren Sie die Akustik Ihres Raumes mit der Dirac Live App und dem sonoro MAESTRO Quantum. Diese Anleitung bietet Schritt-für-Schritt-Anweisungen für Einrichtung und Raumkorrektur.</p>
 <p>Operating instructions</p>	<p><a href="#"><u>Sonoro MAESTRO Quantum Operating Instructions</u></a></p> <p>Comprehensive operating instructions for the Sonoro MAESTRO Quantum All-In-One Audio Music System, covering setup, operation, troubleshooting, and technical specifications.</p>
 <p>STREAM SO-411 INTERNET RADIO WITH WIFI, DAB+ &amp; BLUETOOTH</p>	<p><a href="#"><u>Sonoro STREAM SO-411 Internet Radio Safety Manual</u></a></p> <p>This document provides essential safety and operating instructions for the Sonoro STREAM SO-411 Internet Radio with Wi-Fi, DAB+, and Bluetooth. It covers intended use, warnings, precautions for children, power supply, battery handling, USB charging, transport, environmental conditions, and disposal.</p>
 <p>sonoro<sup>®</sup> sonoroSTREAM (SO-410) Smartradio Bruksanvisning</p>	<p><a href="#"><u>sonoro STREAM SO-410 Smartradio Bruksanvisning</u></a></p> <p>Officiell bruksanvisning för sonoro STREAM SO-410 Smartradio. Lär dig installera, använda och felsöka din enhet för optimal ljudupplevelse.</p>



## [Sonoro PLATINUM Automatic EAS \(SO-2100\) Operating Manual](#)

This manual provides detailed instructions for setting up, operating, and maintaining the Sonoro PLATINUM Automatic EAS turntable (model SO-2100). Learn about its features, connections, and troubleshooting.