

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [RoyalCraft](#) /

› [RoyalCraft Farmhouse Fireplace TV Stand \(Model ZTS010GY-OP\) Instruction Manual](#)

**RoyalCraft ZTS010GY-OP**

# RoyalCraft Farmhouse Fireplace TV Stand Instruction Manual

Model: ZTS010GY-OP

## 1. INTRODUCTION

---

Thank you for choosing the RoyalCraft Farmhouse Fireplace TV Stand. This entertainment center is designed to accommodate TVs up to 65+ inches and includes a 23-inch electric fireplace. It features a rustic design with sliding barn doors, ample storage, and a functional electric fireplace to enhance your living space. This manual provides essential information for safe assembly, operation, and maintenance of your new TV stand.



Image: The RoyalCraft Farmhouse Fireplace TV Stand in Dark Grey, showcasing its overall design and integrated electric fireplace.

## 2. SAFETY INFORMATION

**WARNING: Failure to follow these safety instructions may result in fire, electric shock, injury, or property damage.**

- Ensure the TV stand is securely assembled and attached to the wall using the provided anti-tipping straps and triangle fixers.
- Do not place heavy objects on the top shelf to prevent tipping. The maximum recommended load is 380 pounds.
- Keep the fireplace remote out of reach of children.
- Allow the fireplace to cool down before touching or unplugging.
- Do not block the air outlet of the electric fireplace. Maintain clear space around the unit for proper ventilation.
- This product is intended for indoor use only.

## 3. PACKAGE CONTENTS

---

Your RoyalCraft Farmhouse Fireplace TV Stand will arrive in two separate boxes. Please ensure you have received both packages before beginning assembly.

- **Box 1:** Farmhouse TV Stand components (engineered wood panels, hardware, sliding barn door mechanisms).
- **Box 2:** 23-inch Electric Fireplace unit and remote control.

Verify all parts are present and undamaged by checking against the parts list provided in the assembly instructions.

## 4. ASSEMBLY INSTRUCTIONS

---

Assembly is required for this product. Detailed instructions, tools, and hardware are included in the packaging. Please follow the step-by-step guide carefully.

1. Unpack all components from both boxes and lay them out on a clean, soft surface to prevent scratches.
2. Identify each part using the labels and diagrams in the instruction booklet.
3. Assemble the main frame of the TV stand according to the provided diagrams.
4. Install the sliding barn door tracks and doors. The doors feature an X-shaped panel design.
5. Insert the adjustable shelves into the side compartments. These shelves offer 3 height options for customized storage.
6. Integrate the 23-inch electric fireplace unit into the central opening. Ensure it is securely placed.
7. Utilize the cable holes in the back panel for neat wire management.
8. Attach the anti-tipping straps and triangle fixers to secure the TV stand to the wall, enhancing stability and safety.

# Ample Storage Capacity

It can be classified, and the laminate has three gears which can be adjusted



Image: Illustration of the TV stand's ample storage capacity with adjustable shelves and smooth sliding barn doors.



Image: Detailed dimensions of the TV stand, including overall width, height, depth, and internal compartment measurements.

Your browser does not support the video tag.

Video: A demonstration of the farmhouse fireplace and TV stand, highlighting its features and design.

Your browser does not support the video tag.

Video: A short clip demonstrating the thoughtful design of the cable holes for wire management.

## 5. OPERATING THE ELECTRIC FIREPLACE

The 23-inch electric fireplace offers customizable flame effects and adjustable heating. It can be controlled via the intuitive function keys on the unit or with the included remote control.

### 5.1. Controls

- **Flame Color:** Choose from 6 captivating flame hues.

- **Brightness Levels:** Adjust flame brightness with 3 available settings.
- **Heater:** The 5000 BTU heater provides warmth for areas up to 400 sq. ft. Set your desired temperature from 22 options.
- **Timer:** Set the fireplace to operate for a duration between 0.5 to 6 hours.
- **Power:** Turn the unit on or off.

## 5.2. Safety Features

- **CSA Certified:** Ensures compliance with safety standards.
- **Smart Overheating Protection:** Automatically shuts off the unit if it overheats.
- **Cool-to-Touch Glass:** The front glass remains cool to the touch during operation.



Image: A detailed view of the electric fireplace control panel and the remote control for convenient operation.

Your browser does not support the video tag.

Video: A brief introduction to the RoyalCraft 23-inch Electric Fireplace, demonstrating its features.

Your browser does not support the video tag.

Video: A demonstration of the electric fireplace's realistic flames and heating capabilities.

Your browser does not support the video tag.

Video: A short clip showcasing the fireplace with its six flame shades.

## 6. MAINTENANCE AND CARE

---

To ensure the longevity and appearance of your RoyalCraft TV Stand, follow these simple care instructions:

- **Cleaning:** Wipe the surfaces with a dry cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Spills:** The tabletop is waterproof. In case of spills, wipe immediately with a damp cloth and dry thoroughly.
- **Fireplace:** Ensure the fireplace is turned off and cooled before cleaning. Refer to the separate fireplace manual for specific cleaning instructions.

## 7. TROUBLESHOOTING

---

If you encounter any issues with your RoyalCraft Farmhouse Fireplace TV Stand, please refer to the following common solutions:

- **Fireplace Not Turning On:** Check if the unit is properly plugged into a working electrical outlet. Ensure the power button on the unit or remote is pressed.
- **No Heat Output:** Verify that the heater function is activated and the temperature setting is above the ambient room temperature. Check for any obstructions around the air outlet.
- **Remote Control Not Working:** Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the fireplace unit.
- **Sliding Doors Sticking:** Check the barn door tracks for any debris or misalignment. Ensure the doors are properly seated on the rollers.
- **Unstable Stand:** Confirm that all assembly hardware is tightened. Ensure the anti-tipping straps are correctly installed and secured to the wall.

If the problem persists after attempting these solutions, please contact customer service for further assistance.

## 8. SPECIFICATIONS

---

<b>Brand</b>	RoyalCraft
<b>Model Number</b>	ZTS010GY-OP
<b>Product Dimensions</b>	58 x 16 x 34 inches (W x D x H)
<b>Item Weight</b>	110 pounds
<b>Material</b>	Engineered Wood (P2-grade particleboard and MDF)
<b>Color</b>	Dark Grey
<b>Maximum Recommended Load</b>	380 Pounds
<b>Number of Shelves</b>	2 (adjustable)
<b>Fireplace Size</b>	23 inches

<b>Heat Output</b>	5000 BTU
<b>Heating Coverage</b>	Up to 400 sq. ft.
<b>Flame Colors</b>	6 changeable hues
<b>Temperature Settings</b>	22 options (62°F-82°F)
<b>Timer</b>	0.5 to 6 hours adjustable
<b>Certifications</b>	CSA Certified

## 9. WARRANTY AND SUPPORT

---

RoyalCraft is committed to providing quality products and excellent customer service.

- **Returns:** Enjoy 30-day easy returns.
- **Coverage:** This product includes 18-month coverage.
- **Assistance:** RoyalCraft offers 100% lifelong assistance for any product-related inquiries.
- **Customer Service:** If you have any questions, concerns, or require assistance with assembly or operation, please feel free to contact our customer service team.