



Manuals.plus /

- › ALECK /
- › ALECK Punks Wireless Bluetooth Bike Helmet Speakers User Manual

ALECK ALKPUNKS-2

ALECK Punks Wireless Bluetooth Bike Helmet Speakers User Manual

Model: ALKPUNKS-2

INTRODUCTION

The ALECK Punks Wireless Bluetooth Bike Helmet Speakers are designed to enhance your outdoor adventures by providing high-quality open-ear audio and seamless communication. These lightweight and durable speakers attach easily to any open-face helmet, allowing you to enjoy music, make hands-free calls, and communicate with your group while maintaining full awareness of your surroundings. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance and longevity of your device.



Image: The ALECK Punks Wireless Bluetooth Bike Helmet Speakers, showcasing their sleek, compact design.

Your browser does not support the video tag.

Video: An overview of the ALECK Punks, highlighting their design and primary use cases.

FEATURES

- **Open Ear Audio:** Delivers crystal clear sound while maintaining spatial awareness, allowing you to hear your surroundings.
- **Hands-Free Calls:** Equipped with dual integrated microphones for clear communication, even in windy conditions.
- **2-Button Operation:** Intuitive controls for managing music playback, answering calls, and activating voice assistants (Siri, Google Assistant).
- **Universal Helmet Mounting:** Designed to effortlessly mount to any open-face helmet strap.

- **Long-Lasting Battery:** Provides up to 12 hours of play/talk time on a single charge.
- **Water & Dust Resistance:** IP65 rated, making them resistant to water, sweat, and dust.
- **Lightweight Design:** Each speaker weighs only 16 grams, ensuring comfort during extended use.




Image: Visual representation of ALECK Punks key features including universal compatibility, powerful sound, IP65 protection, and 12 hours of battery life.

Your browser does not support the video tag.

Video: Detailed explanation of the features and benefits of the ALECK Punks.

WHAT'S IN THE BOX

- ALECK Punks Speakers (Left and Right)
- USB Charging Cable
- Storage Bag

In the box



Punks, carry pouch, sticker & cable

Image: All items included in the ALECK Punks product packaging.

SETUP

1. Powering On/Off

To power on your ALECK Punks, press and hold the main button on each speaker until you hear the power-on chime. The LED indicators will flash green and blue, indicating they are in Bluetooth pairing mode. To power off, press and hold the main button until you hear the power-off chime.

2. Bluetooth Pairing

1. Ensure both ALECK Punks speakers are powered on and in pairing mode (flashing green/blue LEDs).
2. Open the ALECK app on your smartphone. If you don't have the app, download it from your device's app store.
3. From the app's home screen, tap the "Add" button.
4. Select "Add Device" and then choose "Aleck Punks" from the list.
5. The app will guide you to your phone's Bluetooth settings. Locate "ALECK PUNKS" followed by a unique 3-digit code (e.g., ALECK PUNKS 780) and tap to connect.
6. Once connected, return to the ALECK app. The app will confirm successful pairing.

Your browser does not support the video tag.

Video: A step-by-step guide on setting up the ALECK Punks with the mobile application.

3. Helmet Installation

The ALECK Punks are designed for easy and secure attachment to the nylon straps of most open-face helmets. For optimal audio performance, position the speakers on the leading strap closest to the front of the helmet, with the speaker facing backwards towards your ear.

1. Identify the leading strap on your helmet (the strap closest to the front of your face).
2. Thread the nylon strap through the top hook of the ALECK Punks speaker.
3. Then, thread the strap through the bottom hook, ensuring the speaker is securely attached and facing backwards towards your ear. The hooks are designed to lock in opposite directions for a firm grip.
4. Repeat for the other speaker on the opposite side of the helmet.
5. Once installed, adjust the position of the speakers along the strap to ensure they are as close to your ears as possible without causing discomfort. This maximizes sound quality.
6. Ensure your helmet's chin strap is securely fastened, but not overly tight, to keep the speakers in place.
7. If wearing glasses, the Punks are designed with a small ledge to accommodate glasses arms over the straps, ensuring comfort and functionality.




Image: Close-up of the ALECK Punks speaker mounted on a helmet strap, positioned for open-ear audio.

Your browser does not support the video tag.

Video: Comprehensive instructions for installing the ALECK Punks on a helmet.

OPERATING

1. Music and Call Control

The ALECK Punks feature intuitive 2-button operation for controlling your audio and calls. The buttons are located on the back of each speaker, designed for easy access even with gloves.

- **Play/Pause:** Single tap the main button on either speaker.
- **Volume Up/Down:** Press and hold the main button on the left speaker to cycle through volume levels. Release when desired volume is reached.
- **Next Track:** Double tap the main button on the right speaker.
- **Previous Track:** Triple tap the main button on the right speaker.
- **Answer/End Call:** Single tap the main button on either speaker when a call comes in or to end an ongoing call.
- **Activate Voice Assistant (Siri/Google Assistant):** Press and hold the main button on the right speaker until you hear a chime.




Image: A user demonstrating the simple 2-button operation of the ALECK Punks.

2. Group Communication (ALECK App)

The ALECK app unlocks unlimited range group communication, functioning like a VoIP call (e.g., Zoom, Teams). This requires cellular connectivity on your smartphone.

- **Creating a Group:**

- From the app's home screen, tap the "Add" button.
- Select "Create Group."
- Choose a group name and optionally add a picture.
- Select your preferred communication mode:
 - **Party Mode:** Dive into an active chat where music lowers when someone is unmuted for uninterrupted conversation. Everyone can talk simultaneously.
 - **PTT Mode (Push-to-Talk):** Functions like a walkie-talkie. Unmute whenever you're ready to jump into the conversation.
- Save your group settings.

- **Joining a Group:**

- From the app's home screen, tap the "Add" button.
- Select "Join Group" and enter the group invitation code provided by the group creator.

- **Using Group Communication:**

- Once in a group, tap "Go Live" to activate communication.
- In Party Mode, your microphone is active by default.
- In PTT Mode, tap the left speaker's main button to speak (unmute) and release to listen (mute).
- You can adjust the PTT speaking time in the app's settings (up to 12 seconds).

- **Location Tracking:** The ALECK app also provides real-time location tracking of all group members on a map, allowing you to see where everyone is.

MAINTENANCE

- **Charging:** Use the provided USB charging cable to charge your ALECK Punks. A full charge takes approximately 1 hour and provides up to 12 hours of use.
- **Cleaning:** Wipe the speakers with a soft, damp cloth. Do not use harsh chemicals or abrasive materials.
- **Water & Dust Resistance:** The IP65 rating means the Punks are resistant to sweat and splashes. Avoid submerging them in water. Ensure charging ports are dry before charging.
- **Storage:** When not in use, store the speakers in the provided storage bag to protect them from dust and scratches.



Battery for Days!

Enjoy long rides with Aleck Punks
helmet speakers.

Image: The ALECK Punks connected to their charging cable, highlighting their long battery life.



Image: The ALECK Punks demonstrating their IP65 water and dust resistance.

TROUBLESHOOTING

Problem	Solution
Speakers not powering on.	Ensure speakers are charged. Connect to USB cable and allow to charge for at least 15 minutes before attempting to power on again.
Cannot pair with phone/app.	<ul style="list-style-type: none"> • Ensure speakers are in pairing mode (flashing green/blue LEDs). • Turn off and on your phone's Bluetooth. • Forget the device in your phone's Bluetooth settings and attempt to pair again. • Ensure the ALECK app has Bluetooth permissions enabled in your phone's settings.
Poor sound quality or low volume.	<ul style="list-style-type: none"> • Adjust speaker position on helmet straps to be closer to your ears. • Increase volume using the speaker buttons or your phone's volume controls. • Ensure speakers are clean and free from debris.
Group communication issues (ALECK App).	<ul style="list-style-type: none"> • Verify stable cellular data connection for all group members. • Ensure all members are in the same group within the ALECK app. • Check app permissions for microphone access. • For PTT mode, ensure you are pressing the button to speak.

SPECIFICATIONS

- **Model Name:** Aleck Punks
- **Connectivity Technology:** Bluetooth 5.2 True Wireless
- **Battery Life:** 12 Hours (Play/Talk Time)
- **Charging Time:** 1 Hour
- **Item Weight:** 16 grams (each speaker)
- **Dimensions:** 5.7 x 2.7 x 1 cm (2.25 x 1 x 0.5 in)
- **Water Resistance Level:** IP65 (Water Resistant)
- **Control Type:** App, Google Assistant, Siri, 2-Button
- **Audio Driver Type:** Dynamic Driver
- **Audio Driver Size:** 22 Millimeters
- **Material:** ABS reinforced with polycarbonate
- **Recommended Uses:** Cycling, Equestrian, Snowboarding, Skateboarding

WARRANTY & SUPPORT

ALECK products are designed for durability and performance. For specific warranty information and to access customer support, please visit the official ALECK website or contact their customer service directly. Keep your proof of purchase for warranty claims.

Manufacturer: Peclat Ltd.

