Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Snailax SL-681

Snailax Cordless Neck Shoulder Massager User Manual

Brand: **Snailax** | Model: **SL-681**

Introduction

Thank you for choosing the Snailax Cordless Neck Shoulder Massager. This device is designed to provide a deep, relaxing massage experience with its innovative 4D kneading technology and soothing heat function. This manual provides essential information for safe and effective use, setup, operation, maintenance, and troubleshooting.



Image: The Snailax Cordless Neck Shoulder Massager, showcasing its ergonomic design and control panel.

Safety Information

Please read all safety instructions carefully before using the massager.

- The device features an auto-shutdown function after 10 minutes to prevent overheating and ensure user safety.
- Do not use the massager while charging.
- Keep out of reach of children.
- Consult a physician before use if you have any medical conditions, are pregnant, or have a pacemaker.
- Do not use on swollen, inflamed, or broken skin.
- Do not use in damp or wet environments.
- Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

Product Features

- **Innovative 4D Deep Kneading:** Simulates deep human-like massages with 6 ergonomic massage nodes, covering a wider area from neck to trapezius and shoulders.
- **Adjustable Gentle Heating:** Offers two heat settings (104°F/120°F) to warm the neck and shoulders, promoting relaxation. Auto-shutdown after 10 minutes.
- **Hand-free Design:** Can be handheld or worn with the adjustable strap for various usage scenarios. Compact and portable.
- **Cordless Operation:** Features a Type-C charging port, providing 70-80 minutes of continuous massage on a single charge.




Image: Diagram illustrating the upgraded 4D deep kneading massage mechanism.



Image: A person experiencing the soothing hot compress feature on the neck massager.



Image: Demonstrating the hand-free design with an adjustable strap for secure wearing.



Image: A user enjoying the cordless design while charging via Type-C.

Setup

1. **Unboxing:** Carefully remove the massager and all accessories from the packaging. Ensure all components listed in the package contents (massager, USB cable, user manual, packing box) are present.
2. **Initial Charge:** The power may be low during transportation. Fully charge the product before first use. Connect the Type-C USB cable to the massager's charging port and a suitable power source. The charging indicator light will illuminate. A full charge provides 70-80 minutes of continuous use.
3. **Familiarize with Controls:** Locate the control panel on the massager. It typically includes Power ON/OFF, Mode, Heat, and Speed buttons.



Image: Visual representation of product dimensions and included package contents.

Operating Instructions

Follow these steps to operate your Snailax Neck Shoulder Massager:

1. **Power On:** Press the **Power ON/OFF** button to turn on the massager. The default timer is 10 minutes.
2. **Select Mode:** Press the **Mode** button to cycle through the 3 available massage modes.
3. **Adjust Speed:** Press the **Speed** button to select High, Medium, or Low intensity for the massage. The default strength is medium. If too strong, adjust to low.
4. **Activate Heat:** Press the **Heat** button to turn on the heating function. Press again to switch between 104°F and 120°F, or to turn off the heat.
5. **Positioning:** Place the massager around your neck and shoulders. You can use the adjustable strap for a hands-free experience, or hold the handles to guide the massage nodes to other areas like the back, waist, thighs, or

shanks.

6. **Power Off:** The device will auto-shutdown after 10 minutes. To manually turn off, press and hold the **Power ON/OFF** button.




Image: Close-up of the control panel with Power, Mode, Heat, and Speed buttons.




Image: Demonstrating the massager's versatility for use on shoulders, waist, thighs, and shanks.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your massager:

- **Cleaning:** Disconnect the massager from any power source before cleaning. Wipe the surface with a soft, damp cloth. Do not use abrasive cleaners or immerse the device in water.
- **Storage:** Store the massager in a cool, dry place away from direct sunlight and extreme temperatures. Keep it in its original packaging or a protective bag to prevent dust accumulation.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge it regularly, even if not in use for extended periods.

Troubleshooting

If you encounter any issues with your Snailax massager, refer to the table below for common problems and solutions:

Problem	Solution
Battery problem or unable to charge	Note: The power will be lost during transportation. Please fully charge the product before use. Make sure the TYPE-C is plugged in properly and the charging indicator light is on when charging, otherwise it may affect the charging effect. The default timer of this neck massager is 10 minutes. If it stops working after a period of use, it may be due to the end of the timer.
Massage heads rotating at reduced speed	Device may have been in use for 10 minutes. Auto-shutdown function activated. Continue using by pressing the 'On' button after resting the unit for 15 minutes.
Device fails to start	Over-heat protection function activated. Device is switched off for your safety. Please rest device for 15-30 minutes before restarting. Check if device has been used for more than 10 minutes. If so, let device rest for 15 minutes before continuing. Device may require longer time to cool in warmer environments. The battery is low, please charge in time.

Specifications

Attribute	Value
Product Dimensions	3.54 x 2.36 x 1.97 inches; 3.22 Pounds
Item model number	SL-681
Batteries	2 9V batteries required. (included)
Date First Available	September 26, 2023
Manufacturer	Snailax
ASIN	B0CJTW9DYC
Use for	Shoulder, Back, Neck
Power Source	Battery Powered
Material	Polyester
Brand	Snailax

Attribute	Value
Color	Light Black

Official Product Videos

No official product videos from the seller are available for embedding at this time.

Warranty and Support

For warranty information and customer support, please refer to the contact details provided in your product packaging or visit the official Snailax website. Keep your purchase receipt for warranty claims.

© 2023 Snailax. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CJTW9DYC

More documents and user manuals: **https://manuals.plus/**