Vikye Vikyekh3gtqmd5c-11

Wireless Keyboard 10 Inch User Manual

Brand: Vikye

Introduction

The Vikye Wireless Keyboard is designed for seamless integration with your mobile devices, transforming them into efficient workstations. Featuring a silent design with scissor feet and chocolate keycaps, it ensures a quiet typing experience. This portable keyboard includes multimedia function keys for enhanced convenience and boasts a durable, stylish brushed metal texture. It is widely compatible with both Android and iOS devices.



Image: Top-down view of the Vikye Wireless Keyboard, showcasing its compact design and full QWERTY layout with function keys.

Package Contents

Please check the package for the following items:

- 1 x Wireless Keyboard

Setup

1. Charging the Keyboard

Before first use, ensure the keyboard is fully charged. Connect the provided charging cable to the keyboard's charging port and a USB power source. The charging indicator light will illuminate during charging and turn off when fully charged. Charging time is typically less than 2 hours.

2. Powering On/Off

Locate the ON/OFF switch on the keyboard. Slide the switch to the "ON" position to power on the keyboard. Slide it to "OFF" to power it down when not in use to conserve battery life.

3. Pairing with Your Device

1. Ensure the keyboard is powered on.
2. Press the "Connect" button on the keyboard (usually located near the ON/OFF switch) to enter pairing mode. The indicator light will blink, signaling it's ready to pair.
3. On your device (tablet, computer, or phone), go to the settings menu and enable Bluetooth.
4. Search for available Bluetooth devices. The keyboard will appear as "Wireless Keyboard" or a similar name.
5. Select the keyboard from the list to initiate pairing. Your device may prompt you to enter a code displayed on the screen using the keyboard, then press Enter.
6. Once successfully paired, the indicator light on the keyboard will stop blinking and remain solid or turn off, depending on the model.



Image: Angled view of the Vikye Wireless Keyboard, highlighting the power switch and connect button for pairing.

Operating Instructions

General Use

Once paired, the keyboard functions like a standard external keyboard. Simply open any application that requires text input and begin typing. The silent design ensures a quiet and comfortable typing experience.

Multimedia Function Keys

The keyboard is equipped with multimedia function keys (F1-F12) that provide quick access to various controls. These keys typically require pressing the "Fn" key simultaneously with the desired function key.

- **Fn + F1:** Home
- **Fn + F2:** Search
- **Fn + F3:** Select All
- **Fn + F4:** Copy
- **Fn + F5:** Paste
- **Fn + F6:** Cut
- **Fn + F7:** Previous Track
- **Fn + F8:** Play/Pause
- **Fn + F9:** Next Track
- **Fn + F10:** Mute
- **Fn + F11:** Volume Down
- **Fn + F12:** Volume Up

Note: The exact functionality of multimedia keys may vary slightly depending on your device's operating system (iOS, Android, Windows).

Compatibility

This keyboard is designed for broad compatibility with iOS and Android devices. It can be used with tablets, smartphones, and other devices that support Bluetooth keyboard input.



Image: A person using the Vikye Wireless Keyboard with a tablet, demonstrating its portability and ease of use in a work setting.

Maintenance

Cleaning

To clean the keyboard, gently wipe the surface with a soft, dry, lint-free cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals, solvents, or abrasive materials, as these can damage the keyboard's finish and internal components.

Storage

When not in use for extended periods, store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures. It is recommended to power off the keyboard to preserve battery life.

Battery Care

To maximize the lifespan of the built-in lithium battery, avoid fully discharging it frequently. Recharge the keyboard when the battery low indicator (if present) illuminates or when performance degrades. Do not expose the battery to high temperatures or attempt to disassemble it.

Troubleshooting

Keyboard Not Connecting/Pairing

- Ensure the keyboard is powered on and fully charged.
- Make sure Bluetooth is enabled on your device.
- Move the keyboard closer to your device (within 10 meters effective range).
- Turn off and on both the keyboard and your device's Bluetooth.
- If previously paired, try "forgetting" or "unpairing" the keyboard from your device's Bluetooth settings and then re-pairing it.
- Ensure no other Bluetooth devices are interfering with the connection.

Keys Not Responding

- Check if the keyboard is properly connected to your device.
- Recharge the keyboard, as low battery can affect performance.
- Restart your device.
- Clean any debris that might be under the keys.

Short Battery Life

- Ensure the keyboard is fully charged before use.
- Power off the keyboard when not in use.
- Avoid extreme temperatures during operation or storage.

Specifications

Item Type	Wireless Keyboard
Material	ABS
Bluetooth Version	3.0
Charging Time	<2 hours
Effective Range	≤10 meters
Battery Type	Lithium battery
Battery Capacity	110mAh (included)
Operating Voltage	3.0V to 4.2V
Key Life	3 million clicks
Working Current	<2.5mA
Operating Hours	>40 hours
Standby Time	>100 days
Model Number	Vikyekh3gtqmd5c-11

ASIN	B0CJTWDNBB
Package Dimensions	10.24 x 7.09 x 0.79 inches



Image: Close-up view of the Vikye Wireless Keyboard keys, showing the "chocolate keycaps" and function key labels.

Warranty and Support

For any product inquiries, technical support, or warranty information, please contact your retailer or the manufacturer directly. Keep your purchase receipt as proof of purchase for any warranty claims.
Manufacturer: Vikye

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How can I make the Vikye Wireless Keyboard visible on my Android phone if it powers on but does not enter pairing mode?

To make your Vikye Wireless Keyboard visible to your Android phone, you must manually trigger the pairing mode after turning the power on. Follow these steps:Power On: Slide the ON/OFF switch to the ON...

Read full answer