

[Manuals.plus](#) /

> [Anfilank](#) /

> Electric Gooseneck Kettle, 1L 1500W Fast Boil, 100% Stainless Steel BPA Free Pour-Over Coffee & Tea Kettle, Water Boiler with Auto Shut & Boil-Dry Protection, Green

Anfilank JK-156A

Anfilank Electric Gooseneck Kettle Instruction Manual

Model: JK-156A | Brand: Anfilank

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions carefully before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or electric kettle in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or personal injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Extreme caution must be used when moving an appliance containing hot water.
- The kettle is only to be used with the stand provided.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

PRODUCT OVERVIEW

The Anfilank Electric Gooseneck Kettle is designed for precision pouring and rapid boiling, ideal for coffee and tea enthusiasts. Below are the key components:

- **Gooseneck Spout:** Provides precise control for pour-over coffee and tea.
- **Lid:** Removable for easy filling and cleaning.
- **Handle:** Ergonomically designed for comfortable grip with anti-scald features.
- **Power Base:** 360° rotational base with cord storage.
- **On/Off Switch:** Lever-style switch with indicator light.
- **Stainless Steel Interior:** 100% food-grade stainless steel, BPA-free.
- **Water Level Markings:** Internal markings for minimum and maximum fill levels, including a 1-cup rapid boil zone.



Figure 1: Anfilank Electric Gooseneck Kettle (Green color variant).

304 STAINLESS STEEL & BPA FREE

Keep The Water Clean And Safe For You



**Stainless Steel
Inner Lid**

**Stainless Steel
Spout**

**Stainless Steel
Interior**

Figure 2: Internal components showing stainless steel inner lid, spout, and interior, ensuring water purity.

SETUP

1. **Unpacking:** Carefully remove the kettle and its power base from the packaging. Retain packaging for future storage or transport.
2. **Initial Cleaning:** Before first use, fill the kettle with clean water to the maximum fill line. Boil the water, then discard it. Repeat this process 2-3 times to remove any manufacturing residues.
3. **Placement:** Place the power base on a dry, flat, stable, and heat-resistant surface. Ensure the power cord is not dangling where it can be pulled or tripped over.
4. **Power Connection:** Plug the power cord into a standard electrical outlet (120V/60Hz).

OPERATING INSTRUCTIONS

1. **Filling the Kettle:** Remove the lid by pulling it upwards. Fill the kettle with the desired amount of fresh, cold water. Do not fill below the minimum mark or above the maximum mark. For a single cup, use the "1 CUP" marking inside.

2. **Replacing the Lid:** Securely place the lid back onto the kettle.
3. **Placing on Base:** Position the kettle onto its power base.
4. **Starting Boil:** Push the On/Off switch lever downwards. The indicator light will illuminate, signifying that the kettle is heating.
5. **Automatic Shut-Off:** The kettle will automatically turn off once the water reaches a rolling boil. The indicator light will extinguish, and the switch will return to the upright position.
6. **Pouring:** Carefully lift the kettle from the base and pour the hot water using the gooseneck spout for controlled flow.



Figure 3: User demonstrating precise pouring from the gooseneck spout into a pour-over coffee maker.

1500W RAPID BOIL BOLI WATER IN 4 MINS

Spend Less Time Waiting And More Time Enjoying
Your Coffee Or Tea



Boil 1 Cup Of Water In 60 Sec.

Figure 4: Diagram illustrating the 1500W rapid boil feature, capable of boiling water in approximately 4 minutes, with a single cup boiling in 60 seconds.



Figure 5: Visual representation of the kettle's safety features, including auto shut-off, boil-dry protection, and overheating protection, which prolong service life.

MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your Anfilank Electric Gooseneck Kettle.

- **Exterior Cleaning:** Wipe the exterior of the kettle with a soft, damp cloth. Do not use abrasive cleaners or scouring pads as they may damage the finish.
- **Interior Cleaning (Descaling):** Over time, mineral deposits (limescale) may build up inside the kettle, especially in hard water areas.
 - a. Fill the kettle with a mixture of 1 part white vinegar and 2 parts water.
 - b. Boil the mixture and let it stand for at least 30 minutes, or longer for heavy buildup.
 - c. Empty the kettle and rinse thoroughly with fresh water several times.
 - d. For stubborn deposits, gently scrub the interior with a soft brush or sponge.
 - e. Alternatively, use a commercial descaling product designed for kettles, following the product's instructions.

- **Drying:** After each use, it is recommended to empty any remaining water and leave the lid open to allow the interior to air dry. This helps prevent limescale buildup and maintains cleanliness.
- **Storage:** When not in use, store the kettle in a dry place. You can wrap the power cord around the base for neat storage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Kettle does not turn on.	Not plugged in; power switch not engaged; no water in kettle.	Ensure kettle is properly plugged into a working outlet. Push the On/Off switch down firmly. Add water to the kettle (above MIN line).
Water not boiling.	Insufficient water; kettle not properly seated on base.	Ensure water level is above the MIN mark. Re-seat the kettle firmly on the power base.
Kettle turns off too quickly.	Limescale buildup; kettle was dry-boiled.	Descale the kettle as per maintenance instructions. If dry-boiled, allow to cool completely before refilling and restarting.
Unusual taste or odor in water.	New kettle odor; mineral deposits.	Perform initial cleaning steps (boil and discard water several times). Descale the kettle if mineral deposits are present.

SPECIFICATIONS

Brand: Anfilank

Model Name: JK-156A

Capacity: 1.0 Liter

Power: 1500W

Voltage: 120V / 60Hz

Material: 100% Stainless Steel (BPA Free)

Special Features: Automatic Shut-Off, Boil-Dry Protection, Overheating Protection

Product Dimensions: 10.31"L x 5.95"W x 8.27"H

Item Weight: 1.68 Pounds

Color: Green (This manual refers to the Green variant)

Country of Origin: China

WARRANTY AND SUPPORT

For warranty information or product support, please contact Anfilank customer service through the retailer where the product was purchased or visit the official Anfilank store online.

Online Store: [Anfilank Official Store](#)

Please have your model number (JK-156A) and purchase date available when contacting support.