

Fockety Focketyn4etomighw-12

Fockety A9 Mini Security Camera User Manual

Model: Focketyn4etomighw-12

1. PRODUCT OVERVIEW

1.1 Introduction

The Fockety A9 Mini Security Camera is a compact and versatile surveillance device designed for various indoor and outdoor monitoring needs. Featuring 1080P high-resolution video, night vision capabilities, and Wi-Fi connectivity, it allows for real-time monitoring via a smartphone application. Its magnetic back cover provides flexible placement options, making it ideal for use as a baby monitor, pet camera, or general security camera.

1.2 Package Contents

Please verify that all items listed below are present in your package:

- 1 x Fockety A9 Mini Camera
- 1 x USB Charging Cable
- 1 x Magnetic Stand
- 1 x Instruction Manual



Image: Contents of the Fockety A9 Mini Camera package, including the camera, USB charging cable, and magnetic stand.

1.3 Product Features

- **1080P High Resolution Lens:** Provides clear and detailed video recording.
- **Compact and Portable Design:** Small size allows for discreet placement in various locations.
- **Magnetic Back Cover:** Built-in magnet for easy attachment to ferrous surfaces.
- **Wi-Fi Connectivity:** Enables real-time remote viewing via a smartphone application.
- **Built-in Rechargeable Battery:** Offers up to 45 minutes of continuous operation without external power.
- **Night Vision:** Equipped for monitoring in low-light or no-light conditions.
- **Motion Detection:** Alerts for detected movement.
- **Micro SD Card Support:** Supports up to 128GB for local storage (card not included).



Image: The Fockety A9 Mini Camera highlighting its Wi-Fi capability and Micro SD card slot.

1.4 Component Identification

Familiarize yourself with the camera's components:



Image: A detailed view of the Fockety A9 Mini Camera, showing its lens and side buttons.

- **Lens:** Front-facing camera lens.
- **ON/OFF Button:** Power control.
- **MODE Button:** Switches between operating modes.
- **Micro USB Port:** For charging the camera.
- **Micro SD Card Slot:** For inserting a memory card.
- **Indicator Light:** Displays camera status.
- **Magnetic Back:** Allows attachment to magnetic surfaces or the included magnetic stand.



Image: Close-up of the Fockety A9 Mini Camera's top surface, showing the ON/OFF and MODE buttons.



Image: The Fockety A9 Mini Camera attached to its magnetic stand, with the Micro SD card slot visible.

2. SETUP

2.1 Charging the Device

Before first use, fully charge the camera. Connect the supplied USB charging cable to the camera's Micro USB port and the other end to a 5V 1A USB power adapter (not included). The indicator light will show charging status and turn off when fully charged. A full charge takes approximately 30 minutes.

2.2 Inserting a Memory Card

To enable video recording and storage, insert a Micro SD card (up to 128GB, not included) into the camera's Micro SD card slot. Ensure the card is inserted correctly until it clicks into place.



Image: The Micro SD card slot on the Fockety A9 Mini Camera, indicating where to insert the memory card.

2.3 App Installation and Connection

The camera connects to your smartphone via a dedicated application. Refer to the included instruction manual for the specific app name and QR code for download. Follow these general steps:

1. Download and install the recommended application on your Android or iOS smartphone.
2. Power on the camera by pressing the ON/OFF button.
3. Open the app and follow the on-screen instructions to add a new device.
4. Connect the camera to your home Wi-Fi network through the app. Ensure your Wi-Fi network is 2.4GHz, as 5GHz networks may not be supported.

5. Once connected, you can view the live feed and access camera settings.

3. OPERATING INSTRUCTIONS

3.1 Powering On/Off

- **To Power On:** Press and hold the **ON/OFF** button until the indicator light illuminates.
- **To Power Off:** Press and hold the **ON/OFF** button until the indicator light turns off.

3.2 Recording Video

Video recording can be initiated manually via the app or automatically based on settings like motion detection.

- **Manual Recording:** Open the app, access the live view, and tap the record button to start/stop recording.
- **Continuous Recording:** If a Micro SD card is inserted and configured, the camera can record continuously.

3.3 Night Vision

The camera is equipped with night vision for clear monitoring in low-light conditions. This feature typically activates automatically when ambient light levels drop.

3.4 Motion Detection

Configure motion detection settings within the smartphone application. When motion is detected, the camera can:

- Send push notifications to your smartphone.
- Start recording video clips to the Micro SD card or cloud storage (if available).

3.5 Remote Viewing

Once the camera is connected to your Wi-Fi network and linked to the app, you can view the live feed from anywhere with an internet connection on your smartphone.

4. MAINTENANCE

4.1 Cleaning

To maintain optimal performance, keep the camera lens clean. Use a soft, dry, lint-free cloth to gently wipe the lens. Avoid using liquid cleaners or abrasive materials that could scratch the lens or damage the camera's surface.

4.2 Storage

When not in use for extended periods, store the camera in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the battery is partially charged (around 50%) before storage to prolong its lifespan.

5. TROUBLESHOOTING

Problem	Possible Cause	Solution
Camera not turning on.	Low battery; faulty charging cable/adapter.	Charge the camera fully. Try a different USB cable and power adapter.
Cannot connect to Wi-Fi.	Incorrect Wi-Fi password; camera too far from router; 5GHz Wi-Fi network.	Ensure correct password. Move camera closer to router. Confirm your Wi-Fi is 2.4GHz. Reset camera and try again.
No video recording.	No Micro SD card; card full or corrupted; recording settings incorrect.	Insert a Micro SD card. Format the card via the app. Check recording settings in the app.
App shows "Offline".	Camera lost Wi-Fi connection; camera powered off.	Check camera power. Verify Wi-Fi signal strength. Reconnect camera to Wi-Fi via the app if necessary.
Poor image quality.	Dirty lens; insufficient lighting; network bandwidth issues.	Clean the camera lens. Ensure adequate lighting or check night vision settings. Check your internet connection speed.

6. SPECIFICATIONS

Model Name	Focketyn4etomighw-12
Brand	Fockety
Video Resolution	1080p
Connectivity Protocol	Wi-Fi (2.4GHz)
Control Method	App (Smartphone)
Compatible Devices	Smartphone (Android, iOS)
Battery Type	Built-in Lithium-ion Battery
Battery Capacity	240 mAh
Battery Life	Approx. 45 minutes (continuous video)
Charging Time	Approx. 30 minutes (0%-100%)
Charging Interface	Micro USB

Memory Expansion	Up to 128GB Micro SD Card (not included)
Video Capture Format	MP4
Compression Standard	H.264 Main, H.264 Baseline, MJPEF, JPEG Baseline
Alert Type	Motion Only
Indoor/Outdoor Usage	Indoor, Outdoor (IP54 rating)
Item Weight	62g / 2.19 ounces
Product Material	ABS

7. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the contact details provided on the product packaging or the official Fockety website. Keep your purchase receipt as proof of purchase for any warranty claims. For further assistance, you may also contact the seller directly through the platform where the product was purchased.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CJW5P9BF>

More documents and user manuals: <https://manuals.plus/>