

[Manuals.plus](#) /

› [Skullcandy](#) /

› Skullcandy Stomp Bluetooth Speaker User Manual

## Skullcandy 2SKSK185

# Skullcandy Stomp Bluetooth Speaker User Manual

Model: 2SKSK185 | Brand: Skullcandy

## 1. INTRODUCTION

---

Welcome to the user manual for your Skullcandy Stomp Bluetooth Speaker. The Stomp is a robust and portable wireless speaker designed to deliver powerful audio with added features like an LED lightshow, IPX7 waterproofing, and the ability to charge other devices. This manual provides essential information on setting up, operating, and maintaining your speaker to ensure optimal performance and longevity.



Figure 1: Skullcandy Stomp Bluetooth Speaker. This image shows the speaker from the front, highlighting its black finish and vibrant LED light strip around the grille.

## 2. WHAT'S IN THE BOX

---

Upon unboxing your Skullcandy Stomp, please ensure all the following items are present:

- Skullcandy Stomp Bluetooth Speaker
- USB-C Charging Cable

- User Manual (this document)




Figure 2: Key features of the Skullcandy Stomp speaker, including 12 hours of battery, Bluetooth 5.3, IPX7 waterproof rating, LED light show, and SKDY Multi-Link™ capability.

### 3. PRODUCT FEATURES

The Skullcandy Stomp Bluetooth Speaker is equipped with several advanced features for an enhanced audio experience:

- **Full-Frequency Audio:** Delivers rich mids, bright highs, and deep, punchy bass for a comprehensive sound profile.
- **IPX7 Waterproof Rating:** Designed to withstand full immersion in water up to 1 meter for 30 minutes, making it suitable for outdoor and poolside use.
- **Multi-Link Technology:** Connect up to 99 Skullcandy Bluetooth speakers for a synchronized, expansive audio system.
- **12-Hour Battery Life:** Provides extended playtime on a single charge, ensuring your music lasts through events.

- **USB-C & USB-A Output Charging:** Use the speaker's battery to charge your mobile devices on the go.
- **LED Lightshow & Strobe Modes:** Integrated lights that sync with your music, adding a visual element to your listening experience.
- **Integrated Carry Handle:** Designed for easy portability and transport.



Figure 3: The Skullcandy Stomp speaker demonstrating its IPX7 water resistance, suitable for use in wet environments.

# IPX7

## WATER RESISTANT

From rainy day jams to splashy poolside grooves,  
never skip a beat



Figure 4: The Skullcandy Stomp speaker's charge-out capability, showing a smartphone being charged from the speaker's USB-A port.

## 4. SETUP GUIDE

### 4.1 Charging the Speaker

Before first use, fully charge your Skullcandy Stomp speaker. A full charge takes approximately 3-4 hours.

1. Locate the USB-C charging port on the back of the speaker, usually protected by a waterproof flap.
2. Open the flap and insert the provided USB-C cable into the speaker's charging port.
3. Connect the other end of the USB-C cable to a compatible USB power adapter (not included) or a computer's USB port.
4. The LED indicator will show charging status (e.g., solid red for charging, off or green for fully charged).

### 4.2 Powering On/Off

- **To Power On:** Press and hold the Power button (usually marked with a power symbol) located on the top panel of the speaker for 2-3 seconds. You will hear an audible tone, and the LED lights will illuminate.

- **To Power Off:** Press and hold the Power button again for 2-3 seconds. You will hear a power-off tone, and the LED lights will turn off.

## 4.3 Bluetooth Pairing

Pair your Skullcandy Stomp with your Bluetooth-enabled device (smartphone, tablet, etc.) to stream audio wirelessly.

1. Ensure the speaker is powered on and within 1 meter (3 feet) of your device.
2. The speaker will automatically enter Bluetooth pairing mode when powered on for the first time, indicated by a flashing blue LED. If it has been paired before, it will attempt to reconnect to the last device. To force pairing mode, press and hold the Bluetooth button (if available) or the power button until the LED flashes rapidly.
3. On your device, go to Bluetooth settings and enable Bluetooth.
4. Search for available devices. You should see "Skullcandy Stomp" in the list.
5. Select "Skullcandy Stomp" to connect. Once connected, the LED indicator will turn solid blue, and you will hear a confirmation tone.

*Note: The speaker will automatically power off after a period of inactivity if not connected to a device.*

## 5. OPERATING YOUR SPEAKER

---

### 5.1 Basic Controls

The Skullcandy Stomp features intuitive controls located on its top panel. Refer to Figure 5 for button layout.

# MULTI LINK™

LINK UP TO 99 SPEAKERS

Seamless synchronization for an immersive  
and customizable audio experience



Figure 5: Top panel controls of the Skullcandy Stomp speaker, including power, volume, play/pause, and light mode buttons.

**Table 1: Control Button Functions**

Button/Indicator	Function
<b>Power Button</b> (Power Symbol)	Press and hold for 2-3 seconds to Power On/Off.
<b>Volume Down (-)</b>	Press to decrease volume. Press and hold to skip to previous track.
<b>Play/Pause Button</b> (Triangle/Two Vertical Bars)	Press to Play/Pause audio. Press twice for next track.
<b>Volume Up (+)</b>	Press to increase volume. Press and hold to skip to next track.
<b>Light Mode Button</b> (Sun/Lightbulb Symbol)	Press to cycle through LED lightshow modes. Press and hold to turn lights On/Off.
<b>Multi-Link Button</b> (Chain Link Symbol)	Press to initiate Multi-Link pairing with other Skullcandy speakers.

## 5.2 Multi-Link Function

The Multi-Link feature allows you to connect up to 99 Skullcandy Stomp (and compatible Skullcandy) speakers for a larger, synchronized audio experience.

1. Ensure all speakers you wish to link are powered on and not currently paired with any device.
2. Pair your primary Skullcandy Stomp speaker with your Bluetooth device as described in Section 4.3. This will be your "Host" speaker.
3. On the Host speaker, press the **Multi-Link Button** (chain link symbol). The LED will flash, indicating it's searching for other speakers.
4. On each additional Skullcandy speaker you want to link, press the **Multi-Link Button**. They will enter search mode.
5. The speakers will automatically connect to the Host speaker. Once connected, their LEDs will synchronize, and audio will play across all linked speakers.
6. To disconnect a speaker from the Multi-Link chain, press its Multi-Link button again.



Figure 6: Two Skullcandy Stomp speakers demonstrating the Multi-Link feature, allowing them to play audio synchronously.

## 5.3 LED Lightshow Modes

The Skullcandy Stomp features dynamic LED lights that can enhance your listening experience.

- Press the **Light Mode Button** (sun/lightbulb symbol) to cycle through various light patterns and colors.
- Some modes may react to the beat of the music, while others are static or cycle through colors.
- Press and hold the **Light Mode Button** to turn the LED lights off or on.

## 5.4 USB Charge Out

Utilize your Skullcandy Stomp as a portable power bank to charge your mobile devices.

1. Locate the USB-A output port on the back of the speaker, next to the USB-C charging port.
2. Connect your device's charging cable (USB-A end) to the speaker's USB-A output port.
3. Connect the other end of the cable to your smartphone, tablet, or other compatible device.
4. Charging will begin automatically. The speaker must be powered on for this function to work.

## 6. CARE AND MAINTENANCE

Proper care ensures the longevity and performance of your Skullcandy Stomp speaker.

- **Cleaning:** Wipe the speaker with a soft, damp cloth. Do not use harsh chemicals, cleaning solvents, or strong detergents.
- **Water Resistance:** While IPX7 rated, ensure the charging port flap is securely closed before exposing the speaker to water. Do not intentionally submerge the speaker for extended periods or beyond specified depths. After exposure to water, dry the speaker thoroughly before charging.
- **Storage:** Store the speaker in a cool, dry place away from extreme temperatures and direct sunlight.
- **Battery Care:** To preserve battery life, avoid fully discharging the speaker frequently. Charge it regularly, even if not in use for extended periods.
- **Avoid Impacts:** Do not drop or subject the speaker to strong impacts, as this can damage internal components.

## 7. TROUBLESHOOTING

If you encounter issues with your Skullcandy Stomp speaker, refer to the table below for common problems and solutions.

**Table 2: Common Troubleshooting Steps**

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker using the provided USB-C cable.
Cannot pair with Bluetooth device.	Speaker not in pairing mode; device Bluetooth off; previously paired device interfering.	Ensure speaker is in pairing mode (flashing blue LED). Turn Bluetooth off/on on your device. Forget "Skullcandy Stomp" from your device's Bluetooth list and try pairing again. Ensure no other devices are connected to the speaker.

Problem	Possible Cause	Solution
No sound or low volume.	Volume too low on speaker or device; speaker not connected; audio source issue.	Increase volume on both the speaker and your connected device. Verify Bluetooth connection. Try playing audio from a different app or source.
Multi-Link not working.	Speakers not in Multi-Link pairing mode; too far apart; incompatible models.	Ensure all speakers are in Multi-Link pairing mode. Keep speakers within close proximity during pairing. Confirm all speakers are Skullcandy Stomp or compatible Multi-Link models.
LED lights not working.	Lights turned off; speaker malfunction.	Press the Light Mode button to cycle modes. Press and hold the Light Mode button to turn lights on. If still not working, contact support.

## 8. TECHNICAL SPECIFICATIONS

Detailed specifications for the Skullcandy Stomp Bluetooth Speaker:

**Table 3: Product Specifications**

Feature	Detail
Model Name	2SKSK185
Connectivity Technology	Bluetooth 5.3, Wireless
Water Resistance Level	IPX7 Waterproof
Battery Life	Up to 12 Hours
Power Source	Battery Powered (1 Lithium Ion battery included)
Speaker Maximum Output Power	120 Watts
Frequency Response	650 Hz (Note: This seems like a typo in the source data, typically a range is provided, e.g., 65Hz-20kHz. Using as provided.)
Product Dimensions	20"D x 10"W x 12"H
Item Weight	13.79 pounds
Audio Driver Type	Dynamic Driver
Woofer Diameter	5.25 Inches
Tweeter Diameter	2.25 Inches
Bluetooth Range	10 Meters
UPC	812350262621

## 9. WARRANTY AND SUPPORT

Skullcandy products are built to last, and the Stomp speaker comes with a limited warranty against manufacturing

defects. Please refer to the official Skullcandy website for the most current and detailed warranty information, as terms and conditions may vary.

For technical support, warranty claims, or general inquiries, please visit the Skullcandy support page or contact their customer service directly. Keep your proof of purchase for warranty validation.

**Online Support:** [www.skullcandy.com/support](http://www.skullcandy.com/support)

**Skullcandy Store:** [Visit the Skullcandy Store on Amazon](#)

© 2024 Skullcandy. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.