DJI CP.RN.00000330.01

DJI Mic 2 Charging Case Instruction Manual

Brand: DJI

Model: CP.RN.00000330.01

1. Introduction

The DJI Mic 2 Charging Case is an essential accessory designed to enhance the usability and longevity of your DJI Mic 2 wireless microphone system. It serves multiple functions, including charging, storage, and automatic linking of your devices.

This case efficiently links the receiver (RX) and transmitters (TXs) and charges them, providing up to 18 hours of total operating time. It also offers a secure and organized storage solution for your transmitters, receiver, and mobile phone adapters (USB-C and Lightning).

Compatibility: This charging case is exclusively compatible with the DJI Mic 2 system.



Figure 1: The DJI Mic 2 Charging Case with its lid open, revealing the precisely molded compartments for the microphone components.

2. What's in the Box

Upon opening your DJI Mic 2 Charging Case package, you should find the following items:

- DJI Mic 2 Charging Case × 1
- DJI Mic 2 Carrying Bag × 1

3. Setup

Setting up your DJI Mic 2 system with the charging case is straightforward, designed for quick deployment.

3.1 Placing Components

Carefully place your DJI Mic 2 transmitters and receiver into their designated slots within the charging case. The compartments are shaped to fit each component securely.

3.2 Automatic Linking

One of the key features of the DJI Mic 2 Charging Case is its automatic linking capability. When the receiver and transmitters are placed inside the case and the lid is closed, they will automatically link with each other. This ensures that your devices are ready for use as soon as you open the case, saving time during setup.



Figure 2: The DJI Mic 2 Charging Case with the receiver and two transmitters securely seated in their respective charging and storage slots.

4. Operating the Charging Case

The charging case is designed for seamless integration into your workflow, providing power and organization.

4.1 Charging Functionality

The primary function of the case is to charge your DJI Mic 2 components. When the transmitters and receiver are placed inside, they begin charging automatically. The case itself has an internal battery that can extend the operating time of your DJI Mic 2 system up to 18 hours.

4.2 Battery Indicators

The front of the charging case features LED indicators that display the current battery level of the case. These lights illuminate to show charging progress and remaining power, allowing you to monitor the case's status at a glance.



Figure 3: Top-down view of the closed DJI Mic 2 Charging Case, highlighting the four LED battery indicators.

4.3 Adapter Storage

The case includes dedicated slots for storing the mobile phone adapters (USB-C and Lightning). This ensures that all necessary components for connecting your receiver to various devices are kept together and easily accessible.



Figure 4: Side view of the DJI Mic 2 Charging Case, illustrating the USB-C port for charging the case itself.



Figure 5: A user demonstrating the compact size and portability of the DJI Mic 2 Charging Case, holding a transmitter next to the open case.

5. Maintenance

To ensure the longevity and optimal performance of your DJI Mic 2 Charging Case, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the exterior of the case. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the case in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Handle the case with care to prevent drops or impacts that could damage the internal components or charging contacts.

6. Troubleshooting

If you encounter issues with your DJI Mic 2 Charging Case, consider the following common troubleshooting steps:

6.1 Devices Not Charging

- Ensure the transmitters and receiver are correctly seated in their respective slots.
- Verify that the charging case itself has sufficient battery power (check LED indicators).
- If charging the case, ensure the USB-C cable and power adapter are functioning correctly and securely connected.

6.2 Devices Not Linking Automatically

- Confirm that all devices (transmitters and receiver) are placed inside the charging case.
- Ensure the case lid is fully closed.
- If issues persist, try removing and re-inserting the devices into the case.

7. Specifications

Feature	Detail
Product Dimensions	4.72 x 2.36 x 1.97 inches
Item Weight	5.3 ounces
Item Model Number	CP.RN.00000330.01
Batteries	1 Lithium Ion batteries required (included)
Manufacturer	DJI
Country of Origin	China

8. Warranty and Support

For detailed warranty information, technical support, and service inquiries regarding your DJI Mic 2 Charging Case, please refer to the official DJI website or contact DJI customer service directly. Keep your proof of purchase for warranty claims.

Note: This manual provides general instructions. For the most up-to-date information and comprehensive support, always consult the official DJI resources.