

**MISINI C66015w**

# Instruction Manual

## MISINI JAPANESE KITTY'S GROCERY BUILDING BLOCK SET

Model: C66015W

### 1. Product Overview

The MISINI Japanese Kitty's Grocery Building Block Set (Model C66015W) is a detailed modular building block model designed for teenagers and adults. This set, part of the CADA Street View Series, allows for the construction of a charming Japanese-style grocery store, featuring intricate exterior and interior details. Comprising 921 high-quality, environmentally friendly ABS parts, the set offers an engaging and rewarding building experience. It also includes a lighting kit to illuminate the completed structure, enhancing its display appeal.



Image: The complete MISINI Japanese Kitty's Grocery Building Block Set, showcasing the assembled model alongside its packaging.

## 2. Safety Information

**Warning: Not suitable for children under 6 years old due to small parts which may pose a choking hazard.**

Always ensure assembly is performed under adult supervision for younger builders. Keep all packaging materials away from children.

## 3. What's in the Box

Your MISINI Japanese Kitty's Grocery Building Block Set includes:

- 921 high-quality building block parts.
- 1 USB-powered lighting kit.
- 1 detailed instruction manual with color images and text.

## 4. Setup and Assembly

Follow the step-by-step instructions provided in the included manual for assembly. The parts are designed for easy installation and fit well together, ensuring a smooth building process.

### Assembly Tips:

- Sort pieces by color and type before beginning to streamline the process.
- Refer to the color images in the manual for clear guidance on each step.
- Ensure each part is firmly connected to prevent the structure from loosening.

This modular set can be combined with other CADA Street View Series models (C66007W, C66006W, C66010W, and C66014W) to create a larger Japanese street view city. Ensure proper alignment when connecting multiple modules.

## Attention to the exterior and interior



Image: A detailed view highlighting the attention to both exterior and interior design of the building block set.



## Opening side wall

Image: The building block set with its side wall opened, providing a clear view of the detailed interior layout and accessories.

### 5. Operating the Lighting Kit

The set includes a USB-powered lighting kit to bring your grocery store to life. Follow these steps to operate the lights:

1. Locate the USB cable integrated with the lighting kit.
2. Connect the USB cable to any standard USB power source (e.g., a USB wall adapter, power bank, or computer USB port).
3. Once connected, the lights will turn on. The lighting kit supports 8 different lighting effects, which can typically be cycled through by pressing a button on the USB connector or a designated switch on the model (refer to the specific instructions in your manual for exact control).

CaDA®

USB with 8 different  
lighting effects



Image: The USB light group component, which powers the internal illumination of the building set.

**CaDA®**

**USB with 8 different  
lighting effects**



Image: The building block set illuminated at night, showcasing the effect of the integrated lighting kit.

Your browser does not support the video tag.

Video: An official product video demonstrating the features of the Japanese Kitty's Grocery building set, including its modular design and lighting effects.

## 6. Maintenance

To keep your building block set in optimal condition:

- **Cleaning:** Use a soft, dry cloth to gently wipe away dust. For stubborn dirt, a slightly damp cloth can be used, but ensure no water enters the electrical components of the lighting kit.
- **Storage:** Store the set in a cool, dry place away from direct sunlight to prevent discoloration or warping of the plastic parts.
- **Handling:** Handle the assembled model with care to avoid accidental disassembly.

## 7. Troubleshooting

### Missing Pieces:

While rare, if you encounter any missing parts during assembly, please contact MISINI customer support

immediately. Provide details of the missing parts (e.g., part number from the manual, description, and quantity) to facilitate a quick resolution.

### **Lights Not Working:**

- Ensure the USB cable is securely connected to both the lighting kit and the power source.
- Try a different USB power source to rule out issues with the original one.
- Check for any visible damage to the USB cable or the lighting components.

For any other issues not covered here, please refer to the "Warranty and Support" section.

## **8. Specifications**

<b>Brand:</b>	MISINI
<b>Model Number:</b>	C66015W
<b>Number of Pieces:</b>	921
<b>Finished Product Dimensions:</b>	8.19 x 8.19 x 7.87 inches (20.8 x 20.8 x 20 cm)
<b>Item Weight:</b>	3.25 pounds
<b>Recommended Age:</b>	14 years and up
<b>Material:</b>	High-quality environmentally friendly ABS
<b>Lighting:</b>	USB-powered lighting kit with 8 effects



Image: A diagram illustrating the dimensions of the assembled building block set.

## 9. Warranty and Support

For any questions, concerns, or issues regarding your MISINI Japanese Kitty's Grocery Building Block Set, please contact the manufacturer or seller directly. They are committed to providing support and resolving any problems you may encounter during assembly or use.

You can often find contact information on the product packaging or through the retailer's website where you purchased the item. For more information about MISINI products, visit the official [MISINI Store on Amazon](#).