

[Manuals.plus](#) /

› [TRIUMPHKEY](#) /

› TRIUMPHKEY Electric Height Adjustable Standing Desk User Manual

TRIUMPHKEY 0162

TRIUMPHKEY Electric Height Adjustable Standing Desk User Manual

Model: 0162

PRODUCT OVERVIEW

The TRIUMPHKEY Electric Height Adjustable Standing Desk is designed to enhance your workspace comfort and productivity. It features an electric motor for smooth height transitions, allowing you to effortlessly switch between sitting and standing positions. The desk includes a smart memory panel for saving preferred heights, a multi-functional monitor stand, and integrated cable management solutions.



Image: The TRIUMPHKEY Electric Height Adjustable Standing Desk in a typical office setup, showcasing its spacious desktop and integrated monitor shelf.


Key Features:

- **Adjustable Height:** Electrically adjustable from 72 cm to 117 cm, suitable for various user heights and preferences.
- **Smart Memory Panel:** Two preset height functions for quick adjustments.
- **Multi-functional Monitor Stand:** Ergonomically designed, can also be used as an open storage cube.
- **Robust Construction:** Industrial-grade steel frame supports up to 60 kg (including desktop).
- **Quiet Operation:** Motor operates at less than 55dB, ensuring a peaceful work environment.
- **Cable Management:** Integrated cable holes for a tidy workspace.
- **Headphone Hook:** Conveniently located for easy access.

SETUP AND ASSEMBLY

The TRIUMPHKEY Electric Standing Desk is designed for straightforward assembly. All necessary parts are numbered, and clear instructions are provided to guide you through the process. Typical assembly time is approximately 30 minutes.


Leicht zu installieren



**Klare
Anweisungen**



**Video zur
Installation**



**30 Minuten
zum Einrichten**

Image: An exploded view of the desk components, illustrating the assembly process and highlighting the estimated 30-minute setup time.

Assembly Steps:

1. Unpack all components and verify against the parts list in the instruction manual.
2. Assemble the desk frame according to the provided diagrams, ensuring all screws are securely fastened.
3. Attach the desktop sections to the assembled frame.
4. Install the electric motor and control panel, connecting all necessary cables.
5. Attach the monitor stand and any other accessories like the headphone hook.
6. Plug the desk into a power outlet and test the height adjustment functions.

For visual guidance, an installation video is available, as indicated in the assembly instructions.

OPERATING INSTRUCTIONS

The TRIUMPHKEY Electric Standing Desk features an intuitive control panel for easy height adjustment and memory functions.

Intelligentes Multifunktions-Steuergerät

Steuern Sie, was Sie wollen




Image: Detailed view of the intelligent multifunction control unit, showing the LED display and control buttons.

Height Adjustment:

- Use the **Up** (▲) and **Down** (▼) arrows on the control panel to raise or lower the desk to your desired height. The current height will be displayed on the LED screen.
- The desk can be adjusted between 72 cm (sitting height) and 117 cm (standing height).

Memory Presets:

The desk allows you to save two preferred height settings for quick recall.

1. Adjust the desk to your desired height using the Up/Down arrows.
2. Press the '**M**' button (or equivalent memory set button, if present) followed by either '**1**' or '**2**' to save the current height to that preset.
3. To recall a saved height, simply press the corresponding '**1**' or '**2**' button. The desk will automatically move to the saved position.

Child Lock Function:

To prevent accidental adjustments, the control panel may feature a child lock. Consult your specific control panel instructions for activation and deactivation procedures. Typically, this involves pressing and holding a specific button combination for a few seconds.



Image: Visual representation of the desk's quiet operation, demonstrating noise levels below 55dB.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your TRIUMPHKEY standing desk.

- **Cleaning:** Wipe the desktop and frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Cable Management:** Periodically check that all cables are neatly organized and not pinched or tangled. Utilize the integrated cable holes to maintain a clean setup.
- **Motor and Connections:** Ensure the power cord is securely plugged into both the desk and the wall outlet. Avoid placing excessive weight on the desk beyond its 60 kg capacity.
- **Adjustable Feet:** Verify that the adjustable feet are stable and level, especially if the desk is moved.

Stabileres **Anheben und Absenken**



Image: Close-up views of the desk's cable management holes, adjustable feet, and headphone hook, illustrating key areas for maintenance checks.

TROUBLESHOOTING

If you encounter any issues with your TRIUMPHKEY standing desk, refer to the following common troubleshooting steps:

- **Desk Not Moving:**

- Check if the power cord is securely connected to both the desk and a working power outlet.
- Ensure the child lock function is not activated.
- If an error code is displayed on the control panel, consult the full manual for specific error definitions.

- **Uneven Movement/Wobbling:**

- Verify that the desk is placed on a flat, level surface.
- Adjust the leveling feet at the bottom of the desk legs to ensure stability.
- Check that all assembly screws are tightened.

- **Unusual Noises:**

- Ensure no objects are obstructing the desk's movement or are caught in the lifting mechanism.
- If the noise persists and is significant, contact customer support.

For issues not covered here, or if troubleshooting steps do not resolve the problem, please contact TRIUMPHKEY customer support.

SPECIFICATIONS

Produkt **Abmessungen**



Image: Product dimensions and weight capacity diagram.

Attribute	Detail
Brand	TRIUMPHKEY
Model Number	0162

Color	Rustic Brown
Product Dimensions (L x W x H)	120 x 60 x 72-117 cm (adjustable)
Material	Engineered Wood, Alloy Steel
Item Weight	23.5 Kilograms
Maximum Load Capacity	60 kg (including desktop)
Special Features	Storage Shelf, Ergonomic, Height Adjustable, Electric, Monitor Shelves
Country of Origin	China

WARRANTY AND SUPPORT

For information regarding product warranty, please refer to the documentation included with your purchase or contact the seller directly. TRIUMPHKEY is committed to providing quality products and customer satisfaction.

If you require technical assistance, have questions about assembly, operation, or maintenance, or need to report a defect, please reach out to TRIUMPHKEY customer support through the retailer where you purchased the product. Please have your model number (0162) and purchase details ready when contacting support.

© 2024 TRIUMPHKEY. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question