Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Briloner 7485013

BRILONER Dimmable LED Bottle Lamp User Manual

Model: 7485013

Brand: Briloner

1. Introduction and Overview

The BRILONER Dimmable LED Bottle Lamp is a versatile, wireless lighting solution designed to transform various bottles, such as champagne or wine bottles, into elegant and functional lamps. Featuring touch-sensitive dimming and a warm white light, it is suitable for both indoor and outdoor use, providing ambient illumination for various settings.



Figure 1: BRILONER Dimmable LED Bottle Lamp on a bottle.

2. Safety Instructions

- Ensure the lamp is used with bottles that have a spout diameter of **max. 3.15 cm (1.24 inches)** to ensure proper fit and stability. The bottle is not included with the lamp.
- Do not submerge the lamp in water. While it has an **IP44 splash protection rating**, it is not waterproof and should not be immersed.
- Use only the provided USB-C cable for charging. Using incompatible chargers may damage the battery or the lamp.
- Do not attempt to disassemble or modify the lamp. This may void the warranty and pose a safety risk.
- Keep the lamp out of reach of children and pets.
- Avoid exposing the lamp to extreme temperatures or direct sunlight for prolonged periods.

3. Package Contents

Please check the package contents to ensure all items are present:

- 1x BRILONER Dimmable LED Bottle Lamp (Copper Matte)
- 1x USB-C Charging Cable

4. Setup

1. **Initial Charge:** Before first use, it is recommended to fully charge the lamp. Refer to the "Charging" section for details.
2. **Bottle Selection:** Choose a suitable bottle (e.g., wine, champagne) with a spout diameter of no more than 3.15 cm (1.24 inches).
3. **Placement:** Gently insert the lamp unit onto the neck of the selected bottle. Ensure it sits securely and stably.



Figure 2: Lamp features including integrated battery, warm white light, touch dimmer, and IP44 rating.

5. Operating Instructions

The BRILONER Bottle Lamp features intuitive touch control for power and brightness adjustment.

- **Power ON/OFF:** To turn the lamp **ON** or **OFF**, gently touch the power symbol located on the top surface of the lamp.
- **Dimming Function:** To adjust the brightness, touch the power symbol repeatedly. The lamp cycles through three dimming levels:
  - First touch: 100% brightness
  - Second touch: 50% brightness
  - Third touch: 15% brightness
  - Fourth touch: Turns the lamp OFF



Figure 3: Illustration of the 3-step dimming function via touch.

6. Charging

The lamp is equipped with an integrated rechargeable Lithium-ion battery.

- **Charging Port:** Locate the USB-C charging port on the underside of the lamp.
- **Connection:** Connect the provided USB-C cable to the lamp's charging port and the other end to a compatible USB power source (e.g., computer USB port, USB wall adapter, power bank).
- **Charging Time:** A full charge typically takes approximately **7 hours**.
- **Battery Life:** On a full charge, the lamp can provide illumination for up to **24 hours**. Actual battery life may vary depending on the selected brightness level and usage patterns.



Figure 4: USB-C charging port and cable connection.

7. Maintenance

- **Cleaning:** To clean the lamp, gently wipe its surface with a soft, dry, or slightly damp cloth. Do not use harsh chemicals, abrasive cleaners, or solvents, as these can damage the finish.
- **Storage:** When not in use for extended periods, store the lamp in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid completely draining the battery frequently. Recharge the lamp when the light becomes dim.

8. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Lamp does not turn on.	Battery is depleted or low. Incorrect touch operation.	Charge the lamp fully for 7 hours. Ensure you are touching the power symbol on the top surface correctly.
Lamp does not hold charge for long.	Insufficient charging time. Battery degradation.	Ensure the lamp is charged for the full 7 hours. If the issue persists after a full charge, the battery may be degrading; contact customer support.
Light is dim or flickering.	Low battery.	Recharge the lamp fully.
Lamp does not fit on bottle.	Bottle spout diameter is too large.	Use a bottle with a spout diameter of max. 3.15 cm (1.24 inches).

9. Specifications

Feature	Detail
Brand	Briloner
Model Number	7485013
Dimensions (Diameter x Height)	11 x 9 cm (4.33 x 3.54 inches)
Weight	297 g (0.65 lbs)
Material	Metal
Color	Copper Matte
Light Source	Integrated LED
Color Temperature	3000K Warm White
Luminous Flux	280 lm
Power Consumption	2.6 Watts
Battery Type	1 Lithium-ion (included)
Charging Time	Approx. 7 hours
Operating Time	Up to 24 hours (depending on brightness level)
Protection Rating	IP44 (splash-proof)
Voltage	3 Volts (DC)
Special Features	Dimmable (3 levels via touch control)
Energy Efficiency Class	F




Figure 5: Dimensions of the BRILONER Dimmable LED Bottle Lamp.

© 2025 Briloner. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CJYFSD8N

More documents and user manuals: **https://manuals.plus/**