

VanAcc TV Stand70in

VanAcc 70-inch Fireplace TV Stand with 36-inch Electric Fireplace User Manual

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your VanAcc 70-inch Fireplace TV Stand with 36-inch Electric Fireplace. Please read all instructions carefully before assembly and use to ensure safe and proper functionality.

SAFETY INFORMATION


Important Safety Precautions:

- Always secure the TV stand to the wall to prevent tip-over. Use appropriate wall anchoring hardware (not included).
- Be cautious of sharp edges during assembly and handling.
- Keep small parts out of reach of children to prevent choking hazards.
- Ensure all electrical connections for the fireplace are properly installed and meet local electrical codes.
- Do not overload electrical outlets.
- The electric fireplace is CTL-certified and equipped with an automatic overheating cutoff system. Do not block air vents.
- Unplug the fireplace from the power outlet before cleaning or performing any maintenance.

PACKAGE CONTENTS

Your VanAcc Fireplace TV Stand will be delivered in two separate packages (Box #1 and Box #2), which may arrive on different days. Please verify that all parts are intact and accounted for upon receipt of both boxes.

PRODUCT SIZE



The item will be delivered in 2 Packages and may NOT arrived on same day



Image: Illustration showing two packages, Box A and Box B, for the TV stand and fireplace components. Refer to the included assembly diagram for a complete list of parts and hardware.

ASSEMBLY INSTRUCTIONS

Assembly typically requires two people and may take approximately 2-3 hours. A power drill can expedite the process. Follow the numbered steps in the provided assembly diagram carefully.

- 1. Unpack and Identify Parts:** Carefully unpack all components from both boxes. Lay them out on a clean, soft surface to prevent scratches. Identify each part using the provided parts list and diagrams.
- 2. Assemble the Main Frame:** Begin by connecting the main panels of the TV stand. Ensure all cam locks and dowels are securely fastened.
- 3. Install Adjustable Shelves:** Insert the shelf pins into the desired holes within the cabinet sections, then place the adjustable shelves on top.
- 4. Attach Cabinet Doors:** Mount the cabinet doors using the provided hinges. Adjust hinges as necessary to ensure doors are level and close properly.
- 5. Install Adjustable Legs:** Screw the adjustable table legs into the designated positions on the bottom of the TV stand. Adjust their height to ensure stability.

6. **Integrate the Electric Fireplace:** Carefully slide the 36-inch electric fireplace into its designated opening in the center of the TV stand. Ensure it is flush and secure.
7. **Connect LED Lights:** Attach the LED light strip according to the diagram. Ensure the power cord for the LED lights is routed neatly and securely to prevent it from hanging.
8. **Final Placement and Securing:** Position the assembled TV stand in its desired location. Secure the stand to the wall using appropriate anti-tip hardware (not included) to prevent accidental tipping.



Image: Product dimensions and weight capacity diagram.



Adjustable Table Legs

Adjustable Partition




Image: Details of adjustable features including legs and internal shelving.

OPERATING INSTRUCTIONS

Electric Fireplace Operation

The electric fireplace can be controlled via the responsive remote control or the intuitive touchscreen interface located on the unit.

AMPLE STORAGE SPACE

W/ Adjustable Shelf



Image: Fireplace controls and features, including remote and touchscreen.

- **Power On/Off:** Press the power button on the remote or touchscreen to turn the fireplace on or off.
- **Flame Colors:** Select from 8 different flame colors with a fire gradient effect. Use the flame color button to cycle through options.
- **Flame Brightness:** Adjust the flame brightness across 5 levels using the brightness control button.
- **Heating Function:** The fireplace offers dual heating options (750W/1500W) with a maximum output of 4800 BTU. Press the heat button to activate and select the desired wattage. The temperature can be adjusted between 62-82°F.
- **Timer:** Set a timer for 1-8 hours using the timer button for automatic shut-off.
- **Overheat Protection:** The unit is equipped with an automatic overheating cutoff system for safety. If the unit overheats, it will shut down automatically. Unplug and allow it to cool for 15-20 minutes before restarting.




Image: Examples of the 8 different flame colors.

LED Lights Operation

The LED light strip under the TV stand features 12 adjustable colors.



Image: TV stand with blue LED lighting activated.

- **Color Selection:** Use the dedicated LED light control on the remote or touchscreen to cycle through the 12 available colors.
- **Brightness Adjustment:** Adjust the brightness of the LED lights to your preference.



Image: Examples of the 12 different LED light colors.

MAINTENANCE

- **Cleaning:** Unplug the unit before cleaning. Use a soft, damp cloth to wipe down surfaces. Avoid abrasive cleaners or solvents that may damage the high-gloss finish.
- **Dusting:** Regularly dust the unit to prevent accumulation, especially around the fireplace vents.
- **Inspection:** Periodically check all connections and hardware to ensure they remain tight and secure.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Fireplace does not turn on.	Not plugged in; power switch off; circuit breaker tripped; overheat protection activated.	Ensure unit is securely plugged into a working outlet. Check the main power switch. Reset the circuit breaker if tripped. If overheat protection activated, unplug and allow to cool for 15-20 minutes before restarting.
No heat output.	Heating function not activated; low wattage setting; air vents blocked.	Ensure heating function is turned on and set to desired wattage (750W/1500W). Check that air intake and exhaust vents are clear of obstructions.
LED lights not working or flickering.	Loose connection; power issue.	Check all LED light strip connections. Ensure the power adapter for the LED lights is securely plugged in.
Cabinet doors are not level.	Hinges require adjustment.	Adjust the screws on the hinges to align the doors. Refer to the assembly diagram for hinge adjustment details.
Unit feels unstable.	Legs not properly adjusted; unit not secured to wall.	Ensure all adjustable legs are firmly on the ground and adjusted for even support. Secure the TV stand to the wall using anti-tip hardware.

SPECIFICATIONS

- **Brand:** VanAcc
- **Model Number:** TV Stand70in
- **Material:** High Gloss Engineered Wood
- **Product Dimensions:** 70 x 15.8 x 24 inches (L x W x H)
- **Item Weight:** 117 pounds
- **Fireplace Size:** 36 inches

- **Maximum TV Size Supported:** Up to 80 inches
- **Maximum Weight Capacity:** 250 lbs
- **Fireplace Heating Options:** 750W/1500W
- **Fireplace BTU Output:** 4800 BTU
- **Fireplace Temperature Control:** 62-82°F
- **Flame Colors:** 8 options with gradient effect
- **Flame Brightness:** 5 levels
- **LED Light Colors:** 12 options
- **Safety Certification:** CTL-certified electric fireplace with automatic overheating cutoff system.




WARRANTY AND SUPPORT




For warranty information or technical support, please contact VanAcc customer service. Refer to your purchase documentation for specific contact details or visit the official VanAcc website.

Online Resources: [Visit the VanAcc Store on Amazon](#)

© 2023 VanAcc. All rights reserved.

Related Documents - TV Stand70in

<div><p>SLEEPER SOFA Assembly Instruction</p><p>NOTE: Cushions and foam included with this sofa. Please do not remove them at any time.</p><p>WARNING: Do not use this sofa as a bed. It is not designed for use as a bed. Use of this sofa as a bed may result in injury or damage.</p></div>	<p>VanAcc Sleeper Sofa Assembly Instructions</p> <p>Comprehensive assembly instructions for the VanAcc Sleeper Sofa, detailing the process for both the chaise and two-seat configurations, including parts lists and step-by-step guidance.</p>
<div><p>CONTEMPORARY SOFA Assembly Instruction</p><p>NOTE: Cushions and foam included with this sofa. Please do not remove them at any time.</p><p>WARNING: Do not use this sofa as a bed. It is not designed for use as a bed. Use of this sofa as a bed may result in injury or damage.</p></div>	<p>Contemporary Sofa Assembly and Care Guide</p> <p>Comprehensive guide for assembling your contemporary sofa, including detailed parts identification, step-by-step instructions, and cushion care tips. Features information on restoring vacuum-packed cushions and ensuring proper assembly with included hardware.</p>
<div><p>Avenue Fireplace Entertainment Center</p><p>BELLEZE</p><p>FEATURES: • 70" Wide • 15" Deep • 36" High • 1500W Electric Fireplace • LED Light Bar • Remote Control • 2x6" Solid Wood Frame • 1x6" Solid Wood Top • 1x6" Solid Wood Base • 1x6" Solid Wood Sides • 1x6" Solid Wood Back • 1x6" Solid Wood Legs</p></div>	<p>Avenue Fireplace Entertainment Center Assembly Instructions</p> <p>Assembly and care guide for the BELLEZE Avenue Fireplace Entertainment Center, including parts list, assembly steps, and maintenance recommendations.</p>

<p>London Fireplace Entertainment Center</p>  <p>BELLEZE</p> <table><tr><td>ITEM NO.</td><td>014-HG-41897</td><td>ITEM NO. 014-HG-41897</td></tr><tr><td>ITEM NAME</td><td>London Fireplace Entertainment Center</td><td>ITEM NAME 014-HG-41897</td></tr><tr><td>ITEM NO.</td><td>014-HG-41897</td><td>ITEM NO. 014-HG-41897</td></tr></table>	ITEM NO.	014-HG-41897	ITEM NO. 014-HG-41897	ITEM NAME	London Fireplace Entertainment Center	ITEM NAME 014-HG-41897	ITEM NO.	014-HG-41897	ITEM NO. 014-HG-41897	<p>London Fireplace Entertainment Center Assembly Manual</p> <p>Assembly instructions and care guide for the BELLEZE London Fireplace Entertainment Center (Item No. 014-HG-41897). Includes parts list, hardware details, step-by-step assembly, and maintenance tips.</p>
ITEM NO.	014-HG-41897	ITEM NO. 014-HG-41897								
ITEM NAME	London Fireplace Entertainment Center	ITEM NAME 014-HG-41897								
ITEM NO.	014-HG-41897	ITEM NO. 014-HG-41897								
<p>Avenue Entertainment Center w/ Fireplace</p>  <p>BELLEZE</p> <table><tr><td>ITEM NO.</td><td>014-HG-41895</td><td>ITEM NO. 014-HG-41895</td></tr><tr><td>ITEM NAME</td><td>Avenue Entertainment Center w/ Fireplace</td><td>ITEM NAME 014-HG-41895</td></tr><tr><td>ITEM NO.</td><td>014-HG-41895</td><td>ITEM NO. 014-HG-41895</td></tr></table>	ITEM NO.	014-HG-41895	ITEM NO. 014-HG-41895	ITEM NAME	Avenue Entertainment Center w/ Fireplace	ITEM NAME 014-HG-41895	ITEM NO.	014-HG-41895	ITEM NO. 014-HG-41895	<p>BELLEZE Avenue Entertainment Center with Fireplace Assembly Instructions and Guide</p> <p>Comprehensive assembly guide for the BELLEZE Avenue Entertainment Center with Fireplace (Item No. 014-HG-41895). Includes parts list, hardware details, step-by-step assembly instructions, safety warnings, and care instructions.</p>
ITEM NO.	014-HG-41895	ITEM NO. 014-HG-41895								
ITEM NAME	Avenue Entertainment Center w/ Fireplace	ITEM NAME 014-HG-41895								
ITEM NO.	014-HG-41895	ITEM NO. 014-HG-41895								
	<p>DKYND SYN JZQ3210 Rattan TV Stand Assembly Instructions</p> <p>Comprehensive assembly guide for the DKYND SYN JZQ3210 Rattan TV Stand with LED Lights. Includes parts list, step-by-step instructions, and safety notices.</p>									