One Fire WH-E22

Northern Lights Projector User Manual

Model: WH-E22 | Brand: One Fire

Introduction

Thank you for purchasing the One Fire Northern Lights Projector. This device is designed to transform your living space into a captivating aurora wonderland, offering a unique and relaxing ambiance. With its versatile lighting modes and user-friendly controls, it's perfect for creating a serene atmosphere in bedrooms, enhancing parties, or simply adding a touch of magic to any environment.
This manual provides essential information for the safe and effective operation of your projector. Please read it thoroughly before use and retain it for future reference.

Product Overview

Package Contents

- Aurora Lamp x 1
- Remote Control x 1
- Instruction Manual x 1
- Charging Cable x 1
- Gift Box x 1 (for storage or gifting)

Key Features

- **162 Lighting Modes:** Combines 18 colors with 3 brightness levels and 3 speeds to create diverse Northern Lights effects.
- **18 Colors:** Features 5 LED light beads (red, green, blue, white, yellow) that mix to produce a spectrum of 18 vibrant colors.
- **Dimmable Brightness:** Adjustable brightness levels via remote control or long-press button.
- **Remote & Timer Control:** Conveniently adjust settings and set a 1-hour timer for automatic shut-off.
- **360° Projection:** Unique cube design with 5 light-emitting surfaces ensures wide projection coverage.
- **No Installation Required:** Ready to use right out of the box.

Product Images



Image: The Northern Lights Projector, its remote control, and the stunning aurora effect it creates in a bedroom setting.



Image: A visual representation of the projector's RGB multi-color capabilities, showcasing various single-color projections.



Image: A person adjusting the brightness of the projector using the remote control while relaxing in bed, demonstrating the dimmable feature.



Image: A hand holding the remote control, with the projector casting a blue aurora effect over a sleeping child, highlighting the auto-timer and remote control functions.



Image: A clear display of all items included in the product package: the Aurora lamp, remote control, instruction manual, charging cable, and gift box.

Setup

1. **Unpack:** Carefully remove all components from the packaging.
2. **Placement:** Place the projector on a stable, flat surface in your desired location. For optimal projection, consider placing it in the center of the room or near a wall you wish to illuminate.
3. **Power Connection:** Connect the provided charging cable to the projector's power input port and then to a suitable USB power adapter (not included) or a USB port.
4. **Initial Power On:** The projector is ready for immediate use upon connecting power.

No complex installation or assembly is required. Simply plug and play!

Operating Instructions

Using the Remote Control

The included remote control provides full functionality for your Northern Lights Projector. Ensure the remote has working batteries (not included) and is pointed towards the projector.

- **Power On/Off:** Press the **Power** button to turn the projector on or off.
- **Color Selection:** Use the color buttons (R, G, B, W, Y, etc.) to select individual colors or combinations. The projector offers 18 distinct color options.
- **Brightness Adjustment:** Press the **Brightness Up (+)** or **Brightness Down (-)** buttons to cycle through 3 preset brightness levels. For infinite dimming, long-press the corresponding button on the projector itself.
- **Speed Adjustment:** Use the **Speed Up** or **Speed Down** buttons to change the movement speed of the aurora effect.
- **Mode Selection:** The remote allows you to switch between various lighting modes, offering 162 different aurora effects.
- **Timer Function:** Press the **1H TIMER** button to activate the 1-hour automatic shut-off timer.

Manual Controls (on Projector)

The projector also features physical buttons for basic control:

- **Power Button:** Press to turn on/off.
- **Brightness/Color Cycle Button:** Short press to cycle through colors. Long press to adjust brightness continuously.

Official Product Video

Your browser does not support the video tag.

Video: This official product video demonstrates the "Wonderful Aurora Northern Lights Projector Light" in action, showcasing its various light effects and how it transforms a room's ambiance.

Maintenance

To ensure the longevity and optimal performance of your Northern Lights Projector, please follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the exterior of the projector. Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the finish or internal components.
- **Storage:** When not in use for extended periods, store the projector in a cool, dry place, away from direct sunlight and extreme temperatures. It is recommended to keep it in its original packaging to protect it from dust and damage.
- **Handling:** Handle the projector with care. Avoid dropping it or subjecting it to strong impacts, which could damage the internal projection mechanism or LED components.

Troubleshooting

If you encounter any issues with your Northern Lights Projector, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Projector does not turn on.	No power supply or loose connection.	Ensure the charging cable is securely connected to both the projector and a working power source. Try a different USB adapter or port.

Problem	Possible Cause	Solution
Remote control is not working.	Batteries are dead or incorrectly inserted; remote not pointed at sensor.	Replace the remote control batteries. Ensure batteries are inserted with correct polarity. Point the remote directly at the projector's sensor.
Light projection is dim or inconsistent.	Brightness setting is too low; projector lens is dirty.	Increase the brightness using the remote or manual controls. Gently clean the projector's light-emitting surfaces with a soft, dry cloth.
Aurora effect is not moving or changing.	Speed setting is too low or paused.	Adjust the speed using the remote control. Cycle through different modes to ensure movement is enabled.

If the problem persists after trying these solutions, please contact customer support.

Specifications

Feature	Detail
Model Number	WH-E22
Color	White
Shape	Rectangular
Material	Acrylonitrile Butadiene Styrene (ABS)
Finish Type	Projector
Light Source Type	LED
Shade Material	Glass
Power Source	Corded Electric
Voltage	120 Volts (AC)
Mounting Type	Table Mount
Bulb Features	Color Changing, Dimmable, Remote Control Compatible
Number of Light Sources	5
Item Weight	1.76 pounds
Product Dimensions	4.7 x 4.7 x 5.5 inches
Included Components	Remote Control

Warranty and Support

One Fire stands behind the quality of its products. Your Northern Lights Projector comes with a **3-year quality promise**. If you encounter any problems or have questions regarding your projector, please do not hesitate to contact One Fire customer support. We are committed to providing excellent service and ensuring your satisfaction.

For support, please refer to the contact information provided on the product packaging or the official One Fire website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question