

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Jata](#) /

› **JATA JECL1900 Electric Milk Frother and Warmer User Manual**

Jata JECL1900

JATA JECL1900 Electric Milk Frother and Warmer User Manual

INTRODUCTION

This user manual provides detailed instructions for the safe and efficient operation, maintenance, and care of your JATA JECL1900 Electric Milk Frother and Warmer. Please read this manual thoroughly before first use and keep it for future reference. This appliance is designed to quickly froth milk for various beverages like cappuccinos and lattes, warm milk, and prepare hot chocolate.



Figure 1: The JATA JECL1900 Electric Milk Frother in a kitchen setting, ready to prepare beverages.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions carefully before using the appliance.

- Do not immerse the base unit, cord, or plug in water or other liquids.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Exercise extreme caution when disposing of hot steam.
- The appliance reaches a maximum temperature of 65°C. Handle with care.

PRODUCT OVERVIEW

Components

The JATA JECL1900 Electric Milk Frother and Warmer consists of the following main components:

- **Main Unit (Carafe):** Non-stick interior for easy cleaning.
- **Rotating Base:** 360° rotatable for convenient handling by both right-handed and left-handed users.
- **Frothing Whisk:** Detachable accessory for frothing milk.
- **Lid:** Transparent lid to cover the carafe.
- **Control Button:** Single button for operation with integrated indicator light.



Figure 2: Exploded view of the JATA JECL1900 components, including the main carafe, detachable base, lid, and frothing whisk.

Features

- **Three Functions:** Froths hot milk, froths cold milk, and heats milk/chocolate without frothing.
- **Versatile Use:** Ideal for preparing foamy coffee, cappuccinos, hot chocolate, and warm milk.
- **Capacity:** Up to 150 ml for frothing milk, and up to 300 ml for heating milk.
- **Easy Operation:** Simple one-button control.
- **Temperature Control:** Heats milk up to a maximum of 65°C.
- **Indicator Light:** Illuminates when connected and flashes/turns off to indicate completion.
- **Non-Stick Carafe:** Ensures easy cleaning.
- **360° Rotating Base:** Convenient for left and right-handed users.
- **Power:** 550 Watts.

SETUP

1. **Unpack:** Carefully remove all packaging materials and inspect the appliance for any damage.
2. **Initial Cleaning:** Before first use, clean the carafe interior and lid with water and mild dish soap. Wipe the exterior of the base unit with a damp cloth. Ensure all parts are dry before assembly.
3. **Assemble Frothing Whisk:** If you intend to froth milk, place the frothing whisk securely onto its anchor inside the carafe. To remove, simply pull it off.

4. **Placement:** Place the rotating base on a stable, flat, heat-resistant surface, away from water sources.
5. **Connect Power:** Plug the power cord into a suitable electrical outlet. The indicator light may briefly illuminate.



Figure 3: The JATA JECL1900 Electric Milk Frother assembled on its rotating base, ready for use.

OPERATING INSTRUCTIONS

The JATA JECL1900 offers three distinct functions controlled by a single button.



Figure 4: Close-up of the control button with symbols for hot (sun) and cold (snowflake) functions.

Filling Guidelines

Observe the MAX/MIN markings inside the carafe for optimal results and to prevent overflow.



Figure 5: Interior view of the carafe showing the 'MAX' line for heating (300ml) and the 'MAX' line with a sun symbol for frothing (150ml).

- For **frothing milk (hot or cold)**: Do not exceed the lower 'MAX' line (approx. 150 ml). Ensure the frothing whisk is in place.
- For **heating milk or chocolate (without frothing)**: Do not exceed the upper 'MAX' line (approx. 300 ml). Remove the frothing whisk if you do not want foam.

Function Selection

1. **Prepare:** Pour the desired amount of milk into the carafe, observing the fill lines. Place the lid on the carafe.
2. **Hot Froth / Hot Milk:**
 - Press the control button **once**.
 - The indicator light will illuminate, indicating the appliance is operating.
 - The appliance will heat and froth (if whisk is installed) the milk to approximately 65°C.
 - Once complete, the indicator light will flash and then turn off.
3. **Cold Froth:**
 - Press the control button **twice** in quick succession.

- The indicator light will illuminate.
- The appliance will froth cold milk without heating.
- Once complete, the indicator light will flash and then turn off.

4. Turn Off:

- Press the control button **three times** in quick succession to manually turn off the appliance during operation.
- The appliance will automatically turn off once a cycle is complete.

5. Serve: Carefully remove the carafe from the base and pour the frothed or heated milk into your beverage.

CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and extends the lifespan of your appliance. It is recommended to clean the frother after each use to prevent milk or chocolate residue from adhering.



Figure 6: The carafe can be easily lifted from its rotating base for cleaning.

- Unplug:** Always unplug the appliance from the power outlet before cleaning.
- Cool Down:** Allow the appliance to cool completely before handling.
- Carafe Interior:** The non-stick interior of the carafe can be cleaned with water and a mild dishwashing detergent. Rinse thoroughly. **Do not immerse the carafe in water.**
- Frothing Whisk:** Remove the frothing whisk and wash it under running water with a little dish soap.
- Lid:** Wash the lid with water and dish soap.
- Exterior:** Wipe the exterior of the carafe and the rotating base with a slightly damp cloth **Never rinse the exterior or immerse the base unit in water.**
- Drying:** Ensure all parts are completely dry before storing or next use.

Warning: Never immerse the electrical base unit or the main carafe in water or any other liquid. This can cause electric shock or damage to the appliance.

TROUBLESHOOTING

If you encounter issues with your JATA JECL1900, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outage; faulty outlet.	Ensure the appliance is securely plugged into a working power outlet. Check your circuit breaker.
Milk is not frothing or heating properly.	Incorrect milk level; frothing whisk not installed (for frothing); incorrect function selected; milk type.	Ensure milk is between MIN and MAX lines. Verify frothing whisk is correctly installed for frothing. Select the correct function (one press for hot froth/heat, two presses for cold froth). Some milk types (e.g., skim milk) froth better than others.
Indicator light flashes but appliance does not operate.	Overheating protection activated.	Unplug the appliance and allow it to cool down for several minutes before attempting to use it again.
Milk overflows.	Overfilled carafe.	Always observe the MAX fill lines for frothing (150ml) and heating (300ml).

If the problem persists after attempting these solutions, please contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	Jata
Model Number	JECL1900

Feature	Detail
Power	550 Watts
Capacity (Frothing)	150 Milliliters
Capacity (Heating)	300 Milliliters
Maximum Heating Temperature	65°C
Material	Plastic (exterior), Non-stick (interior carafe)
Color	White
Item Weight	720 grams
Special Feature	Three functions (hot froth, cold froth, heat)
Care Instructions	Hand wash only

WARRANTY AND SUPPORT

Specific warranty information for the JATA JECL1900 Electric Milk Frother and Warmer is not provided in the product details. For warranty claims, technical support, or spare parts availability, please refer to the documentation included with your purchase or contact JATA customer service directly through their official website or the retailer where the product was purchased.

Please retain your proof of purchase for any warranty-related inquiries.

Related Documents - JECL1900

	<p>Jata JEOL2135 Slow Cooker User Manual Comprehensive user manual for the Jata JEOL2135 Slow Cooker, providing instructions for use, maintenance, cleaning, and warranty information in multiple languages.</p>
	<p>Jata JEGR1913 Contact Grill: User Manual and Safety Instructions Comprehensive instructions for the Jata JEGR1913 Contact Grill, covering its components, safe operation, maintenance, cleaning, and environmental considerations. Includes technical specifications and warranty information.</p>
	<p>Jata GR2600 Electric Grill - Instructions for Use Comprehensive instructions for the Jata GR2600 Electric Grill, covering setup, operation, maintenance, and safety precautions in multiple languages.</p>

 <p>Jata JEOL2135 Slow Cooker User Manual Comprehensive user manual for the Jata JEOL2135 Slow Cooker, providing instructions for use, maintenance, cleaning, and warranty information in multiple languages.</p>	
 <p>Catálogo de Regalos y Utensilios de Cocina Coinfer Navidad 2016-2017 Explora el catálogo de ofertas de Coinfer para Navidad 2016-2017, presentando una variedad de regalos y utensilios prácticos para el hogar y la cocina de marcas como BIALETTI, ARC, WENKO, y más. Ofertas válidas hasta el 28/02/2017.</p>	
 <p>Jata JEGR1913 Contact Grill: User Manual and Safety Instructions Comprehensive instructions for the Jata JEGR1913 Contact Grill, covering its components, safe operation, maintenance, cleaning, and environmental considerations. Includes technical specifications and warranty information.</p>	