

coocaa 50R5G

coocaa ROKU 50R5G 50-inch UHD Smart LED TV User Manual

Model: 50R5G

1. IMPORTANT SAFETY INFORMATION

Please read all safety and operating instructions carefully before using your television. Keep these instructions for future reference.

- **Power Source:** Connect the TV only to the type of power source indicated on the marking label.
- **Ventilation:** Ensure proper ventilation. Do not block any ventilation openings.
- **Water and Moisture:** Do not expose the TV to rain or moisture. Do not use near water.
- **Cleaning:** Unplug the TV from the wall outlet before cleaning. Use a soft, dry cloth. Do not use liquid or aerosol cleaners.
- **Placement:** Place the TV on a stable, level surface. Avoid placing it in direct sunlight or near heat sources.
- **Lightning:** Unplug the TV during lightning storms or when unused for long periods.

2. PACKAGE CONTENTS

Verify that all items listed below are included in your TV package:

- coocaa ROKU 50R5G 50-inch UHD Smart LED TV
- Remote Control with Batteries
- TV Stand (2 pieces)
- Stand Screws
- Power Cable
- Quick Start Guide (this manual)

3. SETUP

3.1 Unpacking and Stand Installation

Carefully remove the TV from its packaging. It is recommended to have two people for this process. Place the TV face down on a soft, clean surface to prevent screen damage.

To install the TV stand:

1. Align each stand piece with the corresponding slots on the bottom of the TV.
2. Secure the stands using the provided screws. Ensure they are tightened firmly.

Alternatively, for wall mounting, consult a professional installer and use a VESA-compatible wall mount (not included).



This image illustrates the coocaa Roku TV seamlessly integrated into a modern living room environment, mounted on a light blue wall. The TV is positioned above a minimalist wooden TV cabinet, demonstrating a typical installation scenario.

3.2 Connecting Power and Initial Setup

1. Connect the power cable to the TV's power input and then to a wall outlet.
2. Press the power button on the remote control or the TV.
3. Follow the on-screen instructions to complete the initial Roku OS setup, including language selection, country, and channel scanning for the triple tuner (satellite, cable, or antenna).

3.3 Network Connection

To access Smart TV features and streaming services, connect your TV to the internet:

- **Wi-Fi:** During initial setup or via the Settings menu, select 'Network' and then 'Wireless'. Choose your Wi-Fi network from the list and enter the password.
- **LAN (Ethernet):** Connect an Ethernet cable from your router to the LAN port on the back of the TV. The TV will automatically detect the wired connection.

4. OPERATING YOUR TV

4.1 Roku OS Home Screen

The Roku OS home screen provides quick access to all your entertainment. It combines linear TV and streaming services into one intuitive interface.



This image shows the coocaa Roku TV from the front, powered on and displaying its intuitive home screen. The screen features icons for popular streaming services like Netflix, Disney+, Apple TV, and live TV options, alongside inputs for cable box and game console. A '2023 Heimkino Innovation Award' badge is visible on the bottom left bezel.

- **Streaming Channels:** Access popular apps like Netflix, Disney+, and Apple TV.
- **Live TV:** Watch broadcast television via the integrated triple tuner.
- **Inputs:** Easily switch between connected devices (e.g., game console, cable box).
- **Search:** Use the cross-channel search to find content by title, actor, or genre.

4.2 Using the Remote Control

The user-friendly remote control provides all necessary functions:

- **Navigation Pad:** Use the arrow buttons to navigate menus and select items.
- **OK Button:** Confirm selections.
- **Home Button:** Return to the Roku OS home screen.
- **Back Button:** Go back to the previous screen.
- **Instant Replay:** Replay the last few seconds of video.
- **Quick Access Buttons:** Dedicated buttons for popular streaming services.
- **Voice Search:** Use the voice search feature for hands-free control (if supported by remote model).

4.3 Input Sources

Connect external devices to your TV using the available ports:

- **HDMI:** The TV features three HDMI inputs for connecting devices like Blu-ray players, game consoles, or set-top boxes.
- **USB:** One USB port is available for media playback or Timeshift functions.
- **Digital Audio Out:** For connecting to external audio systems.

4.4 Smart TV Features

Your coocaa Roku TV offers a wide range of smart features:

- **Streaming Services:** Access pre-installed apps like Netflix, Disney+, Apple TV, and more.
- **Voice Assistant Support:** Compatible with Apple AirPlay, Apple Home, Alexa, and Google Home for integrated smart home control.
- **Roku Mobile App:** Control your TV, use voice search, and listen to audio via headphones using the free Roku app for iOS and Android devices.

4.5 Audio and Video Settings

Optimize your viewing experience:

- **Picture Modes:** Select from various picture modes (e.g., Standard, Movie, Sport) or customize brightness, contrast, and color settings.
- **HDR Support:** Enjoy enhanced contrast and color with HDR10 and HLG content.
- **Sound Modes:** Choose sound modes (e.g., Standard, Music, Speech) or adjust equalizer settings for optimal audio.

5. MAINTENANCE

5.1 Cleaning Your TV

To maintain the TV's appearance and performance:

- Unplug the TV before cleaning.
- Use a soft, dry, lint-free cloth to wipe the screen and cabinet.
- For stubborn marks, lightly dampen the cloth with water. Never spray cleaner directly onto the TV.
- Avoid using abrasive cleaners, waxes, or solvents.

5.2 Software Updates

Your Roku TV automatically checks for and installs software updates when connected to the internet. These updates provide new features, performance improvements, and bug fixes. Ensure your TV remains connected to the internet for timely updates.

6. TROUBLESHOOTING

If you encounter issues with your TV, refer to the following common solutions:

Problem	Possible Solution
No Power	Check if the power cable is securely connected to the TV and the wall outlet. Try a different outlet.
No Picture, but Sound is Present	Ensure the correct input source is selected. Check cable connections to external devices.
No Sound, but Picture is Present	Check the volume level and mute status. Ensure external audio systems are correctly connected and powered on.
Cannot Connect to Wi-Fi	Verify your Wi-Fi password. Restart your router and modem. Move the TV closer to the router or use a wired connection.
Remote Control Not Working	Replace the batteries. Ensure there are no obstructions between the remote and the TV.

7. SPECIFICATIONS

Detailed technical specifications for the coocaa ROKU 50R5G TV:

Produktdatenblatt

DELEGIERTE VERORDNUNG (EU) 2019/2013 DER KOMMISSION zur
Energieverbrauchskennzeichnung von elektronischen Displays

	Parameter	Parameter oder Wert und Genauigkeit			Einheit
1.	Name oder Warenzeichen des Lieferanten	Coocaa			
	Anschrift des Lieferanten	Coocaa, Ohmstraße 55, 90513 Zirndorf, DE			
2.	Modellkennung	50R5G			
3.	Energieeffizienzklasse bei Standard-Dynamikumfang (SDR)	G			
4.	Leistungsaufnahme im Ein-Zustand bei SDR	70,0			W
5.	Energieeffizienzklasse bei hohem Dynamikumfang (HDR)	G			
6.	Leistungsaufnahme im Ein-Zustand bei hohem Dynamikumfang (HDR), falls vorhanden	103			W
7.	Leistungsaufnahme im Aus-Zustand, falls zutreffend	Nicht zutreffend			W
8.	Leistungsaufnahme im Bereitschaftszustand, falls zutreffend	0,4			W
9.	Leistungsaufnahme im vernetzten Bereitschaftsbetrieb, falls zutreffend	1,0			W
10.	Art des elektronischen Displays	Fernsehgerät			
11.	Seitenverhältnis	16	:	9	
12.	Bildschirmauflösung	3 840	x	2 160	pixels
13.	Bildschirmdiagonale	126,0			cm
14.	Bildschirmdiagonale	50			Zoll
15.	Sichtbare Bildschirmfläche	67,6			dm ²
16.	Verwendete Panel-Technologie	LED LCD			
17.	Automatische Helligkeitsregelung (ABC) vorhanden	Nein			
18.	Spracherkennungssensor vorhanden	Nein			
19.	Anwesenheitssensor vorhanden	Nein			
20.	Bildwiederholfrequenz (Standard)	50			Hz
21.	Mindestens garantierte Software- und Firmware-Aktualisierungen (ab dem Datum der Beendigung des Inverkehrbringens)	8			Jahre
22.	Mindestens garantierte Verfügbarkeit von Ersatzteilen (ab dem Datum der Beendigung des Inverkehrbringens)	7			Jahre
23.	Mindestens garantierte Produktunterstützung	7			Jahre
	Mindestlaufzeit der vom Lieferanten angebotenen allgemeinen Garantie	2			Jahre
24.	Art der Stromversorgung (Netzteil)	Intern			
25.	Externes Netzteil (nicht genormt, in der Verkaufsverpackung enthalten)				
	i	-			

Seite 1

comprehensive technical specifications, including energy efficiency class, power consumption, screen resolution, panel technology, and guaranteed software/spare parts availability, as per EU regulations.

Parameter	Value
Brand	coocaa
Model Name / Item Model Number	50R5G
Operating System	Roku OS
Screen Size	50 Inches (126 cm)
Display Technology	LED LCD
Resolution	3840 x 2160 pixels (4K UHD)
Aspect Ratio	16:9
Refresh Rate (Standard)	50 Hz
Connectivity	Wi-Fi, LAN (Ethernet), 3x HDMI, 1x USB
Special Features	Integrated Speaker, HDR10, HLG, Triple Tuner
Supported Internet Services	Netflix, Disney+, Apple TV, Prime Video, RTL+
Product Dimensions (W x H x D)	110 cm x 65 cm x 9 cm (approx.)
Energy Efficiency Class (SDR)	G
Power Consumption (SDR)	70.0 W / 70 kWh/1000h
Energy Efficiency Class (HDR)	G
Power Consumption (HDR)	103 W / 103 kWh/1000h
Guaranteed Software/Firmware Updates	8 years (from end of market placement)
Guaranteed Spare Parts Availability	7 years (from end of market placement)
Guaranteed Product Support	7 years



ENERG




coocaa

50R5G



70 kWh/1000h

ABCDEF**G**
HDR
103 kWh/1000h



2019/2013

This image presents the EU Energy Label for the coocaa 50R5G TV. It indicates an energy efficiency class of 'G' for both Standard Dynamic Range (SDR) and High Dynamic Range (HDR) content, with power consumption values of 70 kWh/1000h for SDR and 103 kWh/1000h for HDR. The label also shows the screen size of 50 inches (126 cm) and resolution of 3840x2160 pixels. A QR code is included for accessing the EPREL database: [EPREL Database Link](#)

8. WARRANTY AND SUPPORT






Your coocaa ROKU 50R5G TV comes with a manufacturer's warranty. Please refer to the official product documentation for specific terms and conditions.

- **General Warranty Period:** 2 years from the date of purchase.
- **Product Support:** Guaranteed for 7 years.
- **Spare Parts:** Guaranteed availability for 7 years after the product is no longer placed on the market.
- **Software Updates:** Guaranteed for 8 years after the product is no longer placed on the market.

For technical assistance or warranty claims, please contact coocaa customer support through their official website or the retailer where the product was purchased.

© 2023 coocaa. All rights reserved.

Related Documents - 50R5G

	<p>Coocaa 43CRUG50Z 4K UHD Smart TV Product Data Sheet</p> <p>Detailed technical specifications for the Coocaa 43CRUG50Z 4K UHD Smart TV, including display, reception, sound, connectivity, power, and dimensions. Features Roku TV smart platform.</p>
	<p>Coocaa 24CGPF70Z Quick Start Guide</p> <p>A comprehensive quick start guide for the Coocaa 24CGPF70Z portable TV, covering setup, safety precautions, terminal connections, remote control functions, basic operations, troubleshooting, and technical specifications.</p>
	<p>Coocaa Roku TV R3G Series Quick Start Guide - Setup and Operation</p> <p>Get started with your Coocaa Roku TV R3G Series LED TV. This quick start guide provides essential information on setup, installation, safety precautions, remote control, basic operation, and troubleshooting. Manufactured by Shenzhen Chuangwei-RGB Electronics Co., Ltd.</p>
	<p>coocaa 24CGPF70Z Google TV Bedienungsanleitung</p> <p>Umfassende Bedienungsanleitung für das coocaa 24CGPF70Z TV-Gerät mit Google TV. Enthält detaillierte Anweisungen zur Einrichtung, Bedienung, Fehlerbehebung und Nutzung von Google TV-Funktionen.</p>
	<p>Coocaa LED TV S8M & S8G Series Quick Start Guide</p> <p>Comprehensive quick start guide for Coocaa LED TVs, models S8M and S8G series, covering setup, safety precautions, terminal connections, remote control functions, voice features, troubleshooting, and specifications.</p>

coocaa

Bedienungsanleitung
S3N S3U

[Coocaa S3N/S3U TV Bedienungsanleitung](#)

Umfassende Bedienungsanleitung für Coocaa S3N und S3U TV-Geräte. Enthält Informationen zu Installation, Gebrauch, Sicherheitshinweisen, Einstellungen und Fehlerbehebung.