

[Manuals.plus](#) /

› [Accudart](#) /

› Accudart Spark Electronic Dartboard User Manual

Accudart Spark Electronic Dartboard

Accudart Spark Electronic Dartboard User Manual

Model: Spark Electronic Dartboard (DA9200W)

INTRODUCTION

The Accudart Spark Electronic Dartboard offers an immersive darting experience with a wide array of game modes and variations. Designed for both solo practice against a virtual opponent and group play for up to eight players, this dartboard features an easy-to-read electronic scoring display and comes complete with soft-tip darts and replacement tips. This manual provides essential information for setup, operation, maintenance, and troubleshooting to ensure optimal performance and enjoyment of your dartboard.



Figure 1: Accudart Spark Electronic Dartboard Overview

SAFETY INFORMATION

- Use only soft-tip darts with this electronic dartboard. Hard-tip darts can damage the board and pose a safety risk.
- Ensure the dartboard is securely mounted to a stable surface before use to prevent it from falling.
- Keep hands and fingers clear of the dartboard surface when darts are being thrown.
- This product is not a toy. Adult supervision is recommended for children.
- Do not expose the dartboard to excessive moisture or direct sunlight.
- Unplug the dartboard from the power source when not in use or during cleaning.

PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- Accudart Spark Electronic Dartboard
- 6 Soft-Tip Darts
- Replacement Soft Tips
- AC Power Adapter
- Mounting Hardware (screws, wall anchors)
- User Manual (this document)



Figure 2: Included Soft-Tip Darts and Replacement Tips

SETUP

Mounting the Dartboard

1. Choose a suitable location: Select a wall or sturdy surface that can support the weight of the dartboard and withstand dart impacts. Ensure there is ample clear space around the board for safe play.
2. Determine mounting height: The center of the bullseye should be 5 feet 8 inches (1.73 meters) from the floor.
3. Mark drilling points: Use the dartboard's mounting holes as a template to mark the positions for drilling on the wall.
4. Drill holes: Drill pilot holes at the marked positions. If mounting into drywall, insert the provided wall anchors.
5. Secure the dartboard: Align the dartboard with the drilled holes and secure it using the provided screws. Ensure it is firmly attached and does not wobble.

Power Connection

- Locate the DC input jack on the back or side of the dartboard.
- Connect the AC power adapter to the DC input jack.
- Plug the AC power adapter into a standard electrical outlet. The dartboard display should illuminate, indicating it is powered on.

OPERATING INSTRUCTIONS

The Accudart Spark Electronic Dartboard features an intuitive control panel and a clear LCD display for easy game management and scoring.

Control Panel Overview

Familiarize yourself with the buttons on the control panel:

- **POWER:** Turns the dartboard on/off.
- **GAME:** Selects different game modes. Press repeatedly to cycle through options.
- **PLAYER:** Selects the number of players (up to 8).
- **START/NEXT PLAYER:** Starts a game or advances to the next player's turn.
- **VIRTUAL OPPONENT:** Activates or deactivates the computer opponent for solo play.
- **DOUBLE:** Used in certain games (e.g., '01 games) to enable double-in/double-out options.



Figure 3: Easy-Read LCD Display and Control Buttons

Game Modes and Variations

The dartboard offers 30 different game modes with 174 variations. Refer to the included game rule sheet for detailed instructions on each game.



Figure 4: Extensive Game Modes Available

Playing Against the Computer (Virtual Opponent)

To sharpen your skills, you can play solo against the built-in computer opponent.

1. Select your desired game mode using the **GAME** button.
2. Press the **VIRTUAL OPPONENT** button to activate the computer player.
3. Press **START/NEXT PLAYER** to begin the game.



Figure 5: Engaging the Virtual Opponent

Scoring and Display

The electronic scoring display automatically tracks scores for up to 8 players and includes a dedicated cricket bar for easy game management. Voice and sound effects enhance the gameplay experience.



Figure 6: Interactive Voice and Sound Effects

MAINTENANCE

- **Cleaning:** Wipe the dartboard surface and cabinet with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Dart Tips:** Regularly check the soft tips of your darts for wear and tear. Replace damaged tips promptly to ensure proper scoring and prevent damage to the board.
- **Storage:** When not in use for extended periods, unplug the dartboard and store it in a dry, cool place away from direct sunlight.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Dartboard does not power on.	No power connection or faulty adapter.	Ensure the power adapter is securely plugged into the dartboard and a working electrical outlet. Test the outlet with another device.
Darts are not registering scores.	Damaged dart tips or darts not fully penetrating segments.	Check dart tips for bends or breaks and replace if necessary. Ensure darts are thrown with enough force to fully enter the segment holes.
Display shows erratic scores.	Stuck segment or electronic malfunction.	Gently press on all segments to ensure none are stuck. If the problem persists, try resetting the dartboard by unplugging and replugging the power.
Sound is not working.	Volume too low or internal speaker issue.	Check if there is a volume control button (if available). If not, try power cycling the unit.

SPECIFICATIONS

Model Name	Spark Electronic Dartboard
Model Number	DA9200W
Brand	Accudart
Material	Plastic
Color	Black
Item Weight	1.43 Kilograms
Dimensions (LxWxH)	7.09 x 7.09 x 7.09 inches (Product) / 16.8 x 16.1 x 1.9 inches (Package)
Game Modes	30 Game Modes, 174 Game Variations
Players Supported	Up to 8 players (with electronic scoring)
Display Type	Easy-Read Electronic Scoring Display with Cricket Bar
Included Darts	6 Soft-Tip Darts with Replacement Tips

WARRANTY AND SUPPORT

For information regarding product warranty, returns, or technical support, please refer to the warranty card included with your purchase or visit the official Accudart website. Contact details for customer service are typically provided on the manufacturer's website or product packaging.

Accudart Official Website: [Visit the Accudart Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question