

[Manuals.plus](#) /

› [HCK](#) /

› HCK 23L Mini Refrigerator SC-23A-BK User Manual

HCK SC-23A

HCK 23L Mini Refrigerator SC-23A-BK User Manual

Model: SC-23A-BK

1. INTRODUCTION

Thank you for purchasing the HCK 23L Mini Refrigerator. This compact and energy-efficient appliance is designed for convenient cooling of beverages and other items in various settings such as bedrooms, offices, or living areas. Featuring a stylish glass door, silent operation, and adjustable temperature settings, it offers a reliable solution for your cooling needs. Please read this manual thoroughly before use to ensure proper operation and maintenance.

一人暮らし向け冷蔵庫



容量23L



1ドア



右開き



省エネ



保鮮・恒湿



Image 1.1: The HCK 23L Mini Refrigerator in a living room, showcasing its compact design and key features like 23L capacity, single door, right-hand opening, energy efficiency, and temperature preservation.

2. SAFETY INFORMATION

- Ensure the refrigerator is placed on a stable, level surface to prevent tipping.
- Do not block ventilation openings in the appliance enclosure or in the built-in structure.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not damage the refrigerant circuit.
- Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- Keep the power cord away from heat sources and sharp edges.
- This appliance is designed for household use only.
- Unplug the appliance before cleaning or performing any maintenance.

3. PACKAGE CONTENTS

Please check that all items are present and in good condition:

- HCK 23L Mini Refrigerator Unit
- Glass Shelf (1 piece)
- User Manual

4. SETUP

4.1 Placement

Place the refrigerator on a firm, level surface. Ensure there is adequate space around the unit for proper ventilation (at least 10 cm on the sides and back). Avoid direct sunlight or heat sources. The compact design allows for placement in various locations such as under desks, next to beds, or on countertops.



Image 4.1: Detailed dimensions of the HCK 23L Mini Refrigerator, illustrating its compact size (440mm D x 350mm W x 490mm H) and

internal shelf measurements.

4.2 Initial Cleaning

Before first use, clean the interior and exterior of the refrigerator with a soft cloth and mild detergent. Wipe dry thoroughly.

4.3 Power Connection

Plug the power cord into a standard 100V AC electrical outlet. Allow the refrigerator to stand for at least 2-3 hours before loading items to ensure the refrigerant settles and the unit reaches its set temperature.



Image 4.2: The HCK 23L Mini Refrigerator showcasing its features: a single removable shelf, quiet 39dB operation, an internal blue LED light, and adjustable feet for leveling.

5. OPERATING INSTRUCTIONS

5.1 Temperature Control

The refrigerator features a 5-stage temperature adjustment system, allowing you to set the internal temperature between

approximately 4°C and 14°C. The temperature dial is typically located inside the unit or on the back. Turn the dial to your desired setting. For general use, the 'Medium' setting (stages 3-4) is recommended.

Temperature Settings Guide

Dial Position	Approx. Internal Temperature
1 (Weak)	14-18°C
2	12-16°C
3 (Medium)	10-14°C
4	8-12°C
5 (Strong)	0-4°C

Note: The temperatures listed are approximate values for the center of the refrigerator. Actual temperatures may vary depending on ambient temperature, door opening frequency, and the amount of items stored.



Image 5.1: Illustration of the 5-stage temperature control dial and the approximate temperature ranges for each setting.

5.2 LED Interior Light

The refrigerator is equipped with a blue LED interior light. This light can be switched ON or OFF as desired, providing illumination for easy viewing of contents and adding an aesthetic touch to your space.



Image 5.2: The interior of the refrigerator illuminated by the built-in blue LED light, showcasing stored beverages.

5.3 Shelf Adjustment and Capacity

The single glass shelf is removable, allowing for flexible storage configurations. You can adjust its height or remove it entirely to accommodate taller items. The 23L capacity can hold approximately 6 bottles of 4-go size (720ml) or 24 cans of 330ml beverages.



Image 5.3: Demonstrates the removable shelf feature and illustrates the storage capacity for various bottle and can sizes.

6. MAINTENANCE

6.1 Cleaning

Regular cleaning helps maintain the refrigerator's efficiency and appearance.

- **Interior:** Unplug the unit. Remove all items and the shelf. Wash the interior with a solution of mild detergent and warm water. Rinse thoroughly and wipe dry with a soft cloth.
- **Exterior:** Wipe the exterior surfaces with a soft cloth dampened with mild detergent. Dry thoroughly.

- **Glass Door:** Clean the glass door with a glass cleaner or a damp cloth. Avoid abrasive cleaners that may scratch the surface.

6.2 Defrosting

This refrigerator features a manual defrost system. Frost buildup can reduce cooling efficiency. Defrost the unit when the frost layer reaches about 5mm (1/4 inch) thick.

1. Unplug the refrigerator from the power outlet.
2. Remove all contents and the shelf.
3. Leave the door open to allow the frost to melt naturally. Place a towel at the bottom to absorb water.
4. Once all frost has melted, clean and dry the interior thoroughly.
5. Reconnect the power and return items to the refrigerator.

Caution: Do not use sharp objects or heating devices to remove frost, as this can damage the cooling system.



Image 6.1: Illustration of the double tempered glass door, demonstrating its ability to suppress condensation and improve insulation by reflecting heat.

7. TROUBLESHOOTING

If you experience issues with your refrigerator, please check the following common problems and solutions before contacting support.

Troubleshooting Guide

Problem	Possible Cause	Solution
Refrigerator does not operate.	No power supply.	Check if the power cord is securely plugged into the outlet. Check the circuit breaker.
Unit is not cooling sufficiently.	Temperature setting is too high. Door is not closed properly. Excessive door openings. Too many items loaded. Poor ventilation.	Adjust the temperature dial to a lower setting. Ensure the door is fully closed. Minimize door openings. Reduce the amount of items stored. Ensure adequate space around the unit for airflow.
Unusual noise.	Unit is not level. Items inside are rattling.	Adjust the leveling feet to stabilize the unit. Rearrange items to prevent contact with each other or the interior walls.
Condensation on glass door.	High humidity environment. Frequent door openings.	This is normal in humid conditions. Wipe away condensation as needed. Minimize door openings.

8. SPECIFICATIONS

Product Specifications

Feature	Detail
Brand	HCK
Model Number	SC-23A
Capacity	23 Liters
Product Dimensions (D x W x H)	44 x 35 x 49 cm
Color	Black
Configuration	Standard, No Freezer Compartment
Special Feature	Compact
Number of Doors	1
Defrost System Type	Manual
Voltage	100 Volts (AC)
Shelf Type	Glass
Number of Shelves	1

Feature	Detail
Power Source	Power cord
Door Opening	Right-hand swing
Installation Type	Freestanding
Door Material Type	Glass
Annual Energy Consumption	112 kWh
Noise Level	39 dB

9. WARRANTY AND SUPPORT

All HCK products come with a 1-year warranty from the date of purchase. In case of a malfunction within the warranty period, repair, replacement, or refund will be provided according to our warranty policy. For further assistance or inquiries, please contact HCK customer support.



Image 9.1: An HCK mini refrigerator in silver, accompanied by information about the 1-year warranty provided for all HCK products.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CK41ZQWL>

More documents and user manuals: <https://manuals.plus/>