

Celly KHSPEAKER

Celly Keith Haring Bluetooth Speaker User Manual

Model: KHSPEAKER

1. INTRODUCTION

Thank you for choosing the Celly Keith Haring Bluetooth Speaker. This powerful 5W speaker combines high-quality audio with the iconic artistry of Keith Haring, making it a stylish and functional addition to your audio setup. This manual provides essential information on how to set up, operate, and maintain your speaker to ensure optimal performance and longevity. Please read this manual thoroughly before using the product.

2. PACKAGE CONTENTS

Please check the package for the following items:

- Celly Keith Haring Bluetooth Speaker
- USB-C Charging Cable
- User Manual (this document)

3. PRODUCT OVERVIEW

Familiarize yourself with the speaker's components and controls.



Figure 3.1: Front view of the Celly Keith Haring Bluetooth Speaker, showcasing its distinctive black body with white Keith Haring artwork and red heart accents. The lower section features a black speaker grille.



Figure 3.2: Close-up view of the speaker's top control panel. It features a central power button, surrounded by buttons for volume control (+/-), track navigation (previous/next), and mode selection (M).



Figure 3.3: Bottom view of the speaker, showing the circular base with the control buttons clearly visible. This perspective highlights the compact and stable design of the speaker.

Controls:

- **Power Button** (): Press and hold to power on/off. Short press to play/pause.
- **Volume Up / Next Track** (▶▶/V+): Short press for next track. Long press to increase volume.
- **Volume Down / Previous Track** (K◀/V-): Short press for previous track. Long press to decrease volume.
- **Mode Button (M)**: Press to switch between available modes (e.g., Bluetooth, AUX).

4. SETUP

4.1 Initial Charging

Before first use, fully charge your speaker. Connect the supplied USB-C cable to the speaker's charging port and the other end to a USB power adapter (not included) or a computer's USB port. The charging indicator light will illuminate during charging and turn off when fully charged.

4.2 Powering On/Off

- **To Power On:** Press and hold the Power button () for approximately 3 seconds until you hear an audible prompt.
- **To Power Off:** Press and hold the Power button () for approximately 3 seconds until you hear an audible prompt.

4.3 Bluetooth Pairing

The speaker will automatically enter Bluetooth pairing mode when powered on for the first time or if no device is connected. A blue indicator light will flash rapidly, indicating it's ready to pair.

1. Ensure the speaker is powered on and in pairing mode.
2. On your smartphone, tablet, or other Bluetooth-enabled device, go to the Bluetooth settings.
3. Search for available devices. You should see "KEITH HARING WIRELESS SPEAKER" in the list.
4. Select the speaker to connect. Once connected, you will hear a confirmation sound, and the blue indicator light will turn solid.
5. If prompted for a password, enter "0000".

The speaker will automatically reconnect to the last paired device when powered on, if the device is within range and Bluetooth is enabled.

5. OPERATING INSTRUCTIONS

5.1 Music Playback

- **Play/Pause:** Short press the Power button ().
- **Next Track:** Short press the ►►/V+ button.
- **Previous Track:** Short press the K◀/V- button.

5.2 Volume Control

- **Increase Volume:** Long press the ►►/V+ button.
- **Decrease Volume:** Long press the K◀/V- button.

5.3 Mode Switching

Press the 'M' (Mode) button to cycle through available input modes, such as Bluetooth or AUX (if applicable).

6. CHARGING

The speaker is equipped with a built-in rechargeable Lithium-polymer battery. When the battery is low, you may hear an audible low battery warning. Connect the USB-C charging cable to the speaker's USB-C port and a compatible USB power source. A full charge takes approximately 2-3 hours and provides over 6 hours of playback time at moderate volume.

7. MAINTENANCE

To ensure the longevity and performance of your speaker, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the speaker's surface. Do not use abrasive cleaners, alcohol, or chemical solvents, as these may damage the finish.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight, extreme temperatures, and humidity.
- **Water Resistance:** This speaker is not waterproof. Avoid exposing it to water or excessive moisture.
- **Handling:** Do not drop, disassemble, or attempt to repair the speaker yourself. This will void the warranty.

8. TROUBLESHOOTING

If you encounter issues with your speaker, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Speaker does not turn on.	Battery is depleted.	Charge the speaker using the USB-C cable.
Cannot pair with Bluetooth device.	Speaker is not in pairing mode or device's Bluetooth is off.	Ensure speaker is in pairing mode (flashing blue light). Turn off and on Bluetooth on your device. Move speaker closer to device.
No sound from speaker.	Volume is too low, speaker is paused, or incorrect input mode.	Increase volume on both speaker and connected device. Press Power button to play. Press 'M' button to select correct input mode.
Poor sound quality.	Device is too far from speaker or interference.	Move speaker closer to the connected device. Avoid obstacles between speaker and device.

9. SPECIFICATIONS

Feature	Specification
Model Name	KEITH HARING WIRELESS SPEAKER 5W
Model Number	KHSPEAKER
Brand	Celly
Connectivity Technology	Bluetooth, Wi-Fi, USB
Speaker Output Power	5 Watts
Battery Life	6 hours
Battery Type	1 Lithium-polymer (included)
Product Dimensions (L x W x H)	14 x 11 x 9 cm (5.5 x 4.3 x 3.5 inches)
Product Weight	390 grams (0.86 lbs)
Controller Type	Touchpad
Color	Black
Included Components	Cable
Special Feature	Exclusive Keith Haring Design
Recommended Uses	For smartphone or tablet, For computer

Feature	Specification
Compatible Devices	Smartphone, tablet, laptop, desktop computer

10. WARRANTY AND SUPPORT

Celly products are designed and manufactured with high-quality standards. For information regarding warranty terms and conditions, please refer to the warranty card included with your purchase or visit the official Celly website. For technical support or customer service inquiries, please contact Celly customer support through their official channels.

Manufacturer: Celly
Country of Origin: China