

## Hapadif 6cbb4013-b676-4072-a46c-3d6cc09bcedf

# Hapadif Motorized Automatic Cordless Roller Shades: 15-Channel Remote Control Instruction Manual

Model: 6cbb4013-b676-4072-a46c-3d6cc09bcedf

## INTRODUCTION

This manual provides instructions for the setup, operation, and maintenance of your Hapadif Motorized Automatic Cordless Roller Shades with a 15-Channel Remote Control. These shades offer convenient control for individual windows or groups of up to 15 shades simultaneously.

Key features include:

- **Group Control:** Control up to 15 shades at the same time.
- **Single Control:** Select a specific channel for individual shade operation.
- **Stable Operation:** Reliable control within a 30-meter range.
- **Cordless Design:** Enhanced safety and a clean aesthetic.

# GROUP CONTROL

up to 15 shades



Image: Hapadif Motorized Roller Shade with its 15-channel remote control, illustrating the product in a home setting.

## SETUP

### 1. Pairing the Remote Control

To pair the remote control with your roller shade, follow these steps:

1. On the remote control, locate the small switch inside the battery compartment. Switch it from 'user' to 'admin' mode.
2. On the roller shade motor, press and hold the 'M' key for two seconds. The motor will briefly rotate forwards and backwards, indicating it is in pairing mode.
3. On the remote control, press and hold the 'S' key for two seconds. The shade will move forwards and backwards once, confirming successful pairing.

Your browser does not support the video tag.

Video: Instructions on how to pair the remote control and set the upper and lower limits for the blinds.

## 2. Setting Upper and Lower Limits

After pairing, set the desired upper and lower stopping positions for your shade:

1. Use the up/down buttons on the remote to move the shade to your desired upper limit. Press the pause button to stop it precisely.
2. Press and hold the 'A' key (up arrow) on the remote for two seconds. The shade will briefly move, confirming the upper limit is set.
3. Use the up/down buttons to move the shade to your desired lower limit. Press the pause button to stop it precisely.
4. Press and hold the 'V' key (down arrow) on the remote for two seconds. The shade will briefly move, confirming the lower limit is set.

### SELECT ORDER WIDTH FOR INSIDE MOUNT

For outside mount order width: =window width + at least 4"

For inside mount order width: the actual window width minus ¼". Window depth > 2"

For other widths and colors, please select "Custom Size" (0"-59" width)

\*No drill device is only suitable for inside mount, but mounting screws are provided in each order.

Window Width	20"-20½"	21"-21½"	22"-22½"	23"-23½"	24"-24½"	25"-25½"	26"-26½"	27"-27½"	28"-28½"	29"-29½"	
Order Width	20"	21"	22"	23"	24"	25"	26"	27"	28"	29"	
Window Width	20½"-21"	21½"-22"	22½"-23"	23½"-24"	24½"-25"	25½"-26"	26½"-27"	27½"-28"	28½"-29"	29½"-30"	
Order Width	20½"	21½"	22½"	23½"	24½"	25½"	26½"	27½"	28½"	29½"	
Window Width	30"-30½"	31"-31½"	32"-32½"	33"-33½"	34"-34½"	34½"-35"	35"-35½"	36"-36½"	37"-37½"	38"-38½"	39"-39½"
Order Width	30"	31"	32"	33"	34"	34½"	35"	36"	37"	38"	39"
Window Width	30½"-31"	31½"-32"	32½"-33"	33½"-34"	34½"-34¾"	34¾"-35"	35½"-36"	36½"-37"	37½"-38"	38½"-39"	39½"-40"
Order Width	30½"	31½"	32½"	33½"	34½"	34¾"	35½"	36½"	37½"	38½"	39½"
Window Width	40"-40½"	41"-41½"	42"-42½"	43"-43½"	44"-44½"	45"-45½"	46"-46½"	47"-47½"	48"-48½"		
Order Width	40"	41"	42"	43"	44"	45"	46"	47"	48"		
Window Width	40½"-41"	41½"-42"	42½"-43"	43½"-44"	44½"-45"	45½"-46"	46½"-47"	47½"-48"	48½"-49"		
Order Width	40½"	41½"	42½"	43½"	44½"	45½"	46½"	47½"	48½"		

Image: Illustration of the no-drill installation method for Hapadif Motorized Roller Shades.

## 3. Selecting Order Width for Inside Mount

For inside mount installations, refer to the following table to determine the correct order width based on your window width. Note that no-drill devices are suitable for inside mount only, but mounting screws are provided for other options.

Window Width	Order Width
20"-20½"	20"
21"-21½"	21"
22"-22½"	22"
23"-23½"	23"
24"-24½"	24"

Window Width	Order Width
25"-25½"	25"
26"-26½"	26"
27"-27½"	27"
28"-28½"	28"
29"-29½"	29"
30"-30½"	30"
31"-31½"	31"
32"-32½"	32"
33"-33½"	33"
34"-34½"	34"
35"-35½"	35"
36"-36½"	36"
37"-37½"	37"
38"-38½"	38"
39"-39½"	39"
40"-40½"	40"
41"-41½"	41"
42"-42½"	42"
43"-43½"	43"
44"-44½"	44"
45"-45½"	45"
46"-46½"	46"
47"-47½"	47"
48"-48½"	48"

Note: For outside mount, order width should be window width + at least 4 inches. For custom sizes (0-59 inches width), please select 'Custom Size'.

## OPERATING INSTRUCTIONS

### 1. Remote Control Operation

The 15-channel remote control allows for flexible operation of your shades.

- **Single Shade Control:** Use the channel selection buttons (e.g., '01', '02') to choose a specific shade. Then, use the up, down, and pause buttons to control its movement.
- **Group Control:** Select channel '00' on the remote to control all paired shades simultaneously. Use the up, down, and pause buttons to operate the group.
- The remote control operates effectively within a 30-meter range.

## 4 Color Options 100% Blackout

-  Noise Reduction
-  UV Protection
-  Easy to Clean
-  Privacy Protection



Image: A remote control operating multiple Hapadif Motorized Roller Shades in a group setting.



**Ultra Quiet Motor**

A single batteries change can be used for 1 year or 600 cycles

25dB  
Leaves rustling

**35dB**  
Motor running

45dB  
Library

Image: A hand holding the remote control, demonstrating single shade operation.

Your browser does not support the video tag.

Video: Demonstration of remote control functionality for Hapadif roller shades.

## 2. Additional Control Methods (Requires Hub)

For enhanced control options, a compatible smart home hub is required:

- **App Control:** Manage your shades from anywhere using a smartphone application. Features may include timing control (e.g., open at 6 AM) and weather-based control (e.g., close on sunny days).
- **Voice Control:** Integrate with voice assistants like Alexa for hands-free operation.

### 3 WAYS TO CONTROL



**Remote Control**  
Single Channel Remote

The remote control has been matched with the blind before shipment. Just move your finger to control.

**15-Channel Remote**

15-Channel Remote controller can connect up to 15 blinds, and can realize group control.

**APP Control**  
(Need a Hub)

Timing Control: You can set it to open at 6 o'clock, let sun wake up a new day.

Weather Control: Set sun/rain, sunrise/sunset open or close the blinds.

Controlled anywhere: Open and close the blinds anytime and anywhere. Make your home safer.

**Voice Control**  
(Need a Hub)

Just say: Open the blinds, whether you are working or watching a play in bed, you will not be affected at all.

Example: "Alexa, close the blinds." → "Okay."

Image: A person interacting with an Alexa device to control Hapadif Motorized Roller Shades.

## MAINTENANCE

- **Cleaning:** The shades should be spot cleaned only. Do not immerse in water or use harsh chemicals.
- **Battery Life:** The motor's battery is designed to last approximately 1 year or 600 cycles on a single charge. Recharge or replace batteries as needed.

## TROUBLESHOOTING

### Shade Not Responding to Remote:

- **Check Remote Battery:** Ensure the remote control has a functional button battery.
- **Verify Pairing:** Confirm that the remote is correctly paired with the shade. Refer to the "Pairing the Remote Control" section for steps. Ensure the remote is in 'admin' mode during pairing.
- **Check Shade Power:** Ensure the shade's motor is charged or has sufficient power.
- **Range:** Ensure the remote is within the 30-meter operating range of the shade.

### Shade Not Stopping at Desired Limits:

- **Reset Limits:** Re-set the upper and lower limits following the instructions in the "Setting Upper and Lower Limits" section.

## SPECIFICATIONS

Feature	Detail
Brand	Hapadif
Model Number	6cbb4013-b676-4072-a46c-3d6cc09bcedf
Material	Polyvinyl Chloride (PVC)
Operation Mode	Automatic
Control Type	Motorized
Additional Features	Motorized & Multi-Channel Control
Closure Type	Cordless, Motorized
Mounting Type	Inside Mount (mounting hardware included)
Recommended Uses	Indoor, Window
Water Resistance Level	Not Water Resistant
Product Care Instructions	Spot Clean Only
Remote Control Dimensions	6"L x 2"W
Remote Control Color	White (15 Channel)
Included Components	Mounting Hardware, User Manual

## WARRANTY INFORMATION

Specific warranty details are not provided in the product information. Please refer to your purchase documentation or contact customer support for warranty inquiries.

## CUSTOMER SUPPORT

For any questions or assistance regarding your Hapadif Motorized Automatic Cordless Roller Shades, please contact our customer service team. We are committed to providing support and will respond to your inquiries.