

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [3MK](#) /

› [3MK Hardy LifePods Pro White Earbuds User Manual](#)

3MK Hardy LifePods Pro

3MK Hardy LifePods Pro White Earbuds User Manual

Model: Hardy LifePods Pro



INTRODUCTION

This manual provides detailed instructions for the proper use and maintenance of your 3MK Hardy LifePods Pro White wireless earbuds. Please read this manual thoroughly before using the product to ensure optimal performance and longevity. Keep this manual for future reference.

PACKAGE CONTENTS

Upon opening the package, verify that all items are present and in good condition. The standard package includes:

- 3MK Hardy LifePods Pro White Earbuds (Left and Right)
- Charging Case
- USB Charging Cable (Type-C)
- User Manual



Image: The 3MK Hardy LifePods Pro White earbuds and their charging case, displayed alongside their retail packaging.

PRODUCT OVERVIEW

Familiarize yourself with the components of your 3MK Hardy LifePods Pro White earbuds and charging case.



Image: The white charging case is open, revealing the two white 3MK Hardy LifePods Pro earbuds seated inside their respective charging slots. Three small indicator lights are visible on the front of the case.

- **Earbuds:** Each earbud features a touch control area, microphone, and charging contacts.
- **Charging Case:** Houses and charges the earbuds. It has a USB-C charging port and LED indicators for battery status.



Image: A close-up view of a single white 3MK Hardy LifePods Pro earbud, highlighting its sleek design, the small microphone opening at the bottom, and the touch-sensitive area.

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Place the earbuds into the charging case. Ensure they are correctly seated; magnetic contacts will hold them in place.
2. Connect the USB charging cable to the charging port on the case and the other end to a USB power source (e.g., computer, wall adapter).
3. The LED indicators on the case will illuminate to show charging status. Once fully charged, the indicators may change or turn off.
4. A full charge typically takes approximately 1-2 hours for the earbuds and 2-3 hours for the case.

2. Bluetooth Pairing

To connect your 3MK Hardy LifePods Pro to your device:

1. Ensure the earbuds are charged and placed inside the charging case.
2. Open the charging case lid. The earbuds will automatically enter pairing mode, indicated by flashing LED lights on the earbuds.
3. On your device (smartphone, tablet, computer), go to the Bluetooth settings.
4. Search for available devices and select "3MK Hardy LifePods Pro" from the list.
5. Once connected, the earbud LEDs will stop flashing, and your device will confirm the connection.
6. If pairing fails, close the case, wait a few seconds, and repeat the steps.



Image: A man wearing a white 3MK Hardy LifePods Pro earbud in his right ear, demonstrating how the earbud fits comfortably.

OPERATING INSTRUCTIONS

Wearing the Earbuds

Gently insert each earbud into your ear canal. Adjust for a comfortable and secure fit. The correct fit enhances sound quality and noise isolation.



Image: A man's hand gently touching a white 3MK Hardy LifePods Pro earbud in his ear, illustrating the process of adjusting the earbud for a proper fit.

Touch Controls

The 3MK Hardy LifePods Pro earbuds feature intuitive touch controls on each earbud. The functions may vary slightly depending on your device and application.

- **Single Tap:** Play/Pause music, Answer/End call.
- **Double Tap (Left Earbud):** Previous track.
- **Double Tap (Right Earbud):** Next track.
- **Triple Tap (Left Earbud):** Volume down.
- **Triple Tap (Right Earbud):** Volume up.
- **Long Press (2 seconds):** Reject call, Activate voice assistant.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your earbuds.

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use abrasive cleaners or solvents.
- **Charging Contacts:** Ensure the charging contacts on both the earbuds and the case are clean and free of debris to maintain a reliable connection.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged.
- **Avoid Moisture:** Keep the earbuds and case away from water, humidity, and extreme temperatures.

TROUBLESHOOTING

If you encounter issues with your 3MK Hardy LifePods Pro, refer to the following common solutions:

Problem	Possible Solution
Earbuds not pairing	<p>Ensure earbuds are charged.</p> <p>Place earbuds back in the case, close the lid, then open to re-enter pairing mode.</p> <p>Turn off and on Bluetooth on your device.</p> <p>Forget "3MK Hardy LifePods Pro" from your device's Bluetooth list and re-pair.</p>
Only one earbud working	<p>Ensure both earbuds are charged.</p> <p>Place both earbuds in the case, close the lid, and then open it again.</p> <p>Try resetting the earbuds (refer to manufacturer's specific reset instructions if available, or try forgetting and re-pairing).</p>
No sound or low volume	<p>Check the volume level on both your device and the earbuds.</p> <p>Ensure earbuds are properly connected to your device.</p> <p>Clean any debris from the earbud speaker mesh.</p>
Charging case not charging	<p>Ensure the charging cable is securely connected to both the case and the power source.</p> <p>Try a different USB cable or power adapter.</p> <p>Check the charging port for any obstructions.</p>

SPECIFICATIONS

Key technical specifications for the 3MK Hardy LifePods Pro White earbuds:

- **Brand:** 3MK
- **Model Number:** 5903108528290
- **Connectivity:** Bluetooth 5.3
- **Color:** White
- **Product Type:** Wireless Earbuds
- **Charging Port:** USB-C
- **Wireless Charging:** Supported
- **Quick Charge:** 15 minutes charge for hours of playtime

SAFETY INFORMATION

Please observe the following safety guidelines to prevent damage to the product or injury to yourself:

- Do not disassemble, repair, or modify the product.
- Avoid exposing the product to extreme temperatures, direct sunlight, or fire.
- Do not immerse the product in water or expose it to excessive moisture.
- Use only approved chargers and cables.
- Avoid listening at high volume levels for extended periods to prevent hearing damage.
- Keep out of reach of children and pets.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact the retailer where the product was acquired. You may also visit the official 3MK website for further assistance.

Manufacturer: 3MK

Model Number: 5903108528290

