Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SteFik zhangmeifengf

Instruction Manual for IKOHS Netbot S15 Robot Vacuum Cleaner Accessories Set

Model: zhangmeifengf

Introduction

This manual provides instructions for the installation, maintenance, and troubleshooting of the replacement accessory set for the IKOHS Netbot S15 Robot Vacuum Cleaner. This set includes essential components designed to maintain the optimal cleaning performance of your robot vacuum.
Compatibility: This accessory set is specifically designed for the IKOHS Netbot S15 Robot Vacuum Cleaner.

Included Components

The accessory set typically includes the following components:

Overview of the Accessory Set



This image displays the full replacement accessory set, which typically contains main brushes, side brushes, HEPA filters, mop cloths, and a small cleaning tool. These components are crucial for maintaining the vacuum's cleaning efficiency.

Main Brush



The main brush is a cylindrical brush, typically yellow and black, designed to agitate and sweep debris from floors into the vacuum's suction path. It features a combination of bristles and rubber fins for effective cleaning on various surfaces.

HEPA Filter



The HEPA filter is a white, rectangular pleated filter designed to capture fine dust particles, allergens, and pet dander, preventing them from being released back into the air. This ensures precise filtration and a cleaner home environment.

Mop Cloths



The mop cloths are semi-circular, blue microfiber pads used for wet mopping. They attach to the robot vacuum's water tank module

> to wipe and clean hard floors, enhancing the overall tidiness of your home.

Installation Instructions

Follow these steps to replace the accessories on your IKOHS Netbot S15 Robot Vacuum Cleaner:

1. **Replacing the Main Brush:**
   - Turn the robot vacuum cleaner upside down.
   - Locate the main brush cover, usually secured by two tabs or screws.
   - Open or unscrew the cover and remove the old main brush.
   - Clean any hair or debris from the brush compartment.
   - Insert the new main brush, ensuring it clicks into place correctly.
   - Close the main brush cover.
2. **Replacing the Side Brushes:**
   - Turn the robot vacuum cleaner upside down.
   - Locate the side brushes, typically held by a single screw.
   - Unscrew and remove the old side brushes.
   - Align the new side brushes with the corresponding posts and screw them into place.
3. **Replacing the HEPA Filter:**
   - Open the dustbin compartment of your robot vacuum.
   - Remove the dustbin.
   - Locate the filter assembly within the dustbin.
   - Remove the old HEPA filter and clean the dustbin.
   - Insert the new HEPA filter firmly into its slot.
   - Reinstall the dustbin into the robot vacuum.
4. **Attaching the Mop Cloths:**
   - Locate the water tank module on your robot vacuum.
   - Attach the mop cloth to the designated Velcro or clip areas on the bottom of the water tank module.
   - Ensure the cloth is securely fastened before operating the vacuum in mopping mode.

Operating with New Accessories

Once the new accessories are installed, your IKOHS Netbot S15 Robot Vacuum Cleaner is ready for operation. No special steps are required beyond regular use.

- Ensure the dustbin is empty and the water tank (if applicable) is filled before starting a cleaning cycle.
- For optimal performance, run the robot vacuum as per its original manufacturer's instructions.
- The new brushes and filters will immediately contribute to improved cleaning efficiency and air filtration.

Maintenance and Care

Regular maintenance of your robot vacuum accessories ensures prolonged performance and extends the lifespan of your

device.

- **Main Brush:**

  Inspect the main brush weekly for tangled hair or debris. Use the provided cleaning tool or scissors to cut and remove any wrapped hair. Replace the main brush every 6-12 months, or sooner if visibly worn.

- **Side Brushes:**

  Check side brushes bi-weekly for bent or damaged bristles. Clean any accumulated hair or debris. Replace side brushes every 3-6 months, or if they become ineffective at sweeping.

- **HEPA Filter:**

  Tap the HEPA filter gently over a trash can weekly to remove accumulated dust.**Do not wash the HEPA filter with water**, as this can damage the filter material. Replace the HEPA filter every 2-3 months, or more frequently if you have pets or allergies.

- **Mop Cloths:**

  Remove and wash mop cloths after each mopping session. They can be hand-washed or machine-washed with mild detergent. Allow them to air dry completely before reattaching. Replace mop cloths when they show signs of wear or reduced absorbency.

Troubleshooting Common Issues

If you encounter issues after replacing accessories, consider the following:

Issue	Possible Cause	Solution
Reduced Cleaning Performance	Brushes tangled or worn; filter clogged.	Clean main and side brushes. Replace brushes if severely worn. Clean or replace HEPA filter.
Robot making unusual noises	Debris caught in main brush or side brush mechanism.	Remove and inspect main and side brushes for obstructions. Ensure they are installed correctly.
Mop cloth not cleaning effectively	Mop cloth dirty or not properly attached.	Wash the mop cloth thoroughly. Ensure it is securely attached to the water tank module.
Dust escaping from vacuum	Filter not installed correctly or damaged.	Ensure HEPA filter is seated firmly in the dustbin. Replace filter if damaged.

Specifications

Feature	Detail
Brand	SteFik
Model Compatibility	IKOHS Netbot S15 Robot Vacuum Cleaner
Included Components (Typical Set)	Main Brush, Side Brushes, HEPA Filters, Mop Cloths, Cleaning Tool
Filter Type	HEPA (High-Efficiency Particulate Air)
Assembly Required	No (for accessories themselves, only installation into robot)
Item Weight (Main Brush)	Approximately 1.76 ounces (50 grams)
Package Dimensions (Main Brush)	Approximately 1.18 x 0.79 x 0.39 inches

Warranty and Support

For any questions regarding the installation or performance of these replacement accessories, please contact the seller or manufacturer directly. Specific warranty details may vary by retailer or region. Always refer to your purchase documentation for precise warranty information.
For general inquiries or technical support related to your IKOHS Netbot S15 Robot Vacuum Cleaner, please consult the original robot vacuum cleaner's instruction manual or the manufacturer's official website.

© 2023 SteFik. All rights reserved.
This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CK5C5JH2

More documents and user manuals: **https://manuals.plus/**