SteFik Q.5147 Replacement Parts Kit

SteFik Replacement Parts Instruction Manual for Qilive Q.5147 Robot Vacuum Cleaner

Model: Q.5147 Replacement Parts Kit

Introduction

This instruction manual provides guidance for the installation and maintenance of SteFik replacement parts compatible with the Qilive Q.5147 Robot Vacuum Cleaner. Regular replacement of these components ensures optimal performance and extends the lifespan of your robot vacuum.
The kit includes:

- Main Brushes
- Side Brushes
- HEPA Filters
- Mop Rags



Image: Overview of the SteFik replacement parts kit for Qilive Q.5147 robot vacuum cleaner. This image displays all components included: two main brushes, four side brushes, five HEPA filters, one pre-filter, and four blue mop cloths, arranged neatly on a white background.

Setup and Installation

Before installing any replacement parts, ensure your Qilive Q.5147 robot vacuum cleaner is powered off and disconnected from its charging base. Refer to your robot vacuum's original manual for specific instructions on accessing component compartments.

1. Main Brush Installation

1. Turn the robot vacuum upside down.
2. Locate the main brush cover, usually secured by latches or screws. Open or remove the cover.
3. Remove the old main brush.
4. Insert the new SteFik main brush into its designated slot, ensuring it clicks into place securely.
5. Close or reattach the main brush cover.



Image: A single SteFik main brush, featuring a yellow central rod with black bristles spiraling around it. This brush is designed to effectively

sweep debris into the vacuum's suction path.

2. Side Brush Installation

1. Turn the robot vacuum upside down.
2. Locate the side brushes. They are typically held in place by a single screw or a snap-on mechanism.
3. Remove the old side brushes. If secured by screws, use a screwdriver.
4. Align the new SteFik side brushes with the corresponding posts and press them down or secure them with screws until they are firmly attached.



Image: Four SteFik side brushes, each with three grey bristles extending from a yellow central hub. These brushes are crucial for sweeping debris from edges and corners into the main cleaning path.

3. HEPA Filter Installation

1. Open the dustbin compartment of your robot vacuum.
2. Remove the dustbin.
3. Locate the filter assembly within the dustbin. Remove the old HEPA filter and any pre-filter.
4. Insert the new SteFik HEPA filter and pre-filter into the dustbin, ensuring they are seated correctly.
5. Reinsert the dustbin into the robot vacuum until it locks into place.



Image: A single SteFik HEPA filter, rectangular in shape with tightly pleated white filter material designed to capture fine dust and allergens. A small white tab is visible at the top for easy removal.



Image: A single SteFik pre-filter, rectangular with a grey frame and a grid pattern of white filter material. This filter acts as a first line of defense, capturing larger particles before they reach the HEPA filter.

4. Mop Rag Installation

1. Locate the mop attachment or water tank on your robot vacuum.
2. Remove the old mop rag.
3. Attach the new SteFik mop rag to the mop attachment or water tank, ensuring it is securely fastened, typically with Velcro or a sliding mechanism.
4. If applicable, fill the water tank before reattaching it to the robot vacuum.



Image: Four blue SteFik mop rags, semi-circular in shape, displaying a soft, textured microfiber surface. These cloths are designed for wet mopping and attach to the robot vacuum's water tank or mop module.

Maintenance and Replacement Schedule

Regular maintenance of your robot vacuum's parts is crucial for maintaining cleaning efficiency and air quality. The following is a general guideline; actual replacement frequency may vary based on usage and environment.

Component	Maintenance	Recommended Replacement
Main Brush	Clean weekly by removing hair and debris.	Every 3-6 months
Side Brushes	Clean weekly, check for tangles.	Every 3-6 months
HEPA Filters	Tap clean weekly to remove dust. Do not wash.	Every 1-3 months
Mop Rags	Wash after each use.	Every 1-3 months

Note: If you notice a decrease in cleaning performance, increased noise, or visible wear on parts, consider replacing them sooner.

Troubleshooting

If you encounter issues after replacing parts, consider the following:

- **Parts not fitting:** Ensure you have the correct replacement parts for the Qilive Q.5147 model. Double-check alignment during installation.
- **Reduced cleaning efficiency:** Verify that brushes are free of tangles and filters are clean and correctly seated. Ensure the mop rag is properly attached and wet.
- **Unusual noise:** Check main and side brushes for any foreign objects or hair tangles that might be causing obstruction. Ensure brushes are installed correctly and not loose.

Specifications

These replacement parts are designed for compatibility with the Qilive Q.5147 Robot Vacuum Cleaner.

- **Brand:** SteFik

- **Compatible Model:** Qilive Q.5147 Robot Vacuum Cleaner
- **Components Included:** Main Brushes, Side Brushes, HEPA Filters, Mop Rags
- **Material:** Durable plastics, microfiber, and filter media.

Support

For further assistance or inquiries regarding SteFik replacement parts, please contact your retailer or the manufacturer directly. Refer to your purchase documentation for contact information.

© 2023 SteFik. All rights reserved. Qilive Q.5147 is a trademark of its respective owner.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question