

## Plyisty Plyistye5odwmkz46-11

# Plyisty Open-Ear Wireless Headphones User Manual

Model: Plyistye5odwmkz46-11

[Overview](#)

[Package Contents](#)

[Setup](#)

[Operating](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

## 1. OVERVIEW

---

The Plyisty Open-Ear Wireless Headphones are designed for comfort and situational awareness. They fit gently around the ears without entering the ear canal, reducing pressure and discomfort during extended wear. Utilizing air conduction principles, these headphones deliver clear, targeted sound while minimizing sound leakage. Equipped with dual microphones and advanced noise cancellation technology, they accurately capture your voice and reduce ambient noise for clear calls. Enjoy up to 10 hours of continuous playback and call time on a single charge, with intuitive touch controls for music and call management.



Image: Front view of the Plyisty Open-Ear Wireless Headphones, showcasing their ergonomic design.

## 2. PACKAGE CONTENTS

---

Please check the package for the following items:

- 1 x Open-Ear Headset
- 1 x Charging Cable (Type-C)
- 1 x Instruction Manual



Image: The Plyisty Open-Ear Wireless Headphones shown with the included USB Type-C charging cable.

## 3. SETUP

---

### 3.1. Charging the Headphones

1. Connect the provided Type-C charging cable to the charging port on the headphones.
2. Connect the other end of the charging cable to a USB power adapter (not included) or a computer's USB port.
3. The indicator light on the headphones will show the charging status. A full charge takes approximately 90 minutes.
4. Once fully charged, disconnect the charging cable.

### 3.2. Bluetooth Pairing

1. Ensure the headphones are fully charged.
2. Press and hold the power button on the headphones until the indicator light flashes, indicating pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "Plyisty Headphones" (or similar name) from the list of found devices.
5. Once connected, the indicator light on the headphones will change, usually to a slow flash or solid light, confirming successful pairing.

6. If pairing fails, turn off the headphones and your device's Bluetooth, then repeat the steps.

## 4. OPERATING INSTRUCTIONS

---

The Plyisty Open-Ear Wireless Headphones feature intuitive touch controls for easy operation.

### 4.1. Power On/Off

- **Power On:** Press and hold the power button for approximately 3 seconds.
- **Power Off:** Press and hold the power button for approximately 5 seconds.

### 4.2. Music Playback

- **Play/Pause:** Single tap the touch control area on either earbud.
- **Next Track:** Double tap the touch control area on the right earbud.
- **Previous Track:** Double tap the touch control area on the left earbud.

### 4.3. Call Management

- **Answer/End Call:** Single tap the touch control area on either earbud.
- **Reject Call:** Press and hold the touch control area on either earbud for 2 seconds.



Image: A person wearing the Plyisty Open-Ear Wireless Headphones, demonstrating their comfortable fit.



Image: Close-up view of one earbud, highlighting the design and potential touch control area.

## 5. MAINTENANCE

Proper care will extend the lifespan of your headphones.

- **Cleaning:** Wipe the headphones with a soft, dry, or slightly damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.
- **Water Resistance:** The headphones are IPX4 rated, meaning they are resistant to splashing water from any direction. Do not submerge them in water or expose them to heavy rain. Ensure the charging port is dry before charging.
- **Battery Care:** To preserve battery life, avoid fully discharging the headphones frequently. Charge them regularly, even if not in use for extended periods.

## 6. TROUBLESHOOTING

If you encounter issues with your headphones, refer to the following common solutions:

Problem	Solution
Headphones do not power on	Ensure the headphones are charged. Connect them to the charging cable and allow sufficient time to charge.
Cannot pair with device	1. Ensure Bluetooth is enabled on your device. 2. Make sure the headphones are in pairing mode (flashing indicator light). 3. Turn off and on Bluetooth on your device, then try pairing again. 4. Move closer to your device.

Problem	Solution
No sound or low volume	1. Check the volume level on both the headphones and your connected device. 2. Ensure the headphones are properly connected to your device. 3. Try disconnecting and re-pairing the headphones.
Charging issue	1. Ensure the charging cable is securely connected to both the headphones and the power source. 2. Try a different USB port or power adapter. 3. Check if the charging port on the headphones is clean and free of debris.

## 7. SPECIFICATIONS

Feature	Detail
Model Number	Plyistye5odwmkz46-11
Material	ABS Plastic
Bluetooth Version	5.3
Transmission Distance	≥10 m / 32.8 ft
Battery Capacity	90 mAh Lithium Battery (built-in)
Charging Time	Approx. 90 minutes
Charging Interface	Type-C
Output Power	52 mW
Music Playback Time	Up to 10 hours (at 60% volume)
Standby Time	3 days
Waterproof Rating	IPX4
Microphones	Dual Microphones with Noise Cancellation

# 「10」 Advantage








Image: Infographic detailing key advantages such as 18 grams weight, open-ear design, 10 hours battery, built-in mic, and Type-C charger.

## 8. SAFETY INFORMATION

- Do not disassemble, repair, or modify the product.
- Keep the product away from extreme temperatures, humidity, and corrosive substances.
- Avoid exposing the product to direct sunlight for prolonged periods.
- Do not use the product at high volume for extended periods to prevent hearing damage.
- Dispose of the product and its battery responsibly according to local regulations.

