ONEWISH TAB093CAC

ONEWISH TAB093CAC Touch Bedside Lamp User Manual

Model: TAB093CAC | Brand: ONEWISH

Introduction

Thank you for choosing the ONEWISH TAB093CAC Touch Bedside Lamp. This manual provides essential information for the safe and efficient use of your new lamp. Please read these instructions carefully before assembly and operation, and retain them for future reference.



Figure 1: ONEWISH TAB093CAC Touch Bedside Lamp

What's in the Box

Please verify that all components are present and undamaged upon opening the package:

- Lamp Base (Black Metal)
- Fabric Lamp Shade
- E26 LED Bulb (2700K Warm White)
- Shade Fixing Ring
- Instruction Manual

Assembly Instructions

Follow these steps to assemble your ONEWISH Touch Bedside Lamp:

1. **Unscrew the Fixing Ring:** Carefully unscrew the fixing ring from the lamp holder on the lamp base.
2. **Position the Lamp Shade:** Place the fabric lamp shade onto the lamp holder, ensuring it sits evenly.
3. **Tighten the Fixing Ring:** Screw the fixing ring back onto the lamp holder to secure the lamp shade

in place.

4. **Install the LED Bulb:** Gently screw the provided E26 LED bulb into the lamp socket until it is firm. Do not overtighten.



Figure 2: Lamp Assembly Steps

For a visual guide on assembly and operation, please watch the official product video below:

Video 1: Onewish Table Lamp Assembly and Demonstration. This video provides a visual walkthrough of the lamp's assembly and showcases its touch control features.

Operating Instructions

The ONEWISH Touch Bedside Lamp features intuitive touch control and 3-way dimmable lighting:

- **Touch Control:** The entire metal base of the lamp is touch-sensitive. Simply touch any part of the metal base to turn the lamp on/off and cycle through brightness settings.
- **3-Way Dimmable:** The lamp offers three levels of brightness (low, medium, high) to suit various needs.
    - **First Touch:** Activates Low brightness, ideal for a soft night light.
    - **Second Touch:** Activates Medium brightness, suitable for ambient lighting.

- **Third Touch:** Activates High brightness, perfect for reading or working.
- **Fourth Touch:** Turns the lamp off.




Figure 3: Touch Control Operation



Figure 4: 3-Way Dimmable Light Levels

Features

- **Touch Control:** Responsive touch-sensitive metal base for easy operation.
- **3-Way Dimmable:** Adjustable brightness levels (low, medium, high) for versatile lighting.
- **LED Bulb Included:** Comes with a complimentary 2700K warm white LED bulb (6.5W, 60W incandescent equivalent, 600 Lumens).
- **Energy Efficient:** The included LED bulb helps save on electricity costs.
- **Modern Design:** Aesthetic metal base with a fabric shade, suitable for various home decors.
- **Compact Size:** Ideal for small spaces, nightstands, desks, and offices.

Specifications

Brand	ONEWISH
Model Number	TAB093CAC
Product Dimensions	5.12"D x 5.12"W x 16.54"H

Item Weight	1.7 Pounds
Base Material	Metal
Shade Material	Fabric
Switch Type	Touch
Light Source Type	LED
Bulb Base	E26
Wattage	6.5 Watts (LED)
Brightness	600 Lumens
Color Temperature	2700 Kelvin (Warm White)
Average Life	10,000 Hours
Power Source	Corded Electric
Indoor/Outdoor Usage	Indoor



Figure 5: Product Dimensions and Bulb Information

Maintenance

To ensure the longevity and optimal performance of your lamp, follow these maintenance guidelines:

- **Cleaning:** Disconnect the lamp from the power source before cleaning. Use a soft, dry cloth to wipe the metal base and shade. Avoid abrasive cleaners or solvents that may damage the finish.
- **Bulb Replacement:** Ensure the lamp is unplugged and the bulb has cooled down before attempting to replace it. Use only E26 base LED bulbs, with a maximum wattage of 60W equivalent.
- **Shade Care:** The fabric shade can be gently dusted with a soft brush or vacuumed with a low-power setting.

Troubleshooting

If you encounter any issues with your lamp, please refer to the following common troubleshooting steps:

- **Lamp Not Turning On:**
  - Ensure the power cord is securely plugged into a working electrical outlet.
  - Check if the bulb is screwed in correctly and is not loose.
  - Verify that the bulb is not burnt out. Replace if necessary.
- **Touch Control Not Responding:**
  - Ensure your hands are dry and clean when touching the lamp base.
  - Confirm the bulb is a dimmable LED bulb, as non-dimmable bulbs may interfere with touch functionality.
  - Try unplugging the lamp for a few minutes and then plugging it back in to reset the touch sensor.
- **Flickering Light:**
  - Ensure the bulb is fully screwed into the socket.
  - Replace the bulb with a new one to rule out a faulty bulb.

Warranty and Support

The ONEWISH TAB093CAC Touch Bedside Lamp comes with a reassuring**1-year protection**. If you have any concerns, questions, or require assistance with your product, please do not hesitate to reach out to our 5-Stars Customer Support team at any time. We are committed to enhancing your daily experience and ensuring your satisfaction.