



Manuals.plus /

- › Fresh 'n Rebel /
- › Fresh 'n Rebel Code Core Bluetooth Headphones User Manual

Fresh 'n Rebel Code Core

Fresh 'n Rebel Code Core Bluetooth Headphones User Manual

Model: Code Core

INTRODUCTION

Welcome to your Fresh 'n Rebel Code Core Bluetooth Headphones. These wireless on-ear headphones are designed for comfort and convenience, offering up to 30 hours of playtime, integrated microphone, voice assistant compatibility, and easy-to-use controls. This manual provides detailed instructions to help you get the most out of your new headphones.



Image: Fresh 'n Rebel Code Core Bluetooth Headphones in Storm Grey, showcasing the sleek design.

WHAT'S IN THE BOX

Please check the package contents to ensure all items are present:

- Fresh 'n Rebel Code Core Wireless On-Ear Headphones
- Charging cable (USB to USB-C)
- Quick start guide (this manual)



Image: The Fresh 'n Rebel Code Core headphones, charging cable, and quick start guide, as packaged in the box.

PRODUCT OVERVIEW

Familiarize yourself with the key features and controls of your Code Core headphones.

Controls and Buttons

The headphones feature intuitive controls located on the earcups for easy access to various functions.

CLICKABLE BUTTON CONTROL

Quick and
easy access to
controls



Image: Detailed view of the clickable buttons on the earcup, including volume controls, power, and multi-function buttons for playback and calls.

- **Power Button:** Press and hold to power on/off.
- **Volume Up/Down:** Adjust audio volume.
- **Multi-function Button:** Play/pause music, answer/end calls, activate voice assistant.
- **Microphone:** For hands-free calls and voice assistant commands.

Foldable Design

The Code Core headphones are designed to be foldable, making them compact and easy to carry or store when not in use.



Image: The headphones in their folded configuration, demonstrating their compact and portable design.

SETUP

Charging the Headphones

Before first use, fully charge your Code Core headphones. A full charge provides up to 30 hours of playtime.

1. Connect the USB-C end of the charging cable to the charging port on the headphone earcup.
2. Connect the USB-A end of the charging cable to a compatible USB power source (e.g., wall adapter, computer USB port).
3. The LED indicator on the headphones will show charging status. It typically takes about 2 hours for a full charge.



Image: Visual representation of the headphones' 30-hour playtime and 2-hour charging duration.

Bluetooth Pairing

Follow these steps to pair your Code Core headphones with your device:

1. Ensure the headphones are charged and powered off.
2. Press and hold the Power button until the LED indicator flashes blue and red, indicating pairing mode.
3. On your device (smartphone, tablet, computer), go to Bluetooth settings and turn Bluetooth on.
4. Select "Fresh 'n Rebel Code Core" from the list of available devices.
5. Once connected, the LED indicator will turn solid blue or stop flashing.

Note: The headphones will automatically try to reconnect to the last paired device when powered on.

OPERATING INSTRUCTIONS

Music Playback

- **Play/Pause:** Press the Multi-function button once.
- **Next Track:** Double-press the Multi-function button.

- **Previous Track:** Triple-press the Multi-function button.
- **Volume Control:** Use the Volume Up (+) and Volume Down (-) buttons.

Phone Calls

- **Answer/End Call:** Press the Multi-function button once.
- **Reject Call:** Press and hold the Multi-function button for 2 seconds.

Voice Assistant

Activate your device's voice assistant (Siri, Google Assistant, etc.) directly from your headphones.

- **Activate Voice Assistant:** Press and hold the Multi-function button for 3 seconds.




Image: A person using the voice assistant feature with the headphones, showing icons for Siri and Google Assistant.

MAINTENANCE

- **Cleaning:** Wipe the headphones with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the headphones in a cool, dry place when not in use. Avoid extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the headphones frequently. Charge them regularly,

even if not in constant use.

- **Water Resistance:** These headphones are not water-resistant. Avoid exposure to liquids.

TROUBLESHOOTING

Problem	Solution
Headphones won't turn on.	Ensure the headphones are fully charged. Connect to a power source and try again.
Cannot pair with device.	Ensure headphones are in pairing mode (flashing blue/red LED). Turn off and on Bluetooth on your device. Forget the device from your Bluetooth list and try pairing again. Move closer to the device; ensure no obstructions.
No sound or low volume.	Check volume levels on both headphones and your connected device. Ensure headphones are properly connected to your device. Try playing different audio sources.
Poor audio quality.	Move closer to your device to avoid interference. Ensure there are no physical obstructions between the headphones and the device. Try disconnecting and reconnecting the Bluetooth connection.

SPECIFICATIONS

Feature	Detail
Model Name	Code Core
Connectivity	Wireless, Bluetooth
Playtime	Up to 30 hours
Charging Time	Approximately 2 hours for full charge
Ear Placement	On Ear
Form Factor	Foldable On Ear
Microphone	Integrated
Voice Assistant	Supported
Colour	Storm Grey (as per current product)
Dimensions (Package)	18.2 x 16.1 x 7.7 cm
Weight (Package)	468 g

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the Fresh 'n Rebel official website or contact their customer service directly. Keep your proof of purchase for warranty claims.

For further assistance, visit the official Fresh 'n Rebel support page:www.freshnrebel.com/support

