

[Manuals.plus](#) /

> [Audio-Technica](#) /

> Audio-Technica ATH-TWX7BK Wireless Earbuds User Manual

Audio-Technica ATH-TWX7

Audio-Technica ATH-TWX7BK Wireless Earbuds User Manual

MODEL: ATH-TWX7

Introduction

The Audio-Technica ATH-TWX7 truly wireless earbuds are engineered to deliver a high-fidelity audio experience with customizable listening features. These earbuds incorporate 5.8 mm high-resolution drivers, derived from the flagship ATH-TWX9 model, ensuring detailed music playback and support for 24-bit/96 kHz audio files. Designed for portability, the ATH-TWX7 features a compact form factor and intuitive audio controls, including digital hybrid noise-canceling technology activated via the earbud sensor.



Image: Front view of the Audio-Technica ATH-TWX7BK Wireless Earbuds.

What's in the Box

Your Audio-Technica ATH-TWX7BK package includes the following components:

- ATH-TWX7BK Wireless Earbuds (Left and Right)
- Wireless Charging Case
- USB-C Charging Cable
- Multiple sizes of silicone ear tips for optimal fit



Image: All components included in the ATH-TWX7BK package, including the earbuds, charging case, USB-C cable, and various ear tips.

Setup Guide

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Place the earbuds into the charging case. Connect the supplied USB-C cable to the charging case and a USB power source. The indicator light on the case will show charging status.

Charging Time: Approximately 1.5 hours for a full charge.

Battery Life: Up to 6.5 hours of continuous playback, with an additional 13.5 hours from the charging case, totaling 20 hours.




Image: An icon representing battery charging, indicating the earbuds are being powered up.

2. Bluetooth Pairing

To connect your ATH-TWX7BK earbuds to a device:

1. Ensure the earbuds are in the charging case and the case lid is open.
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for new devices.
3. Select "ATH-TWX7" from the list of available devices.
4. Once connected, the earbuds will indicate successful pairing.

The earbuds support Bluetooth 5.0 for stable and efficient wireless communication.




Image: An icon depicting wireless connectivity, symbolizing the Bluetooth pairing process.

3. Fitting the Earbuds

Proper fit is crucial for sound quality and noise cancellation. Experiment with the included ear tips to find the size that provides a secure and comfortable seal in your ear canal.

1. Gently insert the earbud into your ear.
2. Twist slightly to ensure a snug fit.
3. Test different ear tip sizes until you achieve optimal comfort and sound isolation.



Image: A close-up view of the ATH-TWX7BK earbuds, highlighting the ear tip design and fit.

Operating Your Earbuds

Touch Controls

The ATH-TWX7BK earbuds feature intuitive touch controls for managing audio playback, calls, and various functions. Refer to the quick start guide for detailed touch gestures for specific commands.

- **Media Control:** Play/pause, skip tracks, adjust volume.
- **Call Management:** Answer/end calls.
- **Voice Assistant:** Activate your device's voice assistant.



Image: An icon representing touch interaction, illustrating the touch-sensitive controls on the earbuds.

Ambience Control (Noise-Cancelling, Hear-Through, Talk-Through)

Customize your listening environment with the ambience control features:

- **Noise-Cancelling:** Reduces ambient noise for immersive listening.
- **Hear-Through:** Allows you to hear surrounding sounds and your own voice clearly without removing the earbuds, ideal for conversations or awareness.

- **Talk-Through:** Specifically designed to enhance voices around you while reducing other background noise.




Image: An icon representing a person speaking with sound waves, indicating the talk-through function.

Soundscape Function

The Soundscape function provides a selection of relaxing sounds, masking noises for concentration, or sounds for meditation, enhancing your focus or relaxation.




Image: An icon representing a sound wave within a circle, symbolizing the soundscape feature.

Multipoint Pairing

The multipoint pairing function allows the ATH-TWX7BK to be simultaneously connected to two Bluetooth devices. This enables seamless switching between devices, for example, from music on your tablet to a call on your smartphone.




Image: An icon showing a central point connected to two other points, representing multipoint connectivity.

Maintenance

To ensure the longevity and optimal performance of your ATH-TWX7BK earbuds, follow these maintenance guidelines:

- **Cleaning:** Regularly clean the earbuds, especially the ear tips and the charging contact pads on both the earbuds and inside the case. Use a soft, dry cloth. For stubborn dirt on contact pads, a cotton swab lightly dampened with alcohol can be used, ensuring they are completely dry before placing earbuds back in the case.
- **Storage:** Always store the earbuds in their charging case when not in use to protect them and keep them charged.
- **Water Resistance:** The earbuds are water-resistant. However, avoid submerging them in water or exposing them to excessive moisture for prolonged periods. Dry them thoroughly if they get wet.

Troubleshooting

If you encounter issues with your ATH-TWX7BK earbuds, try the following solutions:

- **No Sound or Low Volume:**

- Ensure earbuds are properly paired and connected to your device.
- Check the volume levels on both the earbuds and your connected device.
- Try adjusting sound settings via the Audio-Technica Connect app for optimal audio output.

- **Earbuds Not Disconnecting from Bluetooth:**

- If earbuds remain connected to your device even when placed in the charging case, ensure the case lid is closed properly.
- Manually disconnect or turn off Bluetooth on your device if the issue persists.

- **Intermittent Popping Sound:**

- Ensure the earbud contact pads are clean and free of debris, as this can affect connection.
- Try resetting the earbuds (refer to the full user manual for specific reset instructions).

- **Charging Issues:**

- Verify the charging cable is securely connected to both the case and the power source.
- Ensure the charging contacts on the earbuds and case are clean.

For more detailed troubleshooting or persistent issues, please refer to the comprehensive user manual available on the Audio-Technica support website.

Specifications

Feature	Detail
Model Name	ATH-TWX7BK
Connectivity Technology	Wireless (Bluetooth 5.0)
Noise Control	Active Noise Cancellation
Battery Life (Earbuds)	6.5 Hours
Total Battery Life (with Case)	Up to 20 Hours
Charging Time	1.5 Hours
Water Resistance Level	Water Resistant
Frequency Range	10 - 40,000Hz
Control Method	Touch
Item Weight	5.6 ounces (0.16 Kilograms)
Product Dimensions	2.17 x 3.46 x 4.57 inches

Warranty and Support

Audio-Technica products are manufactured to high quality standards and are warranted to be free from defects in materials and workmanship. For specific warranty terms and conditions applicable to your region, please refer to the warranty card included with your product or visit the official Audio-Technica website.

