



[Manuals.plus](#) /

> [WILAWELS](#) /

> WILAWELS Extension Cord Storage Reel G95CR06 User Manual

WILAWELS G95CR06

WILAWELS Extension Cord Storage Reel G95CR06 User Manual

Model: G95CR06

[Information](#) [Components](#) [Setup](#) [Operation](#) [Maintenance](#) [Introduction](#) [Safety](#) [Troubleshooting](#) [Specifications](#) [Support](#)

1. INTRODUCTION

Thank you for purchasing the WILAWELS Extension Cord Storage Reel G95CR06. This manual provides important information regarding the safe operation, installation, maintenance, and troubleshooting of your new cord reel. Please read this manual thoroughly before use and retain it for future reference.

This heavy-duty open cord reel is designed for convenient storage and access to extension cords, featuring four grounded outlets, a hand-wind retractable mechanism, and a 15A circuit breaker for enhanced safety.

2. SAFETY INFORMATION

WARNING: To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions when using electrical products.

- **Read all instructions:** Before using the cord reel, read and understand all instructions.
- **Electrical Rating:** Do not exceed the electrical rating of 15A, 125V, 1875W. Overloading can cause overheating and fire.
- **Circuit Breaker:** The built-in 15A circuit breaker protects against overloads. If the circuit breaker trips, reduce the load and press the reset button.
- **Grounding:** This product is equipped with a grounded plug. Ensure it is plugged into a properly grounded outlet. Do not modify the plug.
- **Indoor/Outdoor Use:** This cord reel is suitable for general purpose use. If used outdoors, ensure all connections are protected from moisture.
- **Cord Compatibility:** The reel can hold up to 100ft of 14/16 gauge cord or 80ft of 12 gauge cord. Ensure your extension cord is compatible. (Note: Extension cord is not included).

- **Children:** Keep out of reach of children.
- **Inspection:** Inspect the cord reel for damage before each use. Do not use if damaged.



Image: The 15A circuit breaker, designed to prevent overloads and ensure safety. Max Power Rating: 1875W.

3. PRODUCT COMPONENTS

Familiarize yourself with the parts of your WILAWELS Extension Cord Storage Reel:

Front

Grip Handle

15A Circuit Breaker

Wilawels

Extension Cord
Storage Reel

CORD REEL
Wilawels

4
Grounded
Outlets

Winding
Handle

On/Off Switch

Cable Management
Clip



Image: Front view of the cord reel highlighting key components such as the Grip Handle, 15A Circuit Breaker, Winding Handle, On/Off Switch, 4 Grounded Outlets, and Cable Management Clip.

- **Grip Handle:** For easy portability and carrying.
- **Winding Handle:** Used to manually retract and store the extension cord.
- **15A Circuit Breaker:** Automatically cuts power in case of overload. Press to reset.
- **On/Off Switch:** Controls power to the outlets. Features an indicator light.
- **4 Grounded Outlets:** Provides power connections for multiple devices.

- **Cable Management Clip:** Helps secure the cord and prevent tangling during winding or storage.

4. SETUP

Before first use, ensure your extension cord (not included) is properly installed onto the reel.

1. **Unpack:** Remove the cord reel from its packaging.
2. **Prepare Cord:** Obtain a suitable extension cord (12/3, 14/3, or 16/3 gauge, up to 80ft for 12/3 or 100ft for 14/3, 16/3).
3. **Attach Cord:** Securely plug the female end of your extension cord into one of the outlets on the reel.
4. **Wind Cord:** Use the winding handle to carefully wind the extension cord onto the reel. Ensure the cord is neatly coiled to prevent tangling.
5. **Secure Plug:** Use the cable management clip to secure the male plug of the extension cord when fully wound, preventing it from unwinding or dangling.

5. OPERATING INSTRUCTIONS

Follow these steps for safe and effective use of your cord reel.

5.1 Extending the Cord

1. **Unwind:** Hold the cord reel by the grip handle and pull the desired length of the extension cord from the reel.
2. **Secure:** If needed, use the cable management clip to lock the cord at the desired length, preventing the reel from spinning.
3. **Connect:** Plug the male end of the extension cord into a grounded power source.
4. **Power On:** Flip the On/Off switch to the 'ON' position. The indicator light will illuminate, showing power is supplied to the outlets.
5. **Plug in Devices:** Connect your tools or appliances to the four grounded outlets on the reel.



Image: The cord reel in an active workshop setting, demonstrating the rocker power switch in the 'ON' position and a device connected to one of the four grounded outlets.

5.2 Retracting the Cord

1. **Disconnect Devices:** Unplug all tools and appliances from the cord reel outlets.
2. **Power Off:** Flip the On/Off switch to the 'OFF' position.
3. **Unplug from Source:** Disconnect the male plug of the extension cord from the wall outlet.

4. **Wind:** Use the winding handle to smoothly retract the extension cord back onto the reel. Ensure the cord is guided evenly to prevent tangling.
5. **Secure for Storage:** Once fully retracted, use the cable management clip to fix the male plug in place for convenient storage.



Image: A visual guide showing how to use the multifunctional cable management clip: 1) Lock the cord at the desired length, 2) Help to wind the cord smoothly, and 3) Fix the plug when storing.

Smooth Rewinding

A handle and a round knob ensure smooth retraction.



Image: A person demonstrating the smooth rewinding process of the cord reel, highlighting the ergonomic handle and round knob designed for easy retraction.

6. MAINTENANCE

Proper maintenance ensures the longevity and safe operation of your cord reel.

- **Cleaning:** Wipe the cord reel with a dry cloth. Do not use harsh chemicals or abrasive cleaners. Ensure the unit is unplugged before cleaning.

- **Storage:** Store the cord reel in a dry, cool place away from direct sunlight and moisture. Ensure the cord is fully retracted and secured.
- **Inspection:** Regularly inspect the cord reel, outlets, and circuit breaker for any signs of wear, damage, or loose connections. Replace if damaged.



Image: The cord reel stored conveniently on a shelf, illustrating how its design helps keep cables tangle-free and organized.

7. TROUBLESHOOTING

If you encounter issues with your cord reel, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No power to outlets	On/Off switch is OFF	Flip the On/Off switch to 'ON'.
No power to outlets	Circuit breaker tripped	Unplug devices, reduce load, then press the reset button on the circuit breaker.
No power to outlets	Cord reel not plugged into power source	Ensure the extension cord is securely plugged into a live, grounded wall outlet.
Cord tangles during winding	Improper winding technique	Guide the cord evenly onto the reel using the winding handle. Use the cable management clip to assist.
Cord reel feels hot	Overload or prolonged heavy use	Immediately unplug devices and allow the unit to cool. Ensure total wattage does not exceed 1875W.


8. SPECIFICATIONS

Technical details for the WILAWELS Extension Cord Storage Reel G95CR06:

- **Brand:** WILAWELS
- **Model:** G95CR06
- **Material:** Metal, Polypropylene
- **Color:** Orange
- **Item Dimensions (L x W x H):** 10.6 x 4.7 x 12.2 inches
- **Installation Type:** Freestanding
- **Electrical Rating:** 15A, 125V, 1875W
- **Circuit Breaker:** 15 Amp
- **Outlets:** 4 Grounded Outlets
- **Cord Capacity:** Up to 100ft of 14/16 gauge cord or 80ft of 12 gauge cord (cord not included)
- **Certifications:** ETL Listed



Image: Dimensional drawing of the cord reel, indicating its length, width, and height in both centimeters and inches.



Cord Reel Capacity & Current Limits

Compatible Size

80FT-12/3AWG 100FT-14/3AWG 100FT-16/3AWG



Image: Visual representation of the cord reel's capacity and current limits, showing compatible sizes for 80ft of 12/3 AWG, 100ft of 14/3 AWG, and 100ft of 16/3 AWG cords.

9. WARRANTY AND SUPPORT

WILAWELS stands behind the quality of its products. For any questions, concerns, or warranty claims, please contact our customer service. Refer to your purchase documentation for specific warranty terms and contact information.

You can also visit the official WILAWELS store for more information and support: [WILAWELS Store](#)

