



[Manuals.plus](#) /

> [Simplay3](#) /

> Simplay3 Cooking Kids Dine-in Kitchen Set (Model 223040-01) Instruction Manual

Simplay3 223040-01

Simplay3 Cooking Kids Dine-in Kitchen Set (Model 223040-01) Instruction Manual

Comprehensive guide for assembly, operation, and maintenance of your Simplay3 Kids Kitchen Set.

PRODUCT OVERVIEW

The Simplay3 Cooking Kids Dine-in Kitchen Set is designed to provide an engaging and imaginative play experience for children. This durable playset includes a kitchen area with a sink, stove, oven, and microwave, along with a two-seat dining table and 32 cooking accessories. Its compact design allows for versatile placement in various play environments.

Key Features

- **Kids Kitchen Playset:** Features a large toddler table and chairs that attach to an all-around kitchen. Includes a storage oven with clicker knobs, sink and faucet, pass-through window, coffee maker, and realistic decals.
- **All-Around Play:** Designed for two-sided play, offering ample space for multiple children. The backside includes a write-on/wipe-off chalkboard, clips for holding orders, a clock with moving hands, a snack table with attached seats, a dish towel holder, a storage shelf, and a refrigerator.
- **Playfood Included:** Comes with a 32-piece kitchen set, including cut-apart Velcro play food, a pot and pan set with lids, salt and pepper shakers, and two place settings of plastic silverware, cups, and dishes.
- **Space Saving Design:** Its compact footprint allows this play kitchen to fit in various spaces, while still providing numerous pretend cooking activities.
- **Durable Construction:** Built to last in the USA with durable, double-walled plastic construction, ensuring years of use. Colors are designed not to chip, fade, crack, or peel.

SETUP AND ASSEMBLY

The Simplay3 Cooking Kids Dine-in Kitchen Set is designed for straightforward assembly. While specific step-by-step instructions are typically provided in the product packaging, the general process involves connecting the main kitchen unit with the dining table and chairs. Ensure all components are securely fastened before use.

- Unpack all components and verify against the parts list (usually found in the included manual).
- Connect the main kitchen unit sections.

- Attach the two-seat table to the main kitchen unit.
- Apply any included decals as per the visual guide.
- Place the 32-piece accessories in their designated storage areas or for immediate play.
- Ensure all connections are firm and stable for safe play.



Image: Two children engaging with the Simplay3 Kids Kitchen Playset, demonstrating its two-sided play and integrated seating.

OPERATING INSTRUCTIONS

This play kitchen set offers various interactive elements for realistic pretend play.

- **Stove and Oven:** The stove features interactive elements that may light up and make sounds when pots and pans are placed on them (batteries may be required, not included). The oven door opens for placing play food inside. Turn the clicker knobs to simulate cooking temperature adjustments.
- **Sink and Faucet:** The sink area allows for pretend washing of dishes. The faucet handles can be turned.
- **Microwave:** The microwave unit is located above the main kitchen area, providing another station for imaginative

cooking.

- **Chalkboard and Clock:** Use the chalkboard on the backside for writing "orders" or menus. The clock has movable hands for learning time.
- **Storage:** Utilize the various hooks, shelves, and the refrigerator door for storing play food and accessories.




Image: Detailed view of the kitchen's interactive features, including clicking knobs and the oven door.



Image: Features like fun decals and a pass-through window are highlighted, enhancing imaginative play.

MAINTENANCE AND CARE

To ensure the longevity and hygiene of your Simplay3 Kids Kitchen Set, follow these simple maintenance guidelines:

- **Cleaning:** Wipe down all surfaces regularly with a damp cloth and mild soap. For thorough cleaning, a disinfectant wipe can be used. Avoid abrasive cleaners that may damage the plastic.
- **Storage:** While durable for indoor and outdoor use, storing the playset in a shaded area or indoors when not in use can help preserve its colors and material integrity over time.
- **Inspection:** Periodically check all parts for any signs of wear or damage. Ensure all connections remain secure.



Image: The durable construction of the Simplay3 Kids Kitchen Playset, emphasizing its UV resistance, ease of cleaning, and rounded edges.

TROUBLESHOOTING

If you encounter any issues with your play kitchen set, refer to the following common troubleshooting tips:

- **Lights/Sounds Not Working:**
 - Check if batteries are installed correctly.
 - Replace old batteries with new ones.
 - Ensure the power switch (if any) is in the "On" position.
- **Loose Parts:**
 - Inspect all connection points and re-secure any loose components.
 - Refer to the assembly instructions for proper attachment methods.
- **Missing Accessories:**
 - Verify the contents against the included parts list. Contact customer support if items are missing.

SPECIFICATIONS

Feature	Detail
Brand	Simplay3
Model Number	223040-01
Product Dimensions	27 x 33 x 35.5 inches (L x W x H)

Item Weight	16 pounds
Recommended Age	18 months - 5 years
Material	Durable, double-walled plastic
Included Accessories	32-piece cooking accessories, play food, pots, pans, dishes, silverware.



Image: The Simplay3 Kids Kitchen Playset with key dimensions (length, width, height) indicated.

WARRANTY AND SUPPORT

For warranty information, product registration, or customer support, please refer to the official Simplay3 website or the contact details provided in your product packaging. Keep your purchase receipt for warranty claims.

Manufacturer: Simplay3

For further assistance, visit the [Simplay3 Store on Amazon](#).

PRODUCT VIDEOS

Simplay3 Kids Kitchen Playset Overview

Your browser does not support the video tag.

Video: A brief overview showcasing the Simplay3 Kids Kitchen Playset in action, highlighting its various features and how children interact with it. This video demonstrates the compact design and the included accessories.



© 2023 Simplay3. All rights reserved.
Model: 223040-01