

Power Wheels Disney Princess Jeep Wrangler

Power Wheels Disney Princess Jeep Wrangler Ride-On Vehicle User Manual

Model: Disney Princess Jeep Wrangler

1. SAFETY INFORMATION

Please read and understand all instructions before operating the Power Wheels Disney Princess Jeep Wrangler. Adult supervision is required at all times.

- **Age Range:** Suitable for children aged 3 to 7 years.
- **Maximum Weight Capacity:** Do not exceed 130 lb (58 kg).
- **Battery Charging:** For first-time use, charge the battery for at least 18 hours, but no more than 30 hours. Subsequent charges should be at least 14 hours, but no more than 30 hours.
- **Parental Control:** Utilize the parent-controlled high-speed lockout feature for younger or less experienced riders.
- **Braking System:** The vehicle is equipped with a Power-Lock brake system for automatic stopping when the foot pedal is released.
- Always ensure the vehicle is operated in a safe environment, away from traffic, pools, or steep inclines.

2. PRODUCT OVERVIEW

The Power Wheels Disney Princess Jeep Wrangler is a battery-powered ride-on toy designed for adventurous young drivers. It combines authentic Jeep Wrangler styling with enchanting Disney Princess graphics and features.



Image 2.1: The Power Wheels Disney Princess Jeep Wrangler Ride-On Vehicle shown with its accompanying 12-Volt rechargeable battery. The vehicle is pink and purple with Disney Princess decals.



**FORWARD
AND REVERSE**



**RECHARGEABLE
12-VOLT BATTERY**

3-7

**YEARS
130 LB. MAX WEIGHT**

Image 2.2: Two children are seated in the pink and purple Power Wheels Disney Princess Jeep Wrangler, driving on grass. Text overlays highlight features: Forward and Reverse, Rechargeable 12-Volt Battery, and 3-7 Years (130 lb. Max Weight).



Adorable Disney Princess decorations

Image 2.3: A close-up view of the hood of the Power Wheels Jeep, showcasing detailed illustrations of three Disney Princess characters.



Image 2.4: A close-up of the vehicle's pink dashboard, showing a hand pressing a button next to a display that reads "111.8 FM 2". Musical notes and text indicate "Plays driving sounds & character phrases".

Key Features:

- Authentic Jeep Wrangler styling with Disney Princess colors and graphics.
- Plays Disney character phrases and realistic driving sounds.
- Working doors for easy entry and exit.
- Roomy rear storage compartment.
- Multi-terrain traction for driving on hard surfaces, wet grass, and rough terrain.
- Two forward speeds (2.5 mph and 5 mph) and one reverse speed.
- Includes a rechargeable 12-Volt, 12-Ah battery and charger.

3. SETUP

3.1 Battery Charging

Before first use, the battery must be charged for the recommended duration.

1. Connect the charger to the battery.
2. Plug the charger into a standard wall outlet.
3. Charge the battery for **18 to 30 hours** for the initial charge.
4. For subsequent charges, ensure the battery is charged for **14 to 30 hours**.
5. Do not overcharge the battery. Unplug the charger once the charging time is complete.



Image 3.1: A close-up view of the gray Power Wheels 12-Volt battery, showing its labels and the Power Wheels logo.



Image 3.2: Another perspective of the Power Wheels 12-Volt battery, highlighting its design and connection points.

3.2 Vehicle Assembly (General)

While specific assembly steps are detailed in the included assembly guide, general steps involve:

1. Attaching wheels and axles.
2. Securing the steering wheel.
3. Installing the seats.
4. Connecting the battery to the vehicle's power system.

Ensure all connections are secure and all parts are properly fastened before allowing a child to operate the vehicle.

4. OPERATING INSTRUCTIONS

4.1 Driving the Vehicle

- **Starting:** Press the foot pedal to engage the motor and move the vehicle.
- **Stopping:** Release the foot pedal to activate the Power-Lock brake system and bring the vehicle to a stop.
- **Speed Selection:** Use the gear shifter to select between 2.5 mph (low speed), 5 mph (high speed), or reverse.
- **High-Speed Lockout:** For safety, an adult can engage the high-speed lockout feature to prevent the vehicle from operating at 5 mph. Refer to the assembly guide for specific instructions on engaging/disengaging this feature.
- **Steering:** Turn the steering wheel to control the direction of the vehicle.

4.2 Sound and Character Phrases

The vehicle features interactive sounds and Disney character phrases. Locate the buttons on the dashboard to activate these features during play.

4.3 Storage Compartment

The rear of the Jeep includes a roomy storage compartment. This can be used to carry small toys or essentials during adventures.

5. MAINTENANCE

5.1 Battery Care

- Always recharge the battery after each use.
- If the vehicle will not be used for an extended period, charge the battery once a month to prolong its lifespan.
- Store the battery in a cool, dry place. Do not store it in extreme temperatures.
- Only use the charger provided with the vehicle.

5.2 Cleaning the Vehicle

- Wipe the vehicle with a soft, damp cloth.
- Do not use abrasive cleaners or solvents.
- Do not spray water directly onto the vehicle or immerse it in water.

5.3 General Inspection

- Regularly check all nuts, bolts, and screws to ensure they are tight.
- Inspect the wheels for wear and tear.
- Check the electrical connections for any signs of damage.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Vehicle does not move.	Battery is not charged or is dead.	Charge the battery for the recommended time. If the battery is old, it may need replacement.
Vehicle moves slowly.	Battery is low on charge.	Recharge the battery.
Sounds/phrases not working.	Low battery or electrical connection issue.	Ensure battery is charged. Check connections to the sound module.
Vehicle stops suddenly.	Overload protection activated.	Reduce weight or allow the motor to cool down.

7. SPECIFICATIONS

- **Model Name:** Disney Princess Jeep Wrangler
- **ASIN:** B0CKCDFH4M
- **Battery:** 12-Volt, 12-Ah Rechargeable
- **Speeds:** 2.5 mph (4 km/h) and 5 mph (8 km/h) forward, 2.5 mph (4 km/h) reverse
- **Maximum Weight Capacity:** 130 lb (58 kg)
- **Recommended Age:** 3-7 years
- **Seating Capacity:** 2 children
- **Traction:** Multi-terrain (hard surfaces, wet grass, rough terrain)
- **Features:** Disney character phrases, driving sounds, working doors, rear storage, Power-Lock brake system, parent-controlled high-speed lockout.

8. WARRANTY AND SUPPORT

For warranty information, replacement parts, or technical support, please contact Power Wheels customer service. Refer to the documentation included with your purchase for specific contact details or visit the official Power Wheels website.

Power Wheels Official Store: [Visit the Power Wheels Store on Amazon](#)



[pdf] Flyer

115938 S2430 PG16 FGASO indd 59¢ 50¢ \$7999 29999 flyer f wishabi net flyers 44232217

01682f97c718503b |||

1 With Card School Supplies Select varieties. Reg. 1.49-2.99 YOUR CHOICE Elmer s
4 oz. School Glu ... Gelire Ignitor Reg. 11.99 Find more Nerf Active Sport Toys on
sale 7 99 With Card Power Wheels **Disney Princess Jeep Wrangler** Reg. 369.99
SAVE 115 25499 . With Card 8-2-115938 08/28-09/03/202...

lang:en score:17 filesize: 16.22 M page_count: 17 document date: 2024-08-22