

Sweetcrispy CDHNCJ-3801

Sweetcrispy Ergonomic Computer Gaming Desk Chair (Model CDHNCJ-3801) - User Manual

Your guide to assembly, operation, and maintenance.

1. INTRODUCTION

Thank you for choosing the Sweetcrispy Ergonomic Computer Gaming Desk Chair. This manual provides essential information for the safe assembly, operation, and maintenance of your new chair. Please read it thoroughly before use and retain it for future reference.

2. SAFETY INFORMATION

- Always follow the assembly instructions carefully.
- Do not exceed the maximum weight capacity of 275 lbs.
- Keep the chair away from heat sources and sharp objects to prevent damage.
- Be cautious when adjusting the height and using the rocking motion feature to avoid injury.

3. PACKAGE CONTENTS

Before assembly, ensure all components are present. Refer to the included assembly instructions for a detailed list of parts and hardware. Typical components include:

- Backrest
- Seat Cushion
- Armrests (2)
- Gas Lift Cylinder
- Star Base
- Casters (5)
- Mechanism Plate
- Assembly Hardware (screws, washers, wrench)



Figure 3.1: Chair Dimensions and Key Components

4. SETUP AND ASSEMBLY

Assembly is straightforward and typically takes about 17 minutes. Follow the step-by-step instructions provided in your package. Ensure all bolts are tightened securely.

Assembly Video Guide

Your browser does not support the video tag.

Video 4.1: Assembly and Features Overview of the Sweetcrispy Gaming Chair. This video demonstrates the assembly process and highlights key features like comfort and adjustability.

Your browser does not support the video tag.

Video 4.2: Detailed Look at the Sweetcrispy Gaming Chair. This video provides a closer inspection of the chair's design, materials, and ergonomic aspects.

5. OPERATING INSTRUCTIONS

Your Sweetcrispy gaming chair is designed for comfort and adjustability. Familiarize yourself with its features to optimize your seating experience.

5.1 Height Adjustment

To adjust the chair's height, locate the lever under the seat. Pull the lever upwards while applying or releasing your weight from the seat to move it up or down. Release the lever to lock the height.



Figure 5.1: Ergonomic Design and Key Adjustable Components

5.2 Flip-up Armrests

The armrests can be flipped up 92° to save space or provide extra support. When flipped up and locked, the chair can be easily pushed under a desk.

ERGONOMIC DESIGN

Provide comfortable support while working or playing.



Figure 5.2: Swivel, Height, and Tilting Functions

5.3 Rocking Function

Loosen the button underneath the chair to activate a rocking motion (90°-122° tilt tension). Tighten the button to lock the chair in an upright position.



Figure 5.3: Rocking Function and Controls

6. MAINTENANCE

To ensure the longevity and appearance of your chair:

- **Cleaning:** Wipe clean with a damp cloth. Avoid harsh chemicals.
- **Inspection:** Periodically check all bolts and screws to ensure they are tight. Lubricate moving parts if necessary.
- **Protection:** Keep the PU leather away from direct sunlight and extreme temperatures to prevent cracking or fading.

7. TROUBLESHOOTING

If you encounter any issues with your chair, please refer to the following common solutions:

- **Squeaking/Noise:** Check and tighten all screws. Apply a small amount of lubricant to moving parts, especially the gas lift and mechanism.

- **Difficulty Adjusting Height:** Ensure the gas lift lever is fully engaged. If the issue persists, the gas lift cylinder may need replacement.
- **Unstable Chair:** Verify that the star base is correctly assembled and all casters are securely inserted. Ensure the chair is on a flat, even surface.

For further assistance, please contact our professional customer service team.

8. SPECIFICATIONS

Feature	Specification
Brand	Sweetcrispy
Model Name	Sweetcrispy Computer Gaming Desk Chair
Item Model Number	CDHNCJ-3801
Color	Grey
Product Dimensions	25.39"D x 27.76"W x 45.67"H
Item Weight	30 pounds
Maximum Weight Recommendation	275 Pounds
Material	PU Leather, Metal, Foam
Special Features	Arm Rest, Cushion Availability, Ergonomic, Rolling, Scratch Resistant, Tilting
Height Adjustment Range	18 inch - 22 inch
Armrest Feature	92° Flip-up Armrests
Tilting Range	90°-122°
Casters	Silent multi-direction casters, 360° swivel
Assembly Time	Estimated 17 minutes

9. WARRANTY AND SUPPORT

Sweetcrispy is committed to providing high-quality products. While specific warranty details are not provided in this manual, our professional customer service team is available to assist you with any questions or concerns regarding your chair. Please do not hesitate to contact us for support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question