

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Faber](#) /

› [Faber Zion 1600W Induction Stove User Manual](#)

Faber ZION

Faber Zion 1600W Induction Stove User Manual

Model: ZION

1. INTRODUCTION

Thank you for choosing the Faber Zion 1600W Induction Stove. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read these instructions thoroughly before first use and keep them for future reference.

2. IMPORTANT SAFETY INSTRUCTIONS

WARNING: To reduce the risk of fire, electric shock, injury to persons, or damage to the appliance, observe the following basic precautions:

- Ensure the power supply voltage matches the rating label on the appliance.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Keep the appliance out of reach of children. Close supervision is necessary when the appliance is used near children.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Place the induction stove on a stable, flat, heat-resistant surface.
- Do not block the ventilation openings. Ensure adequate space around the appliance for proper airflow.
- Use only induction-compatible cookware. Non-compatible cookware will not heat.
- Do not place metallic objects such as knives, forks, spoons, lids, cans, or aluminum foil on the induction cooktop surface, as they can become hot.
- Avoid touching the hot surface immediately after cooking. The ceramic plate retains residual heat.
- Unplug the appliance from the outlet when not in use and before cleaning.
- Do not use the appliance for purposes other than its intended use.
- This appliance is for household use only.

3. PRODUCT OVERVIEW

The Faber Zion 1600W Induction Stove features a sleek design with soft-touch controls and an LED display for easy operation. It is equipped with advanced safety features and auto-cook functions to enhance your cooking experience.

3.1 Components and Controls

Familiarize yourself with the main parts of your induction stove:

- **Crystal Glass Cooktop:** The main cooking surface.
- **Control Panel:** Soft-touch buttons for power, functions, temperature/power adjustment, and timer.
- **LED Display:** Shows power level, temperature, and timer settings.
- **Ventilation Openings:** Located on the bottom and sides for cooling.



Image: Front view of the Faber Zion 1600W Induction Stove, showing the black crystal glass cooktop and the control panel with LED display.

"Power Up Your Cooking - Fast, Efficient, and Safe"



USER-FRIENDLY OPERATION

User-friendly interface with feather-touch buttons for smooth operation.



PRESET TIMER FUNCTION

Set cooking time in advance for convenience and precision.



POWERFUL & EFFICIENT

1600W high-performance induction heating ensures fast and even cooking.



5 AUTO-COOK FUNCTIONS

Pre-set modes for effortless cooking, including boiling, frying, and simmering.

Image: Illustration showing the Faber Zion Induction Stove is compatible with various types of induction-ready cookware, including stainless steel pots, cast iron pans, and kettles.

4. SETUP

- Unpacking:** Carefully remove the induction stove from its packaging. Retain the packaging for future storage or transport.
- Placement:** Place the induction stove on a dry, stable, and heat-resistant surface. Ensure there is at least 10-15 cm of clear space around all sides for proper ventilation. Do not place it near heat sources or on metallic surfaces that could interfere with induction.
- Power Connection:** Plug the power cord into a grounded electrical outlet. Ensure the outlet voltage matches the appliance's requirements (1600W).
- Initial Cleaning:** Before first use, wipe the ceramic glass surface with a soft, damp cloth.

5. OPERATING INSTRUCTIONS

5.1 Basic Operation

- Power On:** Place an induction-compatible pot or pan centrally on the cooktop. Press the **ON/OFF** button. The LED display will light up.
- Select Function:** Press the **Function** button to cycle through different cooking modes or adjust power/temperature using the **+/** buttons.
- Adjust Settings:** Use the **+/** buttons to increase or decrease the power level or temperature.
- Power Off:** Press the **ON/OFF** button to turn off the appliance after cooking. The fan may continue to run for a short period to cool down internal components.

5.2 Auto Pan Detection

The Faber Zion Induction Stove features an intelligent auto pan detection system. If no induction-compatible cookware is placed on the cooktop, or if the cookware is removed during operation, the appliance will display an error code (e.g., "E0") and automatically shut off after a short period. Ensure your cookware is suitable for induction cooking.

5.3 Auto-Cook Functions

The induction stove includes 5 preset auto-cook functions for convenience. These functions are optimized for common cooking tasks:

- Specific functions may vary, refer to the control panel icons for details (e.g., Fry, Boil, Milk, Curry, Dosa).
- To use an auto-cook function, press the **Function** button until the desired preset is selected. The stove will automatically adjust power and time settings.

5.4 Preset Timer

The integrated timer allows you to set a cooking duration up to 180 minutes. Once the set time expires, the stove will automatically turn off.

1. While cooking, press the **Timer** button.
2. Use the **+-** buttons to adjust the desired cooking time.
3. The timer will start counting down. Once it reaches zero, the stove will switch off.

"INSTANT HEAT, INSTANT DELICIOUS - COOK LIKE A PRO"



Image: The Faber Zion Induction Stove with a pot of food, showing the LED display indicating a 180-minute timer setting.

5.5 Overheat Protection

The induction stove is equipped with an overheat protection feature. If the internal temperature becomes excessively high, the appliance will automatically reduce power or shut down to prevent damage. Allow the unit to cool down before resuming operation.

6. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your induction stove.

1. **Always unplug** the appliance from the power outlet before cleaning.
2. **Cool Down:** Allow the cooktop surface to cool completely before cleaning.
3. **Cooktop Surface:** Wipe the black crystal glass surface with a soft, damp cloth and mild detergent. For stubborn stains, use a non-abrasive ceramic cooktop cleaner. Do not use abrasive pads, scourers, or harsh chemicals.
4. **Control Panel:** Wipe the control panel with a soft, dry cloth. Avoid excessive moisture.
5. **Ventilation Openings:** Periodically check and clean the ventilation openings to ensure they are free from dust and debris. Use a soft brush or vacuum cleaner.
6. **Storage:** When not in use for extended periods, store the appliance in a dry, safe place.

Your Compact Kitchen Companion



Durable Material



Premium Quality



LED Display



Image: A hand wiping the surface of the Faber Zion Induction Stove with a blue cleaning cloth, demonstrating easy cleaning.

7. TROUBLESHOOTING

Before contacting customer service, please refer to the following table for common issues and their solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	No power supply; Power cord not plugged in; Fuse blown.	Check power outlet; Ensure plug is securely inserted; Check household fuse/circuit breaker.
Cookware not heating (Error code E0).	Cookware is not induction-compatible; Cookware is too small or not centered; No cookware on cooktop.	Use induction-compatible cookware; Ensure cookware base covers the induction zone; Place cookware centrally.
Cooking stops unexpectedly (Error code E1/E2).	Overheat protection activated; Ventilation blocked.	Turn off and unplug the unit, allow it to cool down; Clear any obstructions from ventilation openings.
Fan continues to run after turning off.	Normal cooling process.	This is normal. The fan will stop automatically once the internal components have cooled.

If the problem persists after trying these solutions, please contact Faber customer support.

8. SPECIFICATIONS

Feature	Detail

Feature	Detail
Model Number	ZION
Power Consumption	1600W
Control Type	Soft-Touch Control
Display	4-Digit LED Display
Auto-Cook Functions	5 Preset Functions
Timer	Up to 180 Minutes
Safety Features	Auto Pan Detection, Overheat Protection, Shock-Proof Body
Cooktop Material	Black Crystal Glass
Dimensions (LxWxH)	28.2 x 32.5 x 6.7 Centimeters
Item Weight	2 kg 100 g
Included Components	1N Main Unit, 1N User Manual, 1N Warranty Card



Induction

Up To
90%
Energy
efficiency



Time to boil
2L of water

PRECISE & REACTIVE



Ceramic

Up To
70%
Energy
efficiency



Time to boil
2L of water

APPROXIMATE



Gas

Up To
55%
Energy
efficiency



Time to boil
2L of water

BASIC



Image: The Faber Zion Induction Stove showing its physical dimensions: 359mm length, 289mm width, and 38mm height.

9. WARRANTY AND SUPPORT

The Faber Zion 1600W Induction Stove comes with a **1 Year On Product Warranty**. Please retain your purchase receipt for warranty claims.

For technical assistance, service, or warranty inquiries, please contact Faber customer support:

- **Manufacturer:** Franke Faber India Pvt Ltd
- **Contact Number:** 1800-209-3484
- **Address:** 1086/1/2, SANASWADI, TAL - SHIRUR, PUNE - 412208, MAHARASHTRA, INDIA
- You can also visit the official [Faber Store on Amazon](#) for more information.

