

Manuals.plus /

› EtlIN /

› EtlIN 2269 Side Brush for Vileda VR 303 Robot Vacuum Cleaner - Instruction Manual

EtlIN 2269

EtlIN 2269 Side Brush Instruction Manual

For Vileda VR 303 Robot Vacuum Cleaner

INTRODUCTION

This manual provides instructions for the installation and maintenance of your EtlIN 2269 replacement side brush. This accessory is designed to ensure your Vileda VR 303 robot vacuum cleaner maintains optimal cleaning performance, reaching corners and edges effectively.

COMPATIBILITY

The EtlIN 2269 side brush is specifically designed for use with the following robot vacuum cleaner model:

- **Vileda VR 303**

Using this brush with incompatible models may result in improper fit or reduced performance.

PACKAGE CONTENTS

Please verify that all items are present in your package:

- 1 x EtlIN 2269 Side Brush

INSTALLATION INSTRUCTIONS

Follow these steps to install the replacement side brush:

1. **Power Off:** Ensure your Vileda VR 303 robot vacuum cleaner is turned off and disconnected from its charging base before beginning installation.
2. **Access the Brush:** Carefully turn the robot vacuum cleaner upside down to expose the underside.
3. **Remove Old Brush:** Locate the existing side brush. Depending on the model, it may be held in place by a screw or a simple snap mechanism. Unscrew or gently pull off the old brush.

4. **Clean Area:** While the old brush is removed, it is recommended to clean any accumulated dust or debris from the brush's mounting area.
5. **Install New Brush:** Align the new EtliN 2269 side brush with the mounting post. If there's a screw, secure it. If it's a snap-on type, press firmly until it clicks into place. Ensure the brush is securely attached and can rotate freely.
6. **Verify:** Turn the robot vacuum cleaner right-side up. The installation is complete.



Image 1: EtliN 2269 Side Brush. This image shows the replacement side brush, which is designed to sweep debris from edges and corners into the vacuum's path.

MAINTENANCE

Regular maintenance of your side brush is crucial for optimal cleaning performance and extending the lifespan of your robot vacuum cleaner.

- **Cleaning Frequency:** Inspect the side brush weekly for tangled hair, threads, or debris. Clean as needed.
- **Cleaning Procedure:**
 - a. Turn off the robot vacuum cleaner.
 - b. Remove the side brush as described in the installation steps.
 - c. Carefully remove any tangled hair or debris from the bristles and the brush shaft. You may use

a small brush or a pair of scissors for this task.

d. Reinstall the clean side brush.

- **Replacement Frequency:** Side brushes typically need replacement every 3-6 months, depending on usage and environment. Replace sooner if bristles are visibly worn, bent, or damaged, as this can affect cleaning efficiency.

TROUBLESHOOTING

If you encounter issues with your side brush, refer to the following common problems and solutions:

- **Brush Not Spinning:**
 - **Check for Obstructions:** Turn off the robot and remove the brush. Inspect the brush and its mounting area for tangled hair, large debris, or foreign objects that might be preventing rotation. Clean thoroughly.
 - **Improper Installation:** Ensure the brush is correctly installed and securely fastened. Refer to the "Installation Instructions" section.
 - **Worn Brush:** If the brush is old and heavily worn, the motor might struggle to spin it. Consider replacing the brush.
- **Reduced Cleaning Performance:**
 - **Worn Bristles:** Over time, bristles can become bent or worn, reducing their effectiveness. Replace the side brush if bristles show significant wear.
 - **Dirty Brush:** A brush clogged with hair or debris cannot sweep effectively. Clean the brush regularly as per the "Maintenance" section.

SPECIFICATIONS

| | |
|---------------------------|------------------------------------|
| Brand | EtlIN |
| Model Number | 2269 |
| Compatible with | Vileda VR 303 Robot Vacuum Cleaner |
| Color | As shown |
| Item Weight | 1 g |
| Package Dimensions | 3 x 2 x 1 cm |
| Country of Origin | China |

Note: Some specifications like Voltage (110 Volts) and Capacity (500 Grams) from the product data are typically not relevant for a passive replacement part like a side brush and are therefore omitted for clarity.

WARRANTY AND SUPPORT

For information regarding warranty coverage, returns, or technical support, please refer to the seller's policies on the platform where the product was purchased. Keep your proof of purchase for any warranty claims.

For further assistance, you may contact the manufacturer EtlIN through their official channels, if available.

