

[Manuals.plus](#) /

› [Amplify](#) /

› Amplify Note 3.0 TWS Earphones User Manual

Amplify AM-1111-BK[V2]

Amplify Note 3.0 TWS Earphones User Manual

Model: AM-1111-BK[V2]

1. INTRODUCTION

Welcome to the user manual for your Amplify Note 3.0 True Wireless Stereo (TWS) Earphones. These earphones are designed to provide a high-quality audio experience and convenient hands-free communication. This manual will guide you through the setup, operation, maintenance, and troubleshooting of your device to ensure optimal performance.



Image: Amplify Note 3.0 TWS Earphones in Black, shown with their compact charging case.

2. PACKAGE CONTENTS

Please check the package for the following items:

- Amplify Note 3.0 TWS Earphones (Left and Right)
- Charging Case
- USB Charging Cable
- User Manual

3. SETUP

3.1 Charging the Earphones and Case

Before first use, fully charge the charging case and earphones.

1. Connect the provided USB charging cable to the charging port on the case and to a USB power source (e.g., wall adapter, computer USB port).
2. The indicator lights on the charging case will show the charging status. Once fully charged, the lights will indicate completion or turn off.
3. Place the earphones into the charging slots inside the case. Ensure they are correctly seated. The earphones will begin charging automatically.
4. The earphones have up to 6 hours of playtime on a single charge, and the charging case provides up to 3 additional full recharges.

3.2 Bluetooth Pairing

To connect your Amplify Note 3.0 TWS Earphones to your device:

1. Ensure the earphones are charged.
2. Open the charging case. The earphones will automatically power on and enter pairing mode.
3. On your smartphone or other Bluetooth-enabled device, go to the Bluetooth settings.
4. Search for available devices and select "Amplify Note 3.0" from the list.
5. Once connected, you will hear a confirmation tone, and the earphones will be ready for use.
6. The earphones feature Bluetooth 5.3 for fast pairing and a stable connection.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off

- **Power On:** Open the charging case, and the earphones will power on automatically.
- **Power Off:** Place the earphones back into the charging case and close the lid. They will power off automatically.

4.2 Music Playback

The earphones feature touch controls for managing your music:

- **Play/Pause:** Tap either earphone once.
- **Next Track:** Double-tap the right earphone.
- **Previous Track:** Double-tap the left earphone.

4.3 Call Management

With the built-in microphone, you can manage calls hands-free:

- **Answer Call:** Tap either earphone once.
- **End Call:** Tap either earphone once during a call.
- **Reject Call:** Press and hold either earphone for 2 seconds.

4.4 Wearing the Earphones

Gently insert the earphones into your ears, ensuring a comfortable and secure fit. Adjust them slightly to achieve optimal sound quality and passive noise isolation.

5. MAINTENANCE

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the earphones and charging case. Do not use harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the earphones in their charging case to protect them from dust and damage. Store in a cool, dry place.
- **Battery Care:** To prolong battery life, avoid fully discharging the earphones and charging case frequently. Charge them regularly, even if not in constant use.

6. TROUBLESHOOTING

- **Earphones not pairing:** Ensure both earphones are charged and out of the case. Turn off Bluetooth on your device, then turn it back on and try pairing again. If issues persist, try resetting the earphones (refer to manufacturer's website for specific reset instructions if not provided here).
- **No sound from one earphone:** Place both earphones back into the charging case, close the lid, wait a few seconds, then open the lid and try again. Ensure both earphones are charged.
- **Charging issues:** Check the USB cable and power source. Ensure the charging contacts on the earphones and inside the case are clean and free of debris.
- **Connection drops:** Ensure you are within the Bluetooth range of your device. Avoid obstacles that may interfere with the signal.

7. SPECIFICATIONS

Feature	Specification
Brand	Amplify
Model Number	AM-1111-BK[V2]
Colour	Black
Ear Placement	In Ear
Form Factor	In-ear
Impedance	32 Ohms
Noise Control	None
Frequency Response	20 KHz
Sensitivity	108 dB
Wireless Technology	Bluetooth 5.3
Playtime	Up to 6 hours
Charging Case Recharges	Up to 3 full recharges
Item Weight	0.1 Kilograms

8. WARRANTY & SUPPORT

8.1 Warranty Information

Your Amplify Note 3.0 TWS Earphones come with a **1 Year Warranty** from the date of purchase. This warranty covers manufacturing defects. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

8.2 Customer Support

For technical assistance, warranty claims, or further inquiries, please contact Amplify customer support through the retailer where the product was purchased or visit the official Amplify website for contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I reset my Amplify Note 3.0 earpods if the right earbud is not connecting?

To resolve connection issues where one earbud (like the right bud) is not connecting on your Amplify Note 3.0 (AM-1111-BK[V2]), please follow these troubleshooting and reset steps:Resync the Earbuds: Place both earphones back into...

[Read full answer](#)