MAGEASY MAAIWA130WH22

MAGEASY 4-in-1 Charging Station User Manual

Model: MAAIWA130WH22

Thank you for choosing the MAGEASY 4-in-1 Charging Station. This manual provides essential information for safe and efficient use of your device.

1. Product Overview

The MAGEASY 4-in-1 Charging Station is designed to simultaneously charge your iPhone, Apple Watch, AirPods, and an additional device via its USB-C output. It features a magnetic charging stand for iPhones, a dedicated Apple Watch charger, an AirPods charging pad, and adjustable ambient lighting.



Image 1.1: The MAGEASY 4-in-1 Charging Station, showcasing its ability to charge an iPhone, Apple Watch, and AirPods simultaneously. An additional device can be charged via the USB-C port.

2. Package Contents

- MAGEASY 4-in-1 Charging Station
- User Manual

Note: A power adapter (60W-65W recommended) is not included and must be purchased separately for optimal performance.

3. Setup Instructions

1. **Connect Power:** Plug the provided charging cable into the USB-C input port on the back of the

charging station. Connect the other end of the cable to a 60W-65W power adapter (not included).

2. **Power On:** Plug the power adapter into a wall outlet. The charging station will power on, and the ambient light may briefly illuminate.
3. **Placement:** Place the charging station on a stable, flat surface such as a desk or nightstand. Ensure adequate ventilation around the device.



Image 3.1: Illustration emphasizing the requirement of a 60W-65W power adapter for adequate power supply to the charging station. Adapters below 60W may result in inadequate charging performance, especially when charging multiple devices.

4. Operating Instructions

4.1 Charging Devices

- **iPhone (Magnetic Charging Stand):** Place your MagSafe-compatible iPhone (iPhone 12 series and newer) or an iPhone with a MagSafe-compatible case onto the magnetic charging stand. The phone will snap into place and begin charging wirelessly at up to 15W (7.5W for iPhones).
- **Apple Watch:** Place your Apple Watch onto the dedicated charging puck. Ensure the watch is properly aligned for charging to begin.
- **AirPods:** Place your AirPods charging case (AirPods 1/2/3/Pro) onto the designated wireless

charging pad on the base. The indicator light on your AirPods case will confirm charging.

- **External Devices (USB-C Output):** Connect a compatible device (e.g., iPad Pro, power bank, other Android phones) to the USB-C output port on the back of the charging station using an appropriate cable. This port provides up to 20W output.



Image 4.1: This image illustrates the power distribution capabilities of the MAGEASY charging station, indicating 15W for phones, 15W for AirPods, 5W for Apple Watches, and 20W via the USB-C output for external devices, totaling a 55W maximum output.

4.2 Ambient Lighting

The charging station features adjustable ambient lighting. Locate the touch-sensitive control on the base of the unit. Tap to cycle through 3 levels of brightness or to turn the light off.



Image 4.2: The MAGEASY charging station displayed on a nightstand with its ambient lighting feature activated, showing a soft glow around the base. This light has three adjustable intensity levels.

5. Compatibility

The MAGEASY 4-in-1 Charging Station is compatible with a wide range of devices:

- **iPhones:** iPhone 12, 13, 14, 15 series (including Pro, Pro Max, Plus, Mini models). Requires MagSafe compatibility or a MagSafe-compatible case.
- **Apple Watch:** Apple Watch Ultra 1~2, Series 1~9, SE.
- **AirPods:** AirPods Pro, AirPods 2~3.
- **Other Devices:** Qi-enabled Android phones (e.g., Samsung Galaxy S9-S23 series) on the base charging pad, and iPad Pro or other devices using the USB-C output port.



Image 5.1: A visual guide detailing the compatibility of the MAGEASY charging station with various Apple devices, including iPhone 12~15 Series, AirPods Pro/2~3, Apple Watch Ultra 1~2/Series 1~9/SE, and other devices via the Type-C output port.

6. Maintenance

- **Cleaning:** Disconnect the power before cleaning. Use a soft, dry, lint-free cloth to wipe the surface of the charging station. Do not use abrasive cleaners, solvents, or aerosol sprays.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures when not in use for extended periods.

7. Troubleshooting

- **Device not charging:**
  - Ensure the charging station is connected to a 60W-65W power adapter and plugged into a live outlet.
  - Verify that your device is correctly aligned on its respective charging area.
  - Remove any thick or non-MagSafe compatible phone cases that might interfere with wireless

charging.
    - Check if the device is compatible with the charging station (refer to Section 5).
- **Slow charging:**
    - Confirm you are using a 60W-65W power adapter. Lower wattage adapters will reduce charging speed, especially when multiple devices are connected.
    - Ensure no foreign objects are between the device and the charging surface.
    - Close unnecessary background applications on your device.
- **Ambient light not working:**
    - Ensure the charging station is powered on.
    - Tap the touch-sensitive control on the base to cycle through brightness levels.

8. Specifications

Feature	Detail
Model Number	MAAIWA130WH22
Product Dimensions	12.45 x 12.45 x 16.26 cm
Product Weight	531 g
Max Output	55W (Total)
iPhone Wireless Charging	Up to 15W (7.5W for iPhones)
AirPods Wireless Charging	Up to 15W
Apple Watch Charging	Up to 5W
USB-C Output	Up to 20W
Input Power Requirement	60W-65W Power Adapter (not included)
Special Features	Adjustable Ambient Lighting, Overheat Protection, Over Voltage Protection, Over Current Protection, Short Circuit Protection

9. Warranty and Support

MAGEASY products are manufactured to high-quality standards. For information regarding warranty coverage and customer support, please refer to the warranty card included with your purchase or visit the official MAGEASY website. Please retain your proof of purchase for warranty claims.

© 2023 MAGEASY. All rights reserved.